

LMS5xx

2D LiDAR sensors

SICK
Sensor Intelligence.



Described product

LMS5xx

Manufacturer

SICK AG
Erwin-Sick-Str. 1
79183 Waldkirch
Germany

Legal information

This work is protected by copyright. Any rights derived from the copyright shall be reserved for SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Any modification, abridgment or translation of this document is prohibited without the express written permission of SICK AG.

The trademarks stated in this document are the property of their respective owner.

© SICK AG. All rights reserved.

Original document

This document is an original document of SICK AG.



Contents

1	About this document.....	7
1.1	Information on the operating instructions.....	7
1.2	Explanation of symbols.....	7
1.3	Further information.....	8
2	Safety information.....	9
2.1	Intended use.....	9
2.2	Improper use.....	9
2.3	Cybersecurity.....	9
2.4	Limitation of liability.....	9
2.5	Modifications and conversions.....	10
2.6	Requirements for skilled persons and operating personnel.....	10
2.7	Operational safety and specific hazards.....	10
3	Product description.....	12
3.1	Scope of delivery.....	12
3.2	Device variants.....	12
3.2.1	Device views.....	13
3.2.2	Functional scope of the different device variants.....	14
3.2.3	Heavy Duty variants with ventilation element.....	16
3.2.4	Extended Range variants.....	17
3.3	Type code.....	18
3.4	Type label.....	19
3.5	Status indicators.....	20
3.6	Principle of operation.....	22
3.6.1	Measurement principle.....	22
3.6.2	Distance measurement.....	22
3.6.3	Direction measurement.....	22
3.6.4	Impact of object surfaces on the measurement.....	23
3.6.5	Distance between the device and the object/surface to be monitored.....	24
3.6.6	Sensing range.....	25
3.6.7	Beam diameter and measuring point distance.....	27
3.6.8	Minimum object size.....	30
3.6.9	Contamination measurement.....	31
3.6.10	Calculation of the field size for mobile applications.....	32
3.6.10.1	Switching field length.....	33
3.6.10.2	Switching field width.....	34
3.7	Fields of application.....	34
3.7.1	Object measurement.....	35
3.7.1.1	Basic parameters.....	35
3.7.1.2	Interlaced mode.....	37
3.7.1.3	Multi-echo analysis.....	38
3.7.1.4	Filter.....	39

3.7.1.5	Output of measured values.....	41
3.7.1.6	RSSI values.....	44
3.7.2	Field application.....	46
3.7.2.1	Detection fields.....	47
3.7.2.2	Evaluation cases.....	48
3.7.2.3	Linking of evaluation cases at the output.....	51
3.8	Inputs and outputs.....	51
3.9	Data interfaces.....	54
3.10	Communicating data via telegrams.....	55
4	Transport and storage.....	56
4.1	Transport.....	56
4.2	Unpacking.....	56
4.3	Transport inspection.....	56
4.4	Storage.....	56
5	Mounting.....	57
5.1	Mounting instructions.....	57
5.2	Mounting the device.....	57
5.3	Mounting multiple devices.....	58
6	Electrical installation.....	59
6.1	Wiring instructions.....	59
6.2	Overview of the installation steps.....	59
6.3	Prerequisites for safe operation of the device.....	60
6.4	Connections.....	64
6.4.1	Connections of the LMS500.....	64
6.4.2	Connections of LMS511, LMS581 and LMS511 Heavy Duty.....	67
6.4.3	Connections of the LMS531 Security Outdoor.....	69
6.4.4	Connections of the LMS511 with Harting male connector...	72
6.5	Preparing electrical installation.....	73
6.5.1	SELV supply voltage.....	73
6.5.2	Wire cross-sections for LMS500 Indoor.....	73
6.5.3	Wire cross-sections for LMS5x1 Outdoor.....	74
6.5.4	Cable reserve on system plug.....	75
6.5.5	General conditions for data interfaces.....	75
6.6	Performing the electrical installation.....	75
6.6.1	Connection to the auxiliary interface (USB) and the Ethernet interface of the device.....	75
6.6.2	LMS500: Wiring system plug.....	76
6.6.3	LMS511 / LMS531 / LMS581: Connecting M12 round connectors.....	77
6.6.4	Wiring the inputs and outputs.....	77
7	Commissioning.....	81
7.1	Overview of the commissioning steps.....	81

7.2	SOPAS ET configuration software.....	81
7.3	Establishing communication with the device.....	82
7.4	Initial commissioning.....	83
7.4.1	Parameterizing the LMS531 variants for security applications.....	85
7.4.1.1	Default – Standard mode and Expertmode	86
7.4.1.2	Detection fields/monitored areas.....	87
7.4.1.3	Operating mode.....	87
7.4.1.4	Day/night switching (LMS531 Pro).....	88
7.4.1.5	Digital outputs and relay outputs.....	88
7.4.1.6	EasyTeach.....	89
7.4.1.7	Special functions.....	92
7.5	Connecting and performing a test measurement.....	95
8	Maintenance.....	97
8.1	Cleaning.....	97
8.2	Maintenance plan.....	97
8.3	Device replacement.....	97
8.3.1	Exchange of the LMS500 Lite/PRO or LMS511 Heavy Duty when reusing the previous system plug (parameter cloning).....	98
8.3.2	Complete replacement of the LMS5x1 (without reuse of the previous system plug).....	99
8.3.3	Parameter cloning (LMS500 Lite/PRO and LMS511 Heavy Duty).....	100
9	Troubleshooting.....	101
9.1	Repairs.....	101
9.2	Returns.....	101
9.3	General faults, warnings, and errors.....	101
9.3.1	LED fault indicators.....	101
9.3.2	Indicators in the 7-segment display.....	102
9.3.3	Detailed fault analysis.....	102
9.3.4	Resetting the password for the Service user level.....	103
9.4	Disposal.....	104
10	Technical data.....	105
10.1	Features.....	105
10.2	Performance.....	108
10.3	Interfaces.....	109
10.4	Mechanics/electronics.....	111
10.5	Ambient data.....	112
10.6	Dimensional drawings.....	114
11	Accessories.....	116
12	Annex.....	117
12.1	Declarations of conformity and certificates.....	117

- 12.2 Telegram listing (EN)..... 117
 - 12.2.1.1 About this document..... 120
 - 12.2.1.2 Communication format..... 121
 - 12.2.1.3 Workflows..... 124
 - 12.2.1.4 Telegrams..... 126
 - 12.2.1.5 Diagnostics..... 248

1 About this document

1.1 Information on the operating instructions

These operating instructions provide important information on how to use devices from SICK AG.

Prerequisites for safe work are:

- Compliance with all safety notes and handling instructions supplied.
- Compliance with local work safety regulations and general safety regulations for device applications

The operating instructions are intended to be used by qualified personnel and electrical specialists.



NOTE

Read these operating instructions carefully to familiarize yourself with the device and its functions before commencing any work.

The operating instructions are an integral part of the product. Store the instructions in the immediate vicinity of the device so they remain accessible to staff at all times. Should the device be passed on to a third party, these operating instructions should be handed over with it.

These operating instructions do not provide information on the handling and safe operation of the machine or system in which the device is integrated. Information on this can be found in the operating instructions for the machine or system.

1.2 Explanation of symbols

Warnings and important information in this document are labeled with symbols. Signal words introduce the instructions and indicate the extent of the hazard. To avoid accidents, damage, and personal injury, always comply with the instructions and act carefully.



DANGER

... indicates a situation of imminent danger, which will lead to a fatality or serious injuries if not prevented.



WARNING

... indicates a potentially dangerous situation, which may lead to a fatality or serious injuries if not prevented.



CAUTION

... indicates a potentially dangerous situation, which may lead to minor/slight injuries if not prevented.



NOTICE

... indicates a potentially harmful situation, which may lead to material damage if not prevented.



NOTE

... highlights useful tips and recommendations as well as information for efficient and trouble-free operation.

1.3 Further information

More information can be found on the product page.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

The following information is available depending on the product:

- Data sheets
- This document in all available language versions
- CAD files and dimensional drawings
- Certificates (e.g., declaration of conformity)
- Other publications
- Software
- Accessories

2 Safety information

2.1 Intended use

The LMS5xx is a non-contact optical distance measurement sensor in standalone or network operation based on a 2D-LiDAR sensor. It is suitable for applications which demand precise, non-contact optical measuring contours and dimensioning. It can also be used to implement systems for collision protection, object protection or access monitoring, for example.

The device may only be put into operation by authorized staff and only in industrial environments.

SICK AG assumes no liability for losses or damage arising from the use of the product, either directly or indirectly. This applies in particular to use of the product that does not conform to its intended purpose and is not described in this documentation.

2.2 Improper use

Any use outside of the stated areas, in particular use outside of the technical specifications and the requirements for intended use, will be deemed to be incorrect use.

- The device does not constitute a safety component in accordance with the respective applicable safety standards for machines.
- The device must not be used in explosion-hazardous areas, in corrosive environments or under extreme environmental conditions.
- Any use of accessories not specifically approved by SICK AG is at your own risk.



WARNING

Danger due to improper use!

Any improper use can result in dangerous situations.

Therefore, observe the following information:

- Product should be used only in accordance with its intended use.
- All information in the documentation must be strictly observed.
- Shut down the product immediately in case of damage.

2.3 Cybersecurity

Overview

To protect against cybersecurity threats, it is necessary to continuously monitor and maintain a comprehensive cybersecurity concept. A suitable concept consists of organizational, technical, procedural, electronic, and physical levels of defense and considers suitable measures for different types of risks. The measures implemented in this product can only support protection against cybersecurity threats if the product is used as part of such a concept.

You will find further information at www.sick.com/psirt, e.g.:

- General information on cybersecurity
- Contact option for reporting vulnerabilities
- Information on known vulnerabilities (security advisories)

2.4 Limitation of liability

Relevant standards and regulations, the latest technological developments, and our many years of knowledge and experience have all been taken into account when compiling the data and information contained in these operating instructions. The manufacturer accepts no liability for damage caused by:

- Non-adherence to the product documentation (e.g., operating instructions)
- Incorrect use
- Use of untrained staff
- Unauthorized conversions or repair
- Technical modifications
- Use of unauthorized spare parts, consumables, and accessories

2.5 Modifications and conversions



NOTICE

Modifications and conversions to the device may result in unforeseeable dangers.

Interrupting or modifying the device or SICK software will invalidate any warranty claims against SICK AG. This applies in particular to opening the housing, even as part of mounting and electrical installation.

2.6 Requirements for skilled persons and operating personnel



WARNING

Risk of injury due to insufficient training.

Improper handling of the device may result in considerable personal injury and material damage.

- All work must only ever be carried out by the stipulated persons.

The following qualifications are required for various activities:

Table 1: Activities and technical requirements

Activities	Qualification
Mounting, maintenance	■ Basic practical technical training ■ Knowledge of the current safety regulations in the workplace
Electrical installation, device replacement	■ Practical electrical training ■ Knowledge of current electrical safety regulations ■ Knowledge of the operation and control of the devices in their particular application
Commissioning, configuration	■ Basic knowledge of the computer operating system used ■ Basic knowledge of the design and setup of the described connections and interfaces ■ Basic knowledge of data transmission
Operation of the device for the particular application	■ Knowledge of the operation and control of the devices in their particular application ■ Knowledge of the software and hardware environment for the particular application

2.7 Operational safety and specific hazards

Please observe the safety notes and the warnings listed here and in other sections of this product documentation to reduce the possibility of risks to health and avoid dangerous situations.

**CAUTION****Optical radiation: Class 1 Laser Product**

The accessible radiation does not pose a danger when viewed directly for up to 100 seconds. It may pose a danger to the eyes and skin in the event of incorrect use.

- Do not open the housing. Opening the housing may increase the level of risk.
- Current national regulations regarding laser protection must be observed.

Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

It is not possible to entirely rule out temporary disorienting optical effects, particularly in conditions of dim lighting. Disorienting optical effects may come in the form of dazzle, flash blindness, afterimages, photosensitive epilepsy, or impairment of color vision, for example.

**WARNING****Electrical voltage!**

Electrical voltage can cause severe injury or death.

- Work on electrical systems must only be performed by qualified electricians.
- The power supply must be disconnected when attaching and detaching electrical connections.
- The product must only be connected to a voltage supply as set out in the requirements in the operating instructions.
- National and regional regulations must be complied with.
- Safety requirements relating to work on electrical systems must be complied with.

**WARNING****Risk of injury and damage caused by potential equalization currents!**

Improper grounding can lead to dangerous equipotential bonding currents, which may in turn lead to dangerous voltages on metallic surfaces, such as the housing. Electrical voltage can cause severe injury or death.

- Work on electrical systems must only be performed by qualified electricians.
- Follow the notes in the operating instructions.
- Install the grounding for the product and the system in accordance with national and regional regulations.

3 Product description

3.1 Scope of delivery

The delivery of the device includes the following components:

Table 2: Scope of delivery

No. of units	Components	Remarks
1	Device in the version ordered	Type depends on order Put plastic protective caps on all M12 round connectors and cable entries.
1	Printed safety notes, multilingual	Brief information and general safety notes

The actual scope of delivery may differ for special designs, additional orders or due to the latest technical changes.

3.2 Device variants

Table 3: Device variants

Type	Purpose	Sensing range
LMS500-2x000 Lite/PRO	Indoor	Max. 80 m 26 m at 10%
LMS511-1x100 Lite/PRO/Heavy Duty	Outdoor	Max. 80 m 40 m at 10%
LMS511-2x100 Lite/PRO/Heavy Duty	Outdoor	Max. 80 m 26 m at 10%
LMS531-1x100 Lite/PRO	Outdoor Security	Max. 80 m 40 m at 10%
LMS581-10100 PRO	Outdoor	Max. 80 m 40 m at 10%
LMS581-20100 PRO	Outdoor	Max. 80 m 26 m at 10% ¹⁾
LMS511-15100 Heavy Duty Extended Range	Outdoor	Max. 130 m 52 m at 10% ¹⁾
LMS531-15100 Heavy Duty Extended Range	Outdoor Security	Max. 130 m 52 m at 10% ¹⁾

¹⁾ Reflectance

Simplified device designation in the document

In the following instructions, the LMS5xx 2D LiDAR sensor is referred to simply as “device” or “LMS5xx”. except in cases where it is necessary to make a distinction between device variants due to different technical features or functions. In this case, either the designation of the variant series (e.g. LMS511 PRO Outdoor) or the complete type designation according to the type code (e.g., LMS500-20000) is used.

3.2.1 Device views




Figure 1: View of the LMS500 Indoor

- ① System plug (removable) with terminal blocks and cloning parameter memory for device replacement with automated configuration of the replacement device
- ② Viewing window (laser output aperture)
- ③ Mark of horizontal measurement origin
- ④ “Ethernet” connection
- ⑤ “USB” connection
- ⑥ Status indicators
- ⑦ Cable entry




Figure 2: View of the LMS511/581/531 Outdoor

- ① System plug with cloning parameter memory. Removable only for LMS511 Heavy Duty for device replacement with automated configuration of the replacement device
- ② Viewing window (laser output aperture)
- ③ Mark of horizontal measurement origin
- ④ “Ethernet” connection
- ⑤ “I/O” connection; LMS531 Security: “Alarm” connection
- ⑥ “Data” connection; LMS531 Security: “Inputs” connection
- ⑦ “Power” connection
- ⑧ “USB” connection
- ⑨ Status indicators

3.2.2 Functional scope of the different device variants

Device settings

Table 4: Device settings

Function	LMS500 / LMS511	LMS531
Standard mode / Expert mode	–	x
Scanning frequency, angular resolution adjustable	x	x
Device time adjustable or via NTP	x	x
Standby mode	x	x
Identify	x	x

Interfaces

Table 5: Interfaces

Function	LMS500 / LMS511	LMS531
Freely definable inputs and outputs	x	–
Expandable outputs via CAN module	x	x
Input for encoder	x	–
Configurable data output format	x	–

Function	LMS500 / LMS511	LMS531
IO mapping	x	x
Process data interface: Serial and Ethernet	x	x
Display can be deactivated	x	x

Filter

Table 6: Filter

Function	LMS500 / LMS511	LMS531
Average filter	x	x
Echo filter	x	x
Particle filter	x	x
Fog filter	x	x
Glare filter	x	x

Status information

Table 7: Status information

Function	LMS500 / LMS511	LMS531
Device status	x	x
Device temperature	x	x
Display of scan data and detection fields	x	x
Field evaluation interruption history	x	x
Adjustable contamination measurement	x	x
Heating status	x	x
Status of synchronization	x	–
Encoder signal status	x	–

Field evaluation

Table 8: Field evaluation

Function	LMS500 / LMS511	LMS531
Preset field sets and detection cases	–	x
Evaluation of blanking size, pixel, reference contour	x	x
Distance-based blanking	x	x
Dynamic adjustment of the field size	x	–
Perpendicular distance	x	x
Teach-in	x	x
EasyTeach LITE	–	x
EasyTeach PRO	–	x
Automatic field adjustment (snow height adjustment)	x	x
Movement shadows monitoring	x	x

Additional functions

Table 9: Additional functions

Function	LMS500 / LMS511	LMS531
Manipulation protection teach-in	–	x

Function	LMS500 / LMS511	LMS531
Manipulation prevention	x	x
Validity check	–	x

The LMS531 variants are specially optimized for security applications and have hardware and software adapted for this purpose. The security variants are optimized for field evaluation applications and are not suitable for measurement data output.



NOTE

For more information about the special functions of the LMS531 see ["Parameterizing the LMS531 variants for security applications"](#), page 85.


3.2.3 Heavy Duty variants with ventilation element

The ventilation element ensures an improved pressure equalization and allows the exchange of air and heat between the sensor housing and the environment. The breathable membrane allows ambient air to either penetrate into the device, or escape again depending on the prevailing ambient conditions. In particular for applications with frequently changing environmental influences (e.g., large temperature fluctuations or fast temperature changes) or with standing water, the membrane ensures a reliable pressure equalization and thereby relieves the seals and adhesive joints of the sensor housing. This can improve the expected service life of the device in the application.

Table 10: Device variants

Type	Purpose	Sensing range
LMS511-12100S08 Heavy Duty	Outdoor	Max. 80 m 40 m at 10% ¹⁾
LMS511-22100S08 Heavy Duty	Outdoor	Max. 80 m 26 m at 10% ¹⁾
LMS531-10100	Outdoor Security	Max. 80 m 40 m at 10% ¹⁾
LMS531-11100	Outdoor Security	Max. 80 m 40 m at 10% ¹⁾
LMS511-15100 Heavy Duty Extended Range	Outdoor	Max. 130 m 52 m at 10% ¹⁾
LMS531-15100 Heavy Duty Extended Range	Outdoor Security	Max. 130 m 52 m at 10% ¹⁾

¹⁾ Remission factor



① Ventilation element

Notes and recommendations:

- Do not affix any labels or stickers to the ventilation element or paint over the membrane. Longer moist periods and rapid temperature changes may briefly reduce the availability of the device. This applies in particular to previously switched off devices that are started in the application and were previously exposed to the aforementioned environmental influences.
- In some circumstances, therefore, a period of time should be allowed before measurement readiness of the device because any moisture in the housing must first be taken up by the air in the housing, which is heated up through the operation of the device, so that it can then escape via the ventilation element. Depending on the nature of the precipitated moisture, this time period might be several minutes or even up to hours. It is recommended that the LMS5xx variants with a ventilation element be operated continuously during the application (continuous operation).
- It is recommended to connect the integrated sensor heating according to the specifications in the operating instructions to ensure additional heat input at low ambient temperatures.

3.2.4 Extended Range variants

The Extended Range variants feature a higher measuring range as well as an increased sensitivity over the entire measuring range. This enables objects to be measured and detected at larger distances and, in particular, makes it easier to detect objects with a low remission factor.




Figure 3: LMS5xx standard resolution working range, unit m (ft), decimal separator: period

- ① Scanning range in m
- ② Max. scanning range 80 m
- ③ Scanning range for objects up to 10% remission 40 m




Figure 4: Working range of LMS5xx Standard Resolution Extended Range, unit m (ft), decimal separator: period

- ① Scanning range in m
- ② Max. scanning range: 130 m
- ③ Scanning range for objects up to 10% remission factor: 52 m

The increased sensitivity is a preset, non-changeable device characteristic. This extension can, in some circumstances, result in an increased sensitivity to interference, for example fog, spray or rain, compared to the standard variants. The Extended Range variants are, however, designed to provide a good balance between sensitivity and availability and have been optimized accordingly. Furthermore, the Extended Range variants also feature all of the filtering options described in section [Filter](#) for preprocessing and optimizing the measured distance values. This enables the sensor parameterization to be optimally tailored to the application-specific requirements.

The Extended Range variants are Heavy Duty variants with a ventilation element, [see "Heavy Duty variants with ventilation element", page 16](#). For further details on the technical data, [see "Technical data", page 105](#).



NOTE

The Extended Range variants use different scaling factors for the data output via telegrams and differ from the standard variants in this respect.

The distance values received via data output must be multiplied by the specific factor applicable to the Extended Range variants [see table 16, page 36](#).

3.3 Type code

Type code structure

LMS a b c - d e f gg hhhh

Table 11: Type code

Position	Description	Characteristic
a	Device family	5: LMS5xx

Position	Description	Characteristic
b	Type	0: Indoor housing without heating, IP65 1: Outdoor housing with heating, IP65, IP67 3: Security outdoor housing with heating, IP65, IP67 8: Outdoor housing with heating, IP65, IP67, Special
c	Color	0: Blue 1: Gray 2: Black
-		
d	Performance	1: Standard resolution 2: High resolution
e	Variant	0: PRO 1: Lite 2: Heavy Duty 3: PRO Extended Range 4: Lite Extended Range 5: Heavy Duty Extended Range
f	Connectivity	0: PG 1: M12 standard
gg	Application	00: Standard 90: Bulkscan software
hhhh	Device type	(Empty): Standard S: Special device with consecutive number M: Sample device with consecutive number

3.4 Type label

The type label gives information for identification of the product variant.



Figure 5: Elements of the type label (example)

- ① Type code
- ② Voltage supply, typical power, max. power, operating temperature, enclosure rating
- ③ Production date
- ④ Manufacturer and production site
- ⑤ Data Matrix code with product data and link to product page
- ⑥ Part number
- ⑦ Serial number
- ⑧ MAC address
- ⑨ Conformity mark/certification mark, symbol: Observe the operating instructions!




Figure 6: Elements of the type designation label (example)

- ① Device type
- ② Conformity mark/certification mark
- ③ Hardware version

3.5 Status indicators

Operator interface

The device works fully automatically in normal operation and requires no operator intervention.

The SOPAS ET configuration software allows interactive configuration. For this, the software runs on a computer which is connected to the device with one of the data interfaces.

The graphical scan display in SOPAS ET is used to verify the generated measured values and the measuring range online.




NOTE

Scans in SOPAS ET are not displayed in real time, but at a limited speed. Not all measured values are displayed for this reason.

Status indicators

The LEDs and 7-segment display indicate the operational status of the device.



Display	Description
①	Device is either not in measuring mode (stopped by the user) or it is running in measurement mode, but errors have occurred
②	Off: No contamination On (lit up) Contamination warning On (flashing): Contamination error
③	Device running in measurement mode without any errors
④	Reserved
⑤	The 7-segment display is used for diagnostics when errors or faults occur see "Indicators in the 7-segment display", page 102.
⑥	At least one field is breached see "Linking of evaluation cases at the output", page 51.

It is recommended to also monitor the **Device Not Ready** operational status as well as messages from the contamination measurement via the digital outputs of the sensor to ensure the device readiness is continuously checked.



NOTE

As well as the standard indicators described below, the indicator functions of the LEDs and the 7-segment display can be configured in SOPAS ET for the device (SOPAS ET: **Project tree, LMS..., Parameters, Network/Interfaces/IOs, Display**).

For additional information, [see "LED fault indicators", page 101.](#)

3.6 Principle of operation

3.6.1 Measurement principle

The device is an opto-electronic LiDAR sensor that scans the outline of its surroundings with the help of laser beams without making contact. The device measures its surroundings in two-dimensional polar coordinates, relative to its measurement origin. This is indicated by small markings on the sides of the optics cover. If a laser beam strikes an object, the position of that object is determined in terms of distance and angle.





Figure 7: LiDAR sensor with one scan plane

3.6.2 Distance measurement

The device emits beams pulsed by a laser diode. If the laser beam is reflected by an object, the reflected beam is received by the sensor.

The distance to the object is calculated on the basis of the time that the pulsed light beam requires to be reflected and received by the sensor.



- ① Emitted pulse
- ② Receive pulse

3.6.3 Direction measurement

The emitted laser beams are deflected by an internal rotating mirror and scan the environment in a circular motion. The measurements are triggered by an encoder in regular angle increments.

The LMS5xx PRO/Heavy Duty measures with an adjustable scanning frequency of 25, 35, 50, 75 or 100 Hz. A laser pulse and thus a measurement is triggered continuously after each angle increment of 0.1667°, 0.25°, 0.3333°, 0.5°, 0.6667° or 1°.

In interlaced mode, the start angle of a measurement is cyclically shifted in order to achieve an even finer angular resolution [see "Interlaced mode", page 37](#).

The LMS5xx Lite measures at a configurable scanning frequency of 25, 50 or 75 Hz and at angle increments of 0.25°, 0.5° or 1°.

3.6.4 Impact of object surfaces on the measurement

The received signal from a perfectly diffuse reflection from a white surface (diffuse Lambertian reflector) corresponds to a remission of 100%. By this definition, surfaces that reflect the light in bundles (specular surfaces, reflectors) have remissions of over 100%.

Reflection

Most surfaces produce a diffuse reflection of the laser beam in all directions. The structure (smooth or rough), shape (flat or curved), and color (light or dark) of the surface determine how well the laser beam is reflected.

On very rough surfaces, a large proportion of the energy is lost due to absorption. Curved surfaces produce a higher diffusion. Dark surfaces reflect the laser beam worse than light ones (brilliant white plaster reflects approx. 100% of the light, while black foam rubber reflects approx. 2.4%). The aforementioned surface characteristics can reduce the scanning range of the device, in particular for surfaces with low remission values.




Figure 8: Reflection of light on the surface of the object

Angle of reflection

The angle of reflection corresponds to the angle of incidence. If the laser beam hits a surface at right angles, the energy is optimally reflected. If the laser beam hits a surface at an oblique angle, energy and range are lost accordingly.




Figure 9: Angle of reflection

Retroreflection

If the reflective energy is greater than 100%, the beam is not reflected diffusely in all directions; instead it is reflected in a targeted way (retroreflection). Thus a large part of the emitted energy can be received by the laser distance measurer. Plastic reflectors (cat's eyes), reflective tape, and triple prisms have these properties.




Figure 10: Retroreflection

Reflective surfaces

The laser beam is almost completely deflected on reflective surfaces. This means that an object hit by the deflected beam may be detected instead of the reflective surface.




Figure 11: Specular surfaces

Small objects

Objects that are smaller than the diameter of the laser beam cannot reflect the laser light's full energy. The portion of the light beam that does not reach the object is lost. If all of the light reflected to the sensor is insufficient, the object may not be detected.

The portion of the light that does not reach the front object can be reflected by a larger object in the background. If all of the light reflected to the sensor is sufficient, this object is detected. This can lead to a corruption of the measured value.

If the **All echoes** or **Last echo** option is selected, the portion of the light that does not reach the front object, but is reflected from a surface in the background, can produce a second echo [see "Filter", page 39](#).




Figure 12: Object smaller than the laser beam diameter

3.6.5 Distance between the device and the object/surface to be monitored

The laser beam expands with increasing distance from the device. This means that the floor or a wall may be continuously detected as a result of it being hit by the laser beam.




Figure 13: Beam expansion and supplement

- ① Expanded laser beam
- ② Supplement 5 mm/m
- ③ Optical axis
- ④ Continuous detection from 15 m

The optical axis is located around 63 mm above the lower edge of the housing when the device is mounted vertically. This is used as a reference plane for the distance that must be maintained from the ground/wall.

The distance-dependent beam expansion can be calculated using the formula: Beam diameter (mm) = distance (m) × divergence (mrad) + light spot size on the viewing window (mm). For values, see ["Technical data", page 105](#).

The following table shows some example values:

Table 12: Beam diameter on the target object (diagonal) at different distances to the device

Distance	LMS5xx (HR)	LMS5xx (SR)
5 m	37 mm	73 mm
10 m	61 mm	133 mm
15 m	85 mm	192 mm
20 m	108 mm	252 mm
50 m	250 mm	609 mm

When assessing whether the laser beam can hit an object or the wall, the distance from the half beam diameter to the optical axis is used.



NOTE

Take into account the supplement of approx. 5 mm per meter.

3.6.6 Sensing range

The scanning range of the device depends on the remission of the object to be detected. The better a surface reflects the incident beam back to the device, the greater the scanning range of the device.




Figure 14: Scanning range as a function of the target remission
Scanning range of the LMS500-20000 (HR)/LMS511-20100 (HR) and LMS511-10100 (SR) (no filters activated; not affected by fog, rain or dust)

- ① Remission factor of the target [%]
- ② Object distance [m]

Example for [see figure 14, page 26](#): Up to a distance of 15 m, the LMS5xx (HR) can detect objects with a remission factor of 3% or higher. At a distance of 80 m, only objects with a remission factor > 95% are detected reliably.




Figure 15: Scanning range as a function of the remission factor of the target
Scanning range of the LMS511-15100 and LMS531-15100 (SR – Extended Range) (no filters activated; no influence from fog, rain or dust)

- ① Remission factor of the target [%]
- ② Object distance [m]

3.6.7 Beam diameter and measuring point distance

As the distance from the device increases, the laser beam expands. As a result, the diameter of the measuring point increases on the surface of the object.

The range-dependent diameter of the measuring point corresponds to the distance (m) $\times$ 0.0047 rad (HR) or 0.0119 rad (SR) + 13.5 mm.




Figure 16: Beam expansion

- ① Beam diameter at the viewing window = 13.5 mm
- ② Expanded laser beam
- ③ Optical axis

Similarly, as the distance from the device increases, the individual measuring points also grow further apart from one another. The distance between the measuring points also depends on the selected angular resolution. With coarser angular resolution (e.g. 1°), the distance is larger, with finer angular resolution (e.g. 0.1667°), the distance is smaller. The range-dependent distance between the measuring points corresponds to the tangent of the angular resolution $\times$ distance.




Figure 17: Schematic representation of the measuring point distance at different angular resolutions

- ① Scan with coarse angular resolution
- ② Measuring point
- ③ Scan with fine angular resolution

The following diagrams show the beam diameter and measuring point distance as a function of the distance to the device.



NOTE

The correct selection of sensor type (SR or HR) and angular resolution is required for gapless scanning at a certain distance.

Standard Resolution (SR)

Beam diameter / Beam separation mm (in) ①




Figure 18: Beam diameter and measuring point distance at 0 to 80 m (SR)

- ① Beam diameter / beam separation [mm] (in)
- ② Distance of the target [m] (in)
- ③ Resolution 0.042° (interlaced)
- ④ Resolution 0.083° (interlaced)
- ⑤ Resolution 0.1667°
- ⑥ Resolution 0.25°
- ⑦ Resolution 0.3333°
- ⑧ Beam diameter SR
- ⑨ Resolution 0.5°
- ⑩ Resolution 0.6667°
- ⑪ Resolution 1°

Reading example for an angular resolution of 0.1667° (SR) in figure 18

- Distance intersection point 30 m results in a measuring point distance of approx. 87 mm.
- Distance intersection point 30 m with the characteristic curve for beam diameter results in a beam expansion of approx. 370 mm (SR).

Standard Resolution Extended Range




Figure 19: Beam diameter and measuring point distance at 0 to 130 m (SR - Extended Range)

- ① Beam diameter / beam separation [mm] (in)
- ② Distance of the target [m] (in)
- ③ Resolution 0.042° (interlaced)
- ④ Resolution 0.083° (interlaced)
- ⑤ Resolution 0.16667°
- ⑥ Resolution 0.25°
- ⑦ Resolution 0.3333°
- ⑧ Beam diameter SR
- ⑨ Resolution 0.5°
- ⑩ Resolution 0.6667°
- ⑪ Resolution 1°

High Resolution (HR)




Figure 20: Beam diameter and measuring point distance at 0 to 80 m (HR)

- ① Beam diameter / beam separation [mm] (in)
- ② Distance of the target [m] (in)
- ③ Resolution 0.042° (interlaced)
- ④ Resolution 0.083° (interlaced)
- ⑤ Resolution 0.1667°
- ⑥ Resolution 0.25°
- ⑦ Resolution 0.3333°
- ⑧ Beam diameter HR
- ⑨ Resolution 0.5°
- ⑩ Resolution 0.6667°
- ⑪ Resolution 1°

Reading example with angular resolution 0.1667° (HR) in figure 20

- Distance intersection point 30 m results in a measuring point distance of approx. 87 mm.
- Distance intersection point 30 m with the characteristic curve for beam diameter results in a beam expansion of approx. 150 mm (HR).

3.6.8 Minimum object size

For an object to be detected reliably, it must be hit completely by a laser beam once. If the beam only partially hits, less energy may be reflected from the object see "Principle of operation", page 22.

An object is then reliably hit completely at any time if it is at least as large as the measuring point distance plus the beam diameter.




Figure 21: Minimum object size for detection

- ① Beam diameter
- ② Measuring point distance

In the example in [figure 21](#), the object is fully hit at least once during each scan. It is therefore reliably detected if it has the necessary remission.

How to calculate the minimum object size:

Beam diameter + measuring point distance = minimum object size

- Beam diameter and measuring point distance as a function of the distance to the device can be seen in the diagram in [see figure 18, page 28](#) or [see figure 20, page 30](#)



NOTE

For reliable measurement, in particular when using the device to output measured values, the laser needs to hit the object several times. Therefore, the object either needs to be larger than the minimum object size, or both the device and the object must not be moving.

3.6.9 Contamination measurement

The device has a viewing window that protects it. This viewing window can become contaminated. Contamination reduces the energy emitted and received by the laser beam. As a result, scanned objects appear to have a lower remission than they actually have and, with a certain level of contamination, it will no longer be possible to perform measurements. The device has 6 of its own contamination sensors. Depending on the selected contamination strategy, a certain number of these sensors is evaluated. The 6 contamination sensors are divided up into 2 groups (3 + 3).

The contamination is therefore constantly measured by a separate system during operation. A contamination warning is output first for the different degrees of contamination. If the viewing window is not cleaned and contamination increases, then a contamination error is output.

In the case of the outputs, the **Device Not Ready** function responds and switches the outputs in the event of a contamination error. The device continues to output measurement data. The contamination bit in the measurement data telegram should be checked in this case (available in the Telegram Listing, [see "Telegram listing \(EN\)", page 117](#)).

Depending on the application in which the device is used, you can choose from different contamination measurement strategies.

SOPAS ET: **Project tree, LMS..., Parameters, Contamination Measurement.**

- Deactivated: Contamination measurement is not carried out.
- High availability: Contamination warning and contamination errors are only output when the viewing window is uniformly contaminated. This means that all 6 contamination sensors must have reached the limit value for a warning or error.
- Available: Contamination warning and contamination errors are output when the viewing window is partially contaminated.
- Sensitive: Contamination warnings and contamination errors are even output for isolated areas of contamination.
- Semi-sensitive: Contamination warning and contamination errors are output when the viewing window is partially and only slightly contaminated.
- Sensitive: Contamination warning and contamination errors are output even when there is just a little or local contamination.



NOTE

The cleaner the application environment is, the lower you can set the contamination measurement sensitivity. If a high precision of the measured values is required, the contamination measurement must be set to the most sensitive level.

Contamination warnings and contamination errors are displayed on the status indicators of the device [see "LED fault indicators", page 101](#). You can also read these statuses via telegrams (available in the Telegram Listing, [see "Telegram listing \(EN\)", page 117](#)).

A contamination error can also be reported on a digital output if it is configured as an output for the **Device Ready** or **Contamination** status [see "Inputs and outputs", page 51](#).

Table 13: *Contamination (flashing) setting*

Contamination	Digital output
No contamination	Deactivated
Contamination warning flashing	1 Hz 50/50 (on/off)
Contamination error flashing	1 Hz 90/10 (on/off)

To ensure safe operation with deactivated contamination measurement, an external reference contour should be monitored in addition to measurement data recording or the detection field. If the device no longer recognizes this contour, interfering contamination of the viewing window can be assumed.

3.6.10 Calculation of the field size for mobile applications

In order to prevent collisions between vehicles, and between vehicles and fixed objects, the switching field must have sufficient length and width.

To calculate the switching field length, you need to take into consideration the stopping distance of the vehicle. This comprises the following:

- the braking distance, which can be found in the vehicle documentation
- the distance covered during the vehicle control's response time, which can be found in the vehicle documentation
- The distance covered during the response time of the LiDAR sensor, ["Technical data", page 105](#).


NOTE

- We recommend adding a supplement of at least 100 mm to the protective field length in order to stop the vehicle before a possible collision.
- If retro-reflectors are situated in the path of the vehicles, or if you anticipate that the braking force of the vehicle will diminish over time, you may, under certain circumstances, need to increase the recommended supplement.
- The width of the switching field should cover the vehicle width. You should also configure a supplement of at least 100 mm on every side.

Mounting height

The recommended mounting height for mobile applications is at least 150 mm.

3.6.10.1 Switching field length

You must configure the switching field so that a minimum distance to the vehicle is maintained at all times. This ensures that a vehicle monitored by the LiDAR sensor stops before an object is reached. You can define multiple monitoring cases each with different switching fields. These can be switched over dynamically via static control inputs, for example to adjust the protective field size based on the vehicle speed.

In this kind of application, you must calculate the switching field sizes (in particular the switching field lengths) for all speeds.

The switching field length SL can be calculated using the following formula (guideline values based on a pixel calculation):

$$SL = SA + ZG + ZR + ZB$$

SA = Stopping distance


ZG = General supplement of the LiDAR sensor = 100 mm

ZR = Supplement for application-related influences or the selected application parameters

ZB = Supplement for the decreasing braking force of the vehicle. This can be obtained from the relevant vehicle documentation, or alternatively: 10% of the stopping distance.

Stopping distance SA

The stopping distance comprises the vehicle's braking distance and the distance covered during the response time of the LiDAR sensor and the vehicle control's response time.



- ① S_A
- ② S_{AnF}
- ③ S_{AnS}
- ④ S_{Br}



NOTE

Please note that a vehicle's braking distance does not increase linearly with increasing speed, but rather in a squared relationship. This is particularly important if you switch between different-sized switching fields depending on the speed.

How to calculate the stopping distance SA:

$$SA = S_{AnF} + S_{AnS} + S_{Br}$$

S_{AnF} = The distance covered during the vehicle control's response time, which is specified in the vehicle documentation

S_{AnS} = The distance covered during the response time of the LiDAR sensor

S_{Br} = The braking distance, found in the vehicle documentation

The distance S_{AnS} covered during the response time of the LiDAR sensor depends on:

- the response time of the LiDAR sensor
- the maximum speed of the vehicle in your mobile application

For more information on the response time T_S of the LiDAR sensor, see "Technical data", page 105.

How to calculate the distance S_{AnS} covered during the response time of the LiDAR sensor:

$$S_{AnS} = T_S \times V_{max}$$

T_S = Response time of the LiDAR sensor

V_{max} Maximum speed of the vehicle, from the relevant vehicle documentation

The response time T_S of the LiDAR sensor depends on:

- the base response time of the LiDAR sensor
- whether multiple sampling is set
- Filter settings (e.g., particle filter)

ZR supplement

This supplement must be determined on an application-specific basis and taken into account appropriately. The following factors can make it necessary to use a supplement: reflectors or shiny objects on the scan plane, multi-echo analysis, blanking size, device filter (e.g., particle filter).

3.6.10.2 Switching field width

The width of the switching field must cover the width of the vehicle and take into account the supplements for the measurement error.

The switching field width SB can be calculated using the following formula (guideline values based on a pixel calculation):

$$SB = FB + 2 \times (ZG + ZR)$$

FB = Vehicle width

ZG = General supplement of the LiDAR sensor = 100 mm

ZR = Supplement for application-related influences or the selected application parameters

3.7 Fields of application

In general, the device can be used for two purposes:

- Object measurement [see "Object measurement", page 35](#)
- Detection of objects using detection fields [see "Field application", page 46](#)

That is why there is a wide range of possible applications. Some of these applications are listed below:

- Container loading/handling/positioning
- Traffic monitoring/management
- Robots/Pick-and-place applications
- Property/Building protection (low faulty alarm rate)
- Collision protection
- Navigation
- Mapping

It is recommended to continuously check the correct output of the measurement data (measurement of objects) and switching states (field application) via plausibility tests during the application.

This can be done, for example, by analyzing the measurement data or a field evaluation for expected objects in the viewing range of the device (e.g., test target, fixed objects, regularly recurring objects).

To achieve a higher diagnostic coverage, the device can be used as part of an AOS system.

3.7.1 Object measurement

3.7.1.1 Basic parameters

The LMS5xx PRO/Heavy Duty scans at a scanning frequency of 25 to 100 Hz or at an angular resolution of 0.042° to 1°. The LMS5xx Lite offers a reduced number of possible combinations.

At a high scanning frequency or a finer angular resolution, the device delivers more measured values.



NOTE

A scaling factor is used for some scan configurations. The distance values received via data output must be multiplied by this factor.



NOTE

The scan data displayed in the scan data monitor and the field evaluation monitor is already corrected with the scaling factor.

In the case of the **LFEperpdistresult** telegram, the output distance value corresponds to the actual distance and does not need to be corrected [see "Telegram listing \(EN\)", page 117](#).

The following tables provide an overview of the possible configurations.

Table 14: Possible configurations of the LMS5xx Lite

Scanning frequency	Angular resolution			Scaling factor for data output	Max. scanning range	Interlaced
25 Hz	0.25°			x 2	80 m	-
35 Hz		0.5°		x 2	80 m	-
50 Hz		0.5°		x 2	80 m	-
75 Hz		0.5°		x 1	65 m	-
75 Hz			1°	x 2	80 m	-

Table 15: Possible configurations for LMS5xx PRO/Heavy Duty

Scan- ning fre- quency	Angular resolution									Scaling factor for data output	Max. scanning range	Inter- laced
25 Hz	0.042°									x 1	65 m	4-fold 0.1667°
25 Hz		0.083°								x 1	65 m	2-fold 0.1667°
25 Hz				0.1667°						x 1	65 m	-
25 Hz					0.25°					x 2	80 m	-
35 Hz					0.25°					x 1	65 m	-
35 Hz							0.5°			x 2	80 m	-
50 Hz				0.1667°						x 1	65 m	2-fold 0.3333°
50 Hz						0.3333°				x 1	65 m	-
50 Hz							0.5°			x 2	80 m	-
75 Hz					0.25°					x 1	65 m	2-fold 0.5°
75 Hz							0.5°			x 1	65 m	-
75 Hz								1°		x 2	80 m	-
100 Hz				0.1667°						x 1	65 m	4-fold 0.6667°
100 Hz						0.3333°				x 1	65 m	2-fold 0.6667°
100 Hz							0.5°			x 2	80 m	2-fold 1°
100 Hz								0.667°		x 1	65 m	-
100 Hz									1°	x 2	80 m	-

Table 16: Possible configurations for LMS5xx Extended Range

Scan- ning fre- quency	Angular resolution									Scaling factor for data output	Max. scanning range	Inter- laced
25 Hz	0.042°									x 2	80 m	4-fold 0.1667°
25 Hz		0.083°								x 2	80 m	2-fold 0.1667°
25 Hz				0.1667°						x 2	80 m	-
25 Hz					0.25°					x 2	130 m	-
35 Hz					0.25°					x 2	80 m	-
35 Hz							0.5°			x 2	130 m	-
50 Hz				0.1667°						x 2	80 m	2-fold 0.3333°
50 Hz						0.3333°				x 2	80 m	-
50 Hz							0.5°			x 2	130 m	-
75 Hz					0.25°					x 2	80 m	2-fold 0.5°
75 Hz							0.5°			x 2	80 m	-
75 Hz								1°		x 2	130 m	-

Scan- ning fre- quency	Angular resolution								Scaling factor for data output	Max. scanning range	Inter- laced	
100 Hz				0.1667°					x 2	80 m	4-fold 0.6667°	
100 Hz						0.3333°			x 2	80 m	2-fold 0.6667°	
100 Hz							0.5°		x 2	130 m	2-fold 1°	
100 Hz								0.667°	x 2	80 m	-	
100 Hz									1°	x 2	130 m	-

SOPAS ET: Project tree, LMS..., Parameters, Basic settings, Current configuration and New configuration areas.



NOTE

- The device outputs the data after the start of the measurement through the same interface via which the measured values were requested.
- It is only possible to output all measured values of a scan in real time using the Ethernet interface.

3.7.1.2 Interlaced mode

Interlaced mode is available for LMS5xx PRO/Heavy Duty only.

With Interlaced mode, measurement data can be acquired with a fine angular resolution even at high scanning frequencies. Recurring sequences of scans are generated.

The first scan of a sequence is a normal scan. In the following scan, the start angle is offset by a proportional angle increment so that the measuring points are placed in the gaps of the first scan. By combining the individual scans of a sequence, the measurement data is ultimately available with the finer angular resolution.

Table 17: Example of a 2-fold interlaced sequence for 0.3333° at 100 Hz

	Scan num- ber	0°	0.3333°	0.6667°	1°	1.3333°
Sequence	1	x		x		x
	2		x		x	
Sequence	3	x		x		x
	4		x		x	
	5	...				

Table 18: Example of a 4-fold interlaced sequence for angular resolution 0.042° at 25 Hz

	Scan number	0°	0.042°	0.083°	0.125°	0.1667°	0.2087°	0.2507°
Sequence	1	x				x		
	2			x				x
	3		x				x	
	4				x			
Sequence	5	x				x		
	6			x				x
	7	...						

Setting of Interlaced mode

- By telegram: Separate activation of Interlaced mode is not necessary. With the **mLMPsetscancfg** telegram, Interlaced modes can also be selected by using valid values of an Interlaced mode as parameters for scanning frequency and angular resolution. The device will automatically scan in Interlaced mode if necessary. The scans are otherwise output directly without an interlaced sequence.
- SOPAS ET: In the **Defaults** menu, interlaced modes can also be selected as scan configurations.



NOTE

Compared to standard scan configurations, the effectiveness of the particle filter may change with interlaced scan configurations, since measurements at different angular positions are then compared. Confirming the effectiveness in the application is recommended.

Use of the interlaced data

- Measurement data output: Starting with the second scan of a sequence, one data point less per scan is output (example: Data point at 190.000 ° can still be output, but a data point at 190.042 ° is not recorded and can no longer be output). The measurement data are output by telegram (**LMDscandata**) after each scan. The device does not merge the individual scans of a sequence; this can be done by the customer software.
- Field evaluation: Field evaluation is based on the merged scans of a sequence.




NOTE

This reduces the response time of field evaluation. Example: With 4-fold Interlaced mode 100 Hz / 0.1667°, four scans are merged into one sequence: 100 Hz ÷ 4 = data transfer to field evaluation with 25 Hz.

- SOPAS ET: The **Field evaluation monitor** shows the multiply connected scans. **Scan View Pro** shows the individual scans as they are output with the **LMDscandata** telegram.

3.7.1.3 Multi-echo analysis

The distance between the device and an object is calculated via the time-of-flight of the emitted pulse. The device can evaluate up to five echo signals for each measuring beam to deliver reliable measurement results, even under adverse ambient conditions.




- ① Glass
- ② Fog
- ③ Rain
- ④ Dust
- ⑤ Measuring object

3.7.1.4 Filter

By using digital filters to pre-process and optimize the measured distance values, the device can be tailored to the specific requirements of the respective application. This makes it possible to prevent virtually all faults.

If several filters are active, then the filters are applied sequentially to the results of the preceding filter. Processing occurs in the following sequence: Echo filter, particle filter, average filter. It should be noted, however, that the measurement data output may be delayed due to the multiple calculation steps.

The active filter functions affect the outputted measured values. It is not possible to recalculate the original measured values from the filtered output values.



- ① Note: Compared to standard scan configurations, the effectiveness of the particle filter may change with interlaced scan configurations, since measurements at different angular positions are then compared. Confirming the effectiveness in the application is recommended.
- ② When the interlaced mode is activated, the average filter has no function.

3.7.1.4.1 Fog filter

The fog filter enables the device to eliminate unwanted echoes at close range. This considerably lowers the probability of false activations at close range in fog.




Figure 22: Without the fog filter: objects are difficult to detect through the fog due to reflections.




Figure 23: Using the fog filter: objects can be detected reliably because unwanted echoes are screened out.

3.7.1.4.2 Echo filter

The echo filter screens out unwanted measurement data and signals caused by edge hits, rain, dust, snow and other ambient conditions.

You can set whether the first, the last, or all five echoes are output.

The other pulses triggered by undesirable ambient conditions are not taken into account.




Figure 24: **All echoes:** The device receives unwanted echoes from ambient conditions such as rain. The field evaluation only responds to the first echo when the **All echoes** setting is selected




Figure 25: When using the echo filter (setting: **Last echo**): The device screens out unwanted echoes from ambient conditions as per the settings chosen.




Figure 26: When using the echo filter (setting: **First echo**): The device uses the first echo and suppresses all following echoes.

3.7.1.4.3

Particle filter

The particle filter blanks small, irrelevant reflection pulses in dusty environments and in rain or snow which are caused by dust particles, raindrops, snowflakes or the like.

In doing so, successive scans are continuously evaluated in order to detect static objects.

If the distance between a measured value and its temporal spatial neighbors is greater than a defined threshold value, this measured value is discarded as faulty.



NOTE

If the particle filter is activated, measurement data output or reaction of the field evaluation is delayed by one scan.




Figure 27: Without the particle filter: Violation of the contour due to dust particles in the vicinity of the object.




Figure 28: Using the particle filter: The response to dust particles in the detection field is delayed by one scan. Particles can thereby be blanked.

3.7.1.4.4

Average filter

Using the mean filter, a blockwise (not moving) arithmetic average is calculated from the configured number of scans and then outputted. The big advantage when using this filter: Potential noise, i.e. minimal deviation of values, is reduced, which also lowers the quantity of data.




Figure 29: Without the mean filter: The device detects and processes all received signal values.




Figure 30: Using the mean filter: The device calculates an average value from several signal values.

3.7.1.4.5

Glare filter

The glare filter provides the ability to ignore invalid measured values resulting from glare in the field evaluation, provided that glare is only present within a contiguous angular range of less than 5° . If the glare exists for an angular range greater than 5° , these measured values will be included in the field evaluation as invalid measured values. In the event of glare, the measurement data output by telegram are marked by transmitting the distance value `DIST = 1` (LMDscandata, see "Telegram listing (EN)", page 117)



NOTE

Under certain circumstances, glare can falsify surrounding measured values by a few centimeters.

3.7.1.5

Output of measured values

For output of measured values, the device supplies measured values at one of the data interfaces. Prerequisite for data output is that the device is in measurement mode. You have two options for starting the measurement mode:

- Start in SOPAS ET (Project tree, LMS..., Parameters, Basic settings, Measurement area)
- Start via a telegram see "Telegram listing (EN)", page 117.



NOTE

After starting the measurement mode, the device needs some time to reach status 7 ("measurement"). That is why you should request the status of the device with the sRN STlms telegram.

Then request measured data via telegram at the data interface from which you want to receive measured data. This can be achieved in two ways:

- The request of exactly one measured value with the sRN LMDscandata telegram – the last measured scan is transmitted.
- Continuous request of measured data with the sEN LMDscandata telegram – measured data is transmitted until the output of measured values is stopped with the sEN LMDscandata telegram.

Example of one-time output of measured values




Figure 31: Query of measured value telegram

- ① Measured value query
- ② Output of a measured value telegram

1. Log in

Request: <STX>sMN SetAccessMode 03 F4724744<ETX>

Reply: <STX>sAN SetAccessMode <ETX>

2. Start measurement

Request: <STX>sMN LMCstartmeas<ETX>

Reply: <STX>sAN LMCstartmeas 0<ETX>

3. Log out and start device

Request: <STX>sMN Run<ETX>

Reply: <STX>sAN Run 0<ETX>

4. Request measurement status



NOTE

Query the status until status 7 ("measurement") is achieved in the response.

Request: <STX>sRN STlms<ETX>

Reply: <STX>sRA STlms 7 0 8 00:00:00 8 01.0 1.06 0 0 0<ETX>



NOTE

If the status is less than 7, send request again.

5. Starting output of measured values of a single scan

Request: <STX>sRN LMDscandata<ETX>

Reply: <STX>sRA LMDscandata<ETX>

If an error is present and reported in the response telegram: Depending on the type of error, the device will either stop measurement mode or not.

Example of continuous output of measured values




Figure 32: Continuous output of measured values

- ① Measured value query
- ② Output measured-value telegrams
- ③ Command to stop the output



NOTE

If you cannot be sure that the scan data can be processed at the same speed as it is output by the device, you should only query the scan data individually. The scan counter, telegram counter, and time stamp in the output of measured values can serve as an indication that processing is too slow.

1. Log in

Request: <STX>sMN SetAccessMode 03 F4724744<ETX>

Reply: <STX>sAN SetAccessMode <ETX>

2. Start measurement

Request: <STX>sMN LMCstartmeas<ETX>

Reply: <STX>sAN LMCstartmeas 0<ETX>

3. Log out and start device

Request: <STX>sMN Run<ETX>

Reply: <STX>sAN Run 0<ETX>

4. Request measurement status



NOTE

Query the status until status 7 ("measurement") is reached in the response.

Request: <STX>sRN STlms<ETX>

Reply: <STX>sRA STlms 7 0 8 00:00:00 8 01.0 1.06 0 0 0<ETX>



NOTE

If the status is less than 7, send request again.

5. Starting continuous output of measured values

The scan data is output until output of measured values is over.

Request: <STX>sEN LMDscandata 1<ETX>

Confirmation: <STX>sEA LMDscandata 1<ETX>

Continuous response: <STX>sSN LMDscandata<ETX>

6. Stopping continuous output of measured values

Request: <STX>sEN LMDscandata 0<ETX>

Confirmation: <STX>sEA LMDscandata 0<ETX>

3.7.1.6 RSSI values

RSSI (Received Signal Strength Indicator) is the measure of the energy that the sensor receives. This value is determined for each measurement and has a logarithmic, arbitrary unit. The RSSI values have a resolution of 8 bits with whole-number values between 1 and 255, where 1 stands for the weakest signal and 254 for the strongest signal (e.g. with one reflector). A value of 255 means “dazzled”. The value 0 (zero) means that the received energy was too low to produce a valid RSSI value. A valid distance measurement has an RSSI of at least 1.

figure 33 and figure 34 show the different approximation curves for the RSSI ranges of the HR and SR variants depending on the remission of the object, with 10% representing the lowest value (black) and 100% the highest value (white paper). A value of > 80.000% stands for one reflector. For this reason, the curve based on this remains constant at 254.

Table 19: RSSI values

RSSI value	Description
0	No signal
1-254	Valid measurement
254	Reflector
255	Dazzled

If the RSSI value is 0, then no distance measurement is possible. There can be two reasons for this:

- The target object lies outside the scanning range (> 80 m).
- The target object has an extremely low remission.

Please note that white paper (100%) can have very similar values to a reflector at a short distance.




Figure 33: Typical RSSI value HR

- ① RSSI [number]
- ② Distance [m]
- ③ White (approx. 100%)
- ④ Gray (approx. 50%)
- ⑤ Black (approx. 10%)
- ⑥ Reflector (> 80,000%)
- ⑦ Max. signal




Figure 34: Typical RSSI value SR

- ① RSSI [number]
- ② Distance [m]
- ③ White (approx. 100%)
- ④ Gray (approx. 50%)
- ⑤ Black (approx. 10%)
- ⑥ Reflector (> 80,000%)
- ⑦ Max. signal

The RSSI values can vary slightly among different devices and during the service life of the sensor.

SOPAS ET: Project tree, LMS..., Parameters, Data processing, Output format area.

3.7.2 Field application

Using the integrated field application, the LMS5xx PRO/Heavy Duty evaluates up to ten detection fields within its scanning range, the LMS5xx Lite up to four. You can use the field application to implement systems for collision protection, object protection or access monitoring, for example.




Figure 35: Principle of field application

- ① Detection fields
- ② Evaluation cases
- ③ Detection field
- ④ Analysis strategy
- ⑤ Output
- ⑥ Linking of outputs

The LMS5xx PRO/Heavy Duty is adapted to the evaluation situation using up to ten evaluation cases, and the LMS5xx Lite using up to four. In the evaluation case, one of ten (four) configurable detection fields, an evaluation strategy, an output, and possibly a combination of inputs or time periods that activate the evaluation case are selected. For each output, a link is chosen which determines the result of the output if more than one evaluation case affects the output.

In the example in [figure 35](#), detection field 1 is used in evaluation case 1, and detection field 2 is used in evaluation case 2. Both evaluation cases act on output OUT1. If the results of the evaluation cases are AND-linked, the output only switches when both evaluation cases report an event.

3.7.2.1 Detection fields

Using the integrated field application, you can configure up to ten detection fields with the PRO version and up to four fields with the Lite version. The size and shape of these detection fields are (almost) freely configurable.




Figure 36: Examples of 4 different detection field shapes

- ① Measuring range of the device
- ② Outputs
- ③ Rotated detection field
- ④ Detection field for contour monitoring
- ⑤ Square detection field with distance to the device
- ⑥ Polygonal detection field
- ⑦ Dynamic detection field

The detection fields can be drawn using SOPAS ET according to the needs of your application. Detection fields can have the following properties:

- Polygon
- Square
- Beginning on device
- With distance to device ("island field")
- Dynamic, i.e. the length varies according to the speed detected by the encoder, [see "encoder inputs", page 51](#) (LMS500 / LMS511 PRO/Heavy Duty only)

You configure the detection fields in SOPAS ET: **Project tree, LMS..., Parameters, Evaluation fields.**

If the area to be monitored changes, the field can be easily reconfigured using the SOPAS ET configuration software.

3.7.2.2 Evaluation cases

An evaluation case determines which detection field is evaluated in which way and on which output it acts.

With the LMS5xx PRO/Heavy Duty, you can configure up to ten evaluation cases, while the LMS5xx Lite enables up to four evaluation cases.

For each evaluation case, configure in SOPAS ET:

- Inputs or time periods that activate an evaluation case, if applicable. If nothing is specified, the evaluation case is always active.
- The evaluation strategy
- The detection field

- The output affected by the analysis case
- The response time **Project tree**, **LMS...**, **Parameters**, **Evaluation cases**.

Inputs

If the evaluation case is not permanently active, you can configure an input combination that activates the evaluation case.

Table 20: Examples of input combinations for the LMS5xx PRO ¹⁾

Input 1	Input 2	Input 3	Input 4	Evaluation case
Low	Low	Low	Low	1
Low	Low	Low	High	2
Low	Low	High	Low	3
Low	Low	High	High	4
Low	High	Low	Low	5
Low	High	Low	High	6
Low	High	High	Low	7
Low	High	High	High	8
High	Low	Low	Low	9
High	Low	Low	High	10

¹⁾ The initial HIGH state is called "Active HIGH" in SOPAS ET. Accordingly, the initial LOW state is called "Active LOW".



NOTE

An input combination can also be defined for several evaluation cases, then e.g. two evaluation cases become active simultaneously.

Although the LMS5xx Lite has two inputs, only IN1 can be used for field evaluation.

Analysis strategy

In SOPAS ET, you choose from the following possible detection strategies:

- **Pixel analysis:** The device evaluates the entire area of the field. Each individual beam is taken into account in evaluation. If an object enters the field, this result is forwarded to the corresponding output.
- **Blanking:** The device evaluates the entire area of the field. However, objects that are smaller than the specified size are ignored. An object is only detected if it is larger than the configured blanking size. However, this only applies to objects that are at the maximum distance at which they still meet the criteria for the minimum object size. At greater distances, the set blanking size can no longer be achieved by the optical resolution of the device. The device behaves exactly as with pixel evaluation.
- **Contour:** The device also evaluates the existence of a contour, which has to be fully situated within the detection field at all times. This allows the device to detect, for example, that a door opens outwards or that the position of the device has changed. It is also possible to detect someone crawling beneath a vertical detection field or a laser beam deflected in a mirror. Blanking can be used to hide the missing part of the contour up to a certain size.
- **I/O linking:** The I/O linking evaluation strategy allows you to link the inputs of the device to its outputs [see "Inputs and outputs", page 51](#).
- **Perpendicular distance to the reference line:** The device outputs the perpendicular distance to an object located within the detection field. The perpendicular distance d is output in the **LFEperpdresult** telegram, see Telegram Listing. The response time, blanking size, and alignment of the reference line can be configured in SOPAS ET.

Response time

For the **Pixel analysis**, **Blanking**, **Contour** and **Perpendicular distance to the reference line** evaluation strategies, you define a response time. For the device to detect an object using the **Pixel analysis**, **Blanking** and **Perpendicular distance to the reference line** evaluation strategies, the object must be detected at the same location for at least the duration of the response time. For the **Contour** evaluation strategy, the contour breach must be detected at the same location for at least the duration of the response time.

Manipulation prevention

When **Pixel analysis** is configured, dazzling can cause the device to stop monitoring a field. When **Blanking** is configured, small objects in the vicinity of the device can cause large shadows.

If you use detection fields at a distance to the device, the object or the object erroneously measured due to dazzle lies outside the detection field and is not detected.

To prevent this, you can configure the **Manipulation protection** option.




Figure 37: Tamper-proofing against shadowing and dazzle

- ① Shading
- ② Detection field with distance to the device
- ③ Object smaller than blanking
- ④ Light source
- ⑤ Blanked area

The **Manipulation protection** option switches the detection field:

- If an object less than or equal to the blanked object size is in front of the laser output aperture of the device for the response time configured for manipulation protection.
- If the device is blanked for longer than the response time configured for manipulation protection.

Detection field

For the evaluation case, select a field from the already configured detection fields. Its shape must fit the evaluation strategy [see "Detection fields", page 47](#).

Output

Select one of the outputs for the evaluation case. If several evaluation cases act on one output, you must determine how the results of the evaluation cases are linked [see "Linking of evaluation cases at the output", page 51](#).

**NOTE**

The respective output must be configured for "Application".

Negating the result

Negating the result reverses the field evaluation output. The output used is thus switched, for example, if the detection field is free or if the contour is not interrupted.

**NOTE**

Do not confuse negation of the result with the Active HIGH/Active LOW setting of the outputs [see "Linking of evaluation cases at the output", page 51](#).

3.7.2.3 Linking of evaluation cases at the output

If several evaluation cases act on one output, you must determine how the results of the evaluation cases are linked. The respective results can be linked with AND or OR.

SOPAS ET: **Project tree, LMS..., Parameters, Network/Interfaces/IOs, Digital outputs.**

The outputs are configured as **Active Low** by default. You can also configure them as **Active High**.

Resetting an output

In the default setting, the outputs are immediately reset to the deactivated state. You can configure a delay of up to 10 s (e.g. to activate a horn or to transmit the output signal to a PLC).

Alternatively, you can also reset the output via an input. The output is only reset when the assigned input assumes the configured status.

3.8 Inputs and outputs**Digital inputs**

The LMS5xx Lite has two digital inputs, the LMS531 Lite has three, and the LMS5xx PRO/Heavy Duty has four. These inputs could activate different evaluation cases [see "Evaluation cases", page 48](#).

The inputs can also be used to reset the outputs of the LMS5xx [see "Resetting an output", page 51](#).

encoder inputs

The LMS500/511 PRO/Heavy Duty has two encoder inputs (IN3 and IN4) that can be selected via software.

The encoder pulses can be used to influence the size of so-called dynamic fields, for example for speed-dependent vehicle monitoring. A dynamic field changes its length with the speed measured e.g. by encoders.

SOPAS ET: **Project tree, LMS..., Parameters, Network/Interfaces/IOs, Digital inputs 3+4/Encoder (HTL)/Sync.**

When stationary ($V = 0$ m/s), the detection field has the size of the configured basic field. The size increases continuously with increasing speed until the largest field extension is reached at maximum speed.

Digital outputs

The LMS531 Lite has one digital output. The LMS500 / LMS511 Lite has three digital outputs, the LMS500 / LMS511 PRO/Heavy Duty has six.

The outputs can be used as digital outputs to ground or as volt-free outputs [see "Wiring the inputs and outputs", page 77](#).

For the ... / **Device Not Ready** setting, the sensor always signals **Device Not Ready** regardless of whether the outputs are switched by the field evaluation application or by SOPAS ET telegrams.

SOPAS ET: **Project tree, LMS..., Parameters, Network/Interfaces/IOs, Digital outputs**.

If the field evaluation application is being used to switch an output, the LMS5xx may signal object detections or contour interruptions. In SOPAS ET, you can configure which evaluation case affects which output.

External digital outputs

Up to 8 additional digital outputs can be controlled via a CAN extension module (part no. 6038825 or 6041328). To use the additional outputs, the extension module must be activated.

SOPAS ET: **Project tree, LMS..., Parameters, Network/Interfaces/IOs, External digital outputs**



NOTE

For monitoring the extension module (heartbeat), module ID < 63 must be set.

Relay outputs

The LMS531 Lite has two relay inputs, the LMS531 PRO four. These can optionally be configured to switch to HIGH or LOW when an object or person is detected in the detection field.

SOPAS ET: **Project tree, LMS531, Parameters, Network/Interfaces/IOs, Relay outputs**.

There are the following options for configuration:

Table 21: LMS531 Lite/PRO: Status of the outputs in case of object detection

Output	Configured HIGH logic	Configured LOW logic
Relay output	Relay closed	Relay open

Details of the relay outputs [see "Parameterizing the LMS531 variants for security applications", page 85](#).

Synchronization of several LMS5xx units

There may be mutual optical interference between two or more LMS5xx units if they must be mounted on the same scan plane [see "Mounting multiple devices", page 58](#).

Several LMS5xx units arranged in this way can be synchronized to prevent this type of interference. With the help of SOPAS ET, an LMS5xx can be configured according to type and synchronized with other LMS5xx units via assigned outputs and inputs:

Table 22: Overview: Assigned inputs and outputs for synchronization

Variant	Output (as Sync Main)	Input (as Sync Sub)
LMS500 Lite Indoor	Terminal 5: OUT Sync (OUT3)	Terminal 7: OUT IN Sync
LMS500 PRO Indoor	Terminal 26: OUT Sync (OUT6)	Terminal 11: IN Sync (IN4)
LMS511 Lite Outdoor	"I/O" connection Pin 6: OUT Sync (OUT3)	"Data" connection Pin 7: IN Sync
LMS511 PRO Outdoor	"I/O" connection Pin 12: OUT Sync (OUT6)	"I/O" connection Pin 8: IN Sync (IN4)

Variant	Output (as Sync Main)	Input (as Sync Sub)
LMS511 Heavy Duty	"I/O" connection Pin 12: OUT Sync (OUT6)	"I/O" connection Pin 8: IN Sync (IN4)
LMS581 PRO Outdoor	"I/O" connection Pin 12: OUT Sync (OUT6)	"I/O" connection Pin 8: IN Sync (IN4)

LMS500/511 PRO and Heavy Duty: When using synchronization via input 4, input 3 is deactivated.

The synchronization phase value (range: $-180 \dots +180^\circ$) in SOPAS ET can be used to distinguish between the individual main-sub connections.

Synchronization can also be used to increase the scanning frequency of an area by using several units to monitor the same area and setting their phases to alternate scanning.

Linking of inputs and outputs

With the aid of an evaluation case, the inputs and outputs of several LMS5xx units can be linked together [see "Evaluation cases", page 48](#).




Figure 38: Linking of inputs and outputs

- ① Evaluation case 1: Pixel evaluation acts on output 1
- ② Output 1: Active low
- ③ Protective fields of two devices linked by I/O link
- ④ Evaluation case 2: I/O link acts on output 1
- ⑤ Input 1: Active low
- ⑥ Output 1: OR-link of evaluation cases 1 and 2

In the example above, output 1 of the lower LMS5xx is connected to input 1 of the upper LMS5xx. An interruption of the detection field is thereby reported to the input of the upper LMS5xx. In its evaluation case 2, this LMS5xx links the input to output 1. At

the same time, evaluation case 1 affects the upper LMS5xx and its output 1. By linking the two results with the OR logical operator, object detections in the detection field are reported on both LMS5xx units at output 1 of the upper LMS5xx.

3.9 Data interfaces

The device has different data interfaces for configuration and the transmission of measured values.



NOTE

- It is only possible to output all measured values of a scan in real time using the Ethernet interface.
- The data transmission rate of the RS-232 / RS-422 interfaces is limited to 500 kBd. Therefore these interfaces are not suitable for transmitting scan data in real time.

For a description of the electrical interfaces see ["Connections"](#), page 64.

Ethernet interface

The Ethernet interface has a data transmission rate of 10/100 Mbit/s. The interface is a TCP/IP, UDP/IP interface supporting full duplex and half duplex.

- TCP/IP: The device can be used as a server or client in the network to output its data. TCP port 2111 is intended to be used as a configuration interface. TCP port 2112 can be used for the process data. Both ports are equivalent. The device can also send the measurement data via UDP using port 2213.
- Heartbeat: The heartbeat function can be used to cyclically check the communication interface. The device sends a custom text message at regular intervals. This functionality offers the advantage that it closes sockets that have not been closed correctly (e.g., due to connection failures). The device can open up to 10 sockets in parallel per TCP port.
- UDP: The device can output measurement data via UDP using port 2213.

The Ethernet interface allows the configuration of the device as well as the output of measured values.

The factory setting for the Ethernet interface is as follows:

- IP address: 192.168.0.1
- Subnet mask: 255.255.255.0
- TCP port: 2111

You might need to adjust the configuration of the Ethernet interface so that a connected computer (client) can communicate with the device via Ethernet: **Project tree**, **LMS...**, **Parameters**, **Network/Interfaces/IOs**, **Ethernet**.



NOTE

If you change the parameters of the Ethernet interface via the Ethernet interface, you must first save the data permanently to non-volatile memory in the device and then restart the device. A **Restart** button is provided in SOPAS ET for this purpose.

Serial host interface

The serial host interface is an RS-232 / RS-422 interface. The host interface permits the configuration of the device and limited output of measured values.

The interface parameters are freely configurable: SOPAS ET **Project tree**, **LMS...**, **Parameters**, **Network/Interfaces/IOs**, **Serial**, **Serial host interface** area.

The factory setting for the host interface is as follows:

- 57.6 kBd
- 8 data bits
- 1 stop bit
- No parity



NOTE

If you change the parameters for the host interface via the host interface, the connection to the device will be lost. You must then scan for the device again in SOPAS ET (see "Performing a scan", page 83).

USB auxiliary interface

The Mini-USB auxiliary interface permits direct configuration of the device.



NOTE

To access the device via the USB auxiliary interface, the required USB driver must first be installed on the computer. Available for downloading on the online product page.

The product page can be accessed via the **SICK Product ID: `pid.sick.com/{P/N}/{S/N}`**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

Parameters can be changed via USB while the device is connected to a host via another interface such as RS or Ethernet. Only the last changes saved in the configuration, both via USB and via RS or Ethernet, are retained.

3.10 Communicating data via telegrams

The device sends telegrams over the interfaces described above to communicate with a connected host. The following functions can be run using telegrams:

- Request measured values via the host and then output them once via the device
- Parameter setting by the host for the configuration of the device
- Parameters and status log querying by the host.

Each telegram comprises a frame and the application data.

A detailed description of the different telegrams can be found in the Telegram Listing, see "Telegram listing (EN)", page 117.

Frame and coding of the telegrams

The payload varies depending on the coding.

Table 23: Frame of the telegrams when using ASCII coding (CoLa-A)

	Frame	Telegram	Frame
Designation	STX	Application data	ETX
Length (Byte)	1	≤ 60 kB	1
Description	Start of text character	ASCII coded	End of text character

You can configure the frame of the serial host interface in SOPAS ET: **Project tree, LMS..., Parameters, Network/Interfaces/IOs, Serial, Serial host interface area.**

4 Transport and storage

4.1 Transport



NOTICE

Damage due to improper transport!

- The product must be packaged with protection against shock and damp.
- Recommendation: Use the original packaging.
- Note the symbols on the packaging.
- Do not remove packaging until immediately before you start mounting.

4.2 Unpacking

- To protect the device against condensation, allow it to equilibrate with the ambient temperature before unpacking if necessary.
- Handle the device with care and protect it from mechanical damage.
- To avoid ingress of dust and water, only remove the protective elements, e.g. protective caps of the electrical connections just before attaching the connecting cable.

4.3 Transport inspection

Immediately upon receipt in Goods-in, check the delivery for completeness and for any damage that may have occurred in transit. In the case of transit damage that is visible externally, proceed as follows:

- Do not accept the delivery or only do so conditionally.
- Note the scope of damage on the transport documents or on the transport company's delivery note.
- File a complaint.



NOTE

Complaints regarding defects should be filed as soon as these are detected. Damage claims are only valid before the applicable complaint deadlines.

4.4 Storage

- Electrical connections are provided with a protective cap.
- Do not store outdoors.
- Store in a place protected from moisture and dust.
- Recommendation: Use the original packaging.
- To allow any residual dampness to evaporate, do not package in airtight containers.
- Do not expose to any aggressive substances.
- Protect from sunlight.
- Avoid mechanical shocks.
- Storage temperature: [see "Technical data", page 105](#).
- Relative humidity: [see "Technical data", page 105](#).
- For storage periods of longer than 3 months, check the general condition of all components and packaging on a regular basis.

5 Mounting

5.1 Mounting instructions

- Observe the technical data.
- Protect the sensor from direct sunlight.
- To prevent condensation, avoid exposing the device to rapid changes in temperature.
- The mounting site has to be designed for the weight of the device.
- The device should be mounted so that the connectors point downwards. This makes it easier for moisture to run off the male connectors. Furthermore, in this orientation the contamination measurement will better reflect the actual contamination of the front screen.
- The connecting cables should be laid with some cable in reserve to act as a drip loop so no moisture (e.g., condensation) is directed towards the device but instead drips off the cable beforehand.
- It should be mounted so that it is exposed to as little shock and vibration as possible. Optional mounting accessories are available, [see "Accessories", page 116](#).
- Make sure the entire field of view of the device is not restricted, [see "Dimensional drawings", page 114](#).
- Observe maximum torque of the fixing screws: M8 lateral = max. 16 Nm / M6 rear = max. 12 Nm
- Regularly check the tightness of the fixing screws.
- For indoor mounting, use a protection hood if necessary, for outdoor installation use a weather protection hood if necessary (both optional accessories), [see "Accessories", page 116](#).
- Do not mount the device on or directly in front of a bright metallic surface or other reflective surface, since reflections can falsify the measurements.
- Avoid having shiny or reflective surfaces in the scanning range, e.g., stainless steel, aluminum, glass, reflectors, or surfaces with these types of coatings.
- Protect the device from moisture, contamination, and damage.
- Make sure that the status indicator is clearly visible.
- Do not subject the device to excessive shock or vibrations. In systems subjected to heavy vibrations, secure the fixing screws with screw-locking devices.
- When mounting the device up high, and in particular to secure the device during mounting, a retaining cable for fastening is available as an accessory.

5.2 Mounting the device



NOTE

For direct mounting without the SICK mounting bracket:

- There must be a sufficient distance between the housing and the support structure to prevent heat accumulation.
- It must be ensured that no moisture is permanently present on the sealing surfaces and that the housing can dry in a short time.
- In order to prevent bimetallic corrosion, appropriate mounting materials must be used or there must be sufficient distance between the housing (die cast aluminum) and the support structure.

1. Mount the device directly or in a suitably prepared bracket using the fixing holes provided ([see "Dimensional drawings", page 114](#)). Mounting brackets are available as optional accessories, [see "Accessories", page 116](#).
2. Make the electrical connection, [see "Electrical installation", page 59](#).
3. Align the vertical center line of the field of view of the device with the center of the area to be monitored.

4. Switch on the supply voltage.
- ✓ The green **OK** LED lights up after initialization.
5. The device is ready for use. Perform a fine adjustment using a test target and, if necessary, use the alignment aid, [see "Accessories", page 116](#).

5.3 Mounting multiple devices



NOTICE RISK OF INTERFERENCE FROM OTHER DEVICES!

Radiation sources with a wavelength of 905 nm can cause interference if they affect the device directly.

The device has been designed to minimize the probability of mutual interference, including between different LiDAR sensors. To rule out any negative impacts on the measurement accuracy, the devices should be arranged in such a way that the laser beams are not received by another device.




Figure 39: Arrangement for 2 devices

6 Electrical installation

6.1 Wiring instructions



NOTE

Pre-assembled cables can be found on the product page.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).



NOTICE

Faults during operation and defects in the device or the system

Incorrect wiring may result in operational faults and defects.

- Follow the wiring notes precisely.

The enclosure rating stated in the technical data is achieved only with screwed plug connectors or protective caps.

All circuits connected to the device must be configured as SELV or PELV circuits. SELV = safety extra-low voltage, PELV = protective extra-low voltage.

Connect the connecting cables in a de-energized state. Do not switch on the supply voltage until installation is complete and all connecting cables are connected to the device and control.

Wire cross-sections in the supply cable from the customer's power system must be implemented in accordance with the applicable standards.

Take suitable external safety measures to protect the digital inputs, digital outputs and their supply voltage against transient overvoltage.

Only use cables with shielding on both sides for wiring.

6.2 Overview of the installation steps

1. Wire the digital inputs and digital outputs (application-dependent).
2. Connect the computer temporarily (configuration).
3. Wire the data interface for operation.
4. Set up the voltage supply for the device.

6.3 Prerequisites for safe operation of the device

**WARNING****Risk of injury and damage caused by electrical current!**

As a result of equipotential bonding currents between the device and other grounded devices in the system, faulty grounding of the device can give rise to the following dangers and faults:

- Dangerous voltages are applied to the metal housings.
- Devices will behave incorrectly or be destroyed.
- Cable shielding will be damaged by overheating and cause cable fires.

Remedial measures

- Only skilled electricians should be permitted to carry out work on the electrical system.
- If the cable insulation is damaged, disconnect the voltage supply immediately and have the damage repaired.
- Ensure that the ground potential is the same at all grounding points.
- Where local conditions do not meet the requirements for a safe earthing method, take appropriate measures. For example, ensure low-impedance and current-carrying equipotential bonding.

The device is connected to the peripheral devices (any local trigger sensor(s), system controller) via shielded cables. The cable shield – for the data cable, for example – rests against the metal housing of the device.

The device can be grounded through the cable shield or through a blind tapped hole in the housing, for example.

If the peripheral devices have metal housings and the cable shields are also in contact with their housings, it is assumed that all devices involved in the installation have the **same ground potential**.

This is achieved by complying with the following conditions:

- Mounting the devices on conductive metal surfaces
- Correctly grounding the devices and metal surfaces in the system
- If necessary: low-impedance and current-carrying equipotential bonding between areas with different ground potentials




Figure 40: Example: Occurrence of equipotential bonding currents in the system configuration

- ① System controller
- ② Device
- ③ Voltage supply
- ④ Grounding point 2
- ⑤ Closed current loop with equalizing currents via cable shield
- ⑥ Ground potential difference
- ⑦ Grounding point 1
- ⑧ Metal housing
- ⑨ Shielded electrical cable

If these conditions are not fulfilled, equipotential bonding currents can flow along the cable shielding between the devices due to differing ground potentials and cause the hazards specified. This is, for example, possible in cases where there are devices within a widely distributed system covering several buildings.

Remedial measures

The most common solution to prevent equipotential bonding currents on cable shields is to ensure low-impedance and current-carrying equipotential bonding. If this equipotential bonding is not possible, the following solution approaches serve as a suggestion.



NOTICE

We expressly advise against opening up the cable shields. This would mean that the EMC limit values can no longer be complied with and that the safe operation of the device data interfaces can no longer be guaranteed.

Measures for widely distributed system installations

On widely distributed system installations with correspondingly large potential differences, the setting up of local islands and connecting them using commercially available **electro-optical signal isolators** is recommended. This measure achieves a high degree of resistance to electromagnetic interference.




Figure 41: Example: Prevention of equipotential bonding currents in the system configuration by the use of electro-optical signal isolators

- ① System controller
- ② Electro-optical signal isolator
- ③ Device
- ④ Voltage supply
- ⑤ Grounding point 2
- ⑥ Grounding point 1
- ⑦ Metal housing
- ⑧ Shielded electrical cable
- ⑨ Optical fiber

The use of electro-optical signal isolators between the islands isolates the ground loop. Within the islands, a stable equipotential bonding prevents equalizing currents on the cable shields.

Measures for small system installations

For smaller installations with only slight potential differences, insulated mounting of the device and peripheral devices may be an adequate solution.




Figure 42: Example: Prevention of equipotential bonding currents in the system configuration by the insulated mounting of the device

- ① System controller
- ② Device
- ③ Voltage supply
- ④ Grounding point 3
- ⑤ Insulated mounting
- ⑥ Grounding point 2
- ⑦ Ground potential difference
- ⑧ Grounding point 1
- ⑨ Metal housing
- ⑩ Shielded electrical cable

Even in the event of large differences in the ground potential, ground loops are effectively prevented. As a result, equalizing currents can no longer flow via the cable shields and metal housing.



NOTICE

The voltage supply for the device and the connected peripheral devices must also guarantee the required level of insulation.

Under certain circumstances, a tangible potential can develop between the insulated metal housings and the local ground potential.


Suitable external safety measures should be taken by the customer to protect the IOs and their supply voltage against transient overvoltage.

6.4 Connections

6.4.1 Connections of the LMS500


LMS500 Lite and PRO Indoor: “Ethernet” connection on system plug

Table 24: LMS500 Lite and PRO Indoor: Pin assignment of the “Ethernet” connection

Male/female connector	Contact	Short form	Signal description
 Figure 43: M12 female connector, 4-pin, D-coded	1	TX+	Sender+
	2	Rx+	Receiver+
	3	TX-	Sender-
	4	Rx-	Receiver-


LMS500 Lite Indoor: “Power/Data/I/O” connection in system plug

Table 25: LMS500 Lite Indoor: Terminal assignment of the “Power/Data/I/O” connection

Male/female connector	Contact	Short form	Signal description
 Figure 44: 2 x terminal strip, 8-pin	01	V _S	Sensor supply voltage
	02	GND	Ground sensor
	03	OUT1	Digital output 1
	04	OUT2	Digital output 2
	05	OUT3 / OUT Sync	Digital output 3 / Synchronization output
	06	IN1	Digital input 1
	07	IN Sync	Synchronization input
	08	GND IN /IN Sync	Ground of digital input 1 / synchronization input
	09	V _S OUT	Digital output supply voltage
	10	GND V _S OUT	Supply voltage ground of digital outputs
	11	TD+	RS-422 sender
	12	TD-/TxD	RS-422 / RS-232 sender
	13	GND RS	RS-422/RS-232 ground
	14	RD-/RxD	RS-422/RS-232 receiver
	15	RD+	RS-422 receiver
	16	RS shield	RS-422/RS-232 screen

LMS500 PRO Indoor: "Power/Data/I/O" connection in the system plug

Table 26: LMS500 Pro Indoor: Terminal assignment of the "Power/Data/I/O" connection

Male/female connector	Contact	Short form	Signal description
 Figure 45: 2 x terminal strip, 13-pin	01	V _S	Sensor supply voltage
	02	GND	Ground sensor
	03	OUT1	Digital output 1
	04	OUT2	Digital output 2
	05	OUT3	Digital output 3
	06	IN1	Digital input 1
	07	IN2	Digital input 2
	08	GND IN1/2	Ground for digital inputs 1 and 2
	09	GND IN3/4/IN Sync	Ground for digital inputs 3 and 4 / Input Synchronization
	10	IN3	Digital input 3
	11	IN4/IN Sync	Digital input 4 / Synchronization input
	12	OUT4	Digital output 4
	13	OUT5	Digital output 5
	14	V _S OUT	Digital output supply voltage
	15	GND V _S OUT	Supply voltage ground of digital outputs
	16	TD+	RS-422 sender
	17	TD-/TxD	RS-422 / RS-232 sender
	18	GND RS	RS-422/RS-232 ground
	19	RD-/RxD	RS-422/RS-232 receiver
	20	RD+	RS-422 receiver
	21	RS shield	RS-422/RS-232 shielding
	22	CAN shield	CAN bus shielding
	23	CAN H	CAN bus HIGH
	24	GND CAN	Ground CAN-BUS
	25	CAN L	CAN bus LOW
	26	OUT6/OUT Sync	Digital output 6 / Synchronization output

Yellow bypass switch at the system connection

By moving the bypass switch, you can select which pins provide the supply voltage for the outputs or which pin provides the ground potential of the inputs.


**NOTE**

If the bypass switch is set as "bridge", a higher power is consumed via the supply cable of the sensor (supply power for sensor and outputs).

Table 27: Supply voltage outputs

	S1 position SYS(default)	S1 position EXT
		
V _s OUT	Via Vs from Pin1	Via external from Pin14
GND OUT	Via GND from Pin2	Via external from Pin15


Table 28: Ground inputs

	S2 position V_OUT(S1) (default)	S2 position PIN 8/9
		
GND IN1/2 (PRO, Heavy Duty)	Set via GND supply voltage as with S1	Via Pin8
GND IN3/4/IN Sync (PRO, Heavy Duty)		Via Pin9
GND IN (Lite)		Via Pin8

6.4.2 Connections of LMS511, LMS581 and LMS511 Heavy Duty

LMS511 Lite/PRO/Heavy Duty Outdoor, LMS581 PRO, LMS531 Lite/PRO: "Power" connector

Table 29: LMS511 Lite/PRO/Heavy Duty Outdoor, LMS581 PRO, LMS531 Lite/PRO: "Power" connector


Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6036159 ¹⁾
 Figure 46: M12 male connector, 5-pin, A-coded	1	V _S	Sensor supply voltage	Brown
	2	V _S heat.	Heating supply voltage	White
	3	GND	Ground sensor	Blue
	4	Reserved	Do not use!	–
	5	GND heat.	Ground heating	Black

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

Required minimum voltage at flying leads for part no. 6036159: 20.3 V


LMS511 Lite/PRO/Heavy Duty Outdoor, LMS581 PRO and LMS531 Lite/PRO: "Ethernet" connection

Table 30: LMS511 Lite/PRO/Heavy Duty Outdoor, LMS581 PRO and LMS531 Lite/PRO: "Ethernet" connection

Male/female connector	Contact	Short form	Signal description
 Figure 47: M12 female connector, 4-pin, D-coded	1	TX+	Sender+
	2	Rx+	Receiver+
	3	TX–	Sender–
	4	Rx–	Receiver–

LMS511 Lite Outdoor: "Data" connection


Table 31: LMS511 Lite Outdoor: Pin assignment of the "Data" connection

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6036153 ¹⁾
 Figure 48: M12 male connector, 8-pin, A-coded	1	RD–/RxD	RS-422/RS-232 receiver	White
	2	TD–/TxD	RS-422 / RS-232 sender	Brown
	3	RD+	RS-422 receiver	Green
	4	TD+	RS-422 sender	Yellow
	5	GND RS	RS-422/RS-232 ground	Gray
	6	Reserved	Do not use!	Pink
	7	IN Sync	Synchronization input	Blue
	8	GND IN Sync	Synchronization ground	Red

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

LMS511 Lite Outdoor: “I/O” connection


Table 32: LMS511 Lite Outdoor: Pin assignment of the “I/O” connection

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 2134055 ¹⁾
 Figure 49: M12 female connector, 8-pin, A-coded	1	IN1	Digital input 1	White
	2	Reserved	Do not use!	Brown
	3	GND IN1	Ground of digital input 1	Green
	4	OUT1	Digital output 1	Yellow
	5	OUT2	Digital output 2	Gray
	6	OUT3 /OUT Sync	Digital output 3 / Synchronization output	Pink
	7	GND OUT 1 ...3	Ground of digital outputs 1 ... 3 / Synchronization	Blue
	8	V _S OUT	Digital output supply voltage	Red

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

LMS511 PRO, LMS581 PRO and LMS511 Heavy Duty Outdoor: “Data” connection


Table 33: LMS511 PRO, LMS581 PRO and LMS511 Heavy Duty Outdoor: Pin assignment of “Data” connection

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6042735 ¹⁾
 Figure 50: M12 male connector, 12-pin, A-coded	1	V _S OUT	Supply voltage of digital outputs 1 and 2	Brown
	2	RD-/RxD	RS-422/RS-232 receiver	Blue
	3	OUT1	Digital output 1	White
	4	GND RS, CAN	RS-422/RS-232/CAN ground	Green
	5	OUT2	Digital output 2	Pink
	6	Reserved	Do not use!	Yellow
	7	TD-/TxD	RS-422 / RS-232 sender	Black
	8	Reserved	Do not use!	Gray
	9	RD+	RS-422 receiver	Red
	10	TD+	RS-422 sender	Violet
	11	CAN L	CAN bus LOW	Gray+pink
	12	CAN H	CAN bus HIGH	Red+blue

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

LMS511 PRO, LMS581 PRO and LMS511 Heavy Duty Outdoor: "I/O" connection

Table 34: LMS511 PRO, LMS581 PRO and LMS511 Heavy Duty Outdoor: Pin assignment of "I/O" connection


Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6042732 ¹⁾
 Figure 51: M12 female connector, 12-pin, A-coded	1	V _S OUT	Supply voltage of digital outputs 3 ... 6	Brown
	2	GND IN1/2	Ground for digital inputs 1 and 2	Blue
	3	IN1	Digital input 1	White
	4	GND IN3/4/IN Sync	Ground for digital inputs 3 and 4 / Synchronization input	Green
	5	IN2	Digital input 2	Pink
	6	IN3	Digital input 3	Yellow
	7	GND OUT 3 ... 6	Supply voltage ground of digital outputs 3... 6	Black
	8	IN4/IN Sync	Digital input 4 / Synchronization input	Gray
	9	OUT3	Digital output 3	Red
	10	OUT4	Digital output 4	Violet
	11	OUT5	Digital output 5	Gray+pink
	12	OUT6/OUT Sync	Digital output 6 / Synchronization output	Red+blue

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

6.4.3 Connections of the LMS531 Security Outdoor

Connections of the LMS531 Security Outdoor LMS531 Lite and PRO Security Outdoor: "Power" connection

Table 35: LMS531 Lite Security Outdoor: Pin assignment of the "Power" connection


Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6036159 ¹⁾
 Figure 52: M12 male connector, 5-pin, A-coded	1	V _S	Sensor supply voltage	Brown
	2	V _S heat.	Heating supply voltage	White
	3	GND	Ground sensor	Blue
	4	Reserved	Do not use!	–
	5	GND heat.	Ground heating	Black

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

Required minimum voltage at flying leads for part no. 6036159: 20.3 V


LMS531 Lite and PRO Security Outdoor: “Ethernet” connection

Table 36: LMS531 Lite Security Outdoor: Pin assignment of the “Ethernet” connection

Male/female connector	Contact	Short form	Signal description
 Figure 53: M12 female connector, 4-pin, D-coded	1	TX+	Sender+
	2	RX+	Receiver+
	3	TX-	Sender-
	4	RX-	Receiver-

LMS531 Lite Security Outdoor: “Inputs” connection


Table 37: LMS531 Lite Security Outdoor: Pin assignment of the “Inputs” connection

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6036153 ¹⁾
 Figure 54: M12 male connector, 8-pin, A-coded	1	A/DA (IN1)	In focus/Blurry (digital input 1)	White
	2	WT (IN2)	Walk test (digital input 2)	Brown
	3	Reserved	Do not use!	Green
	4	Reserved	Do not use!	Gray
	5	Reserved	Do not use!	Pink
	6	Reserved	Do not use!	Yellow
	7	TEACH (IN3)	EasyTeach (digital input 3)	Blue
	8	GND IN	Ground of all digital inputs	Red

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.


LMS531 Lite Security Outdoor: “Alarm” connection

Table 38: LMS531 Lite Security Outdoor: Pin assignment of the “Alarm” connection

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 2134055 ¹⁾
 Figure 55: M12 female connector, 8-pin, A-coded	1	Alarm A (OUT1)	Alarm output (relay), contact A	White
	2	Alarm B (OUT1)	Alarm output (relay), contact B	Brown
	3	Alarm R A	Alarm output, resistance monitoring, contact A	Green
	4	Alarm R B	Alarm output, resistance monitoring, contact B	Yellow
	5	Error A (OUT2)	Error output (relay), contact A	Gray
	6	Error B (OUT2)	Error output (relay), contact B	Pink
	7	Sab (OUT3)	Sabotage output	Blue
	8	GND Sab	Ground of sabotage output	Red

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.


LMS531 PRO Security Outdoor: “Inputs” connection*Table 39: LMS531 PRO Security Outdoor: Pin assignment of “Inputs” connection*

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6042735 ¹⁾
 Figure 56: M12 male connector, 12-pin, A-coded	1	A/DA (IN1)	In focus/Blurry (digital input 1)	Brown
	2	RD-/RxD	RS-422 / RS-232 receiver	Blue
	3	GND IN	Ground of all digital inputs	White
	4	GND RS/CAN	RS-422 / RS-232/CAN ground	Green
	5	D/N (IN3)	Day/Night (digital input 3)	Pink
	6	WT (IN2)	Walk test (digital input 2)	Yellow
	7	TD-/TxD	RS-422 / RS-232 sender	Black
	8	TEACH (IN4)	EasyTeach (digital input 4)	Gray
	9	RD+	RS-422 receiver	Red
	10	TD+	RS-422 sender	Violet
	11	CAN L	CAN bus LOW	Gray+pink
	12	CAN H	CAN bus HIGH	Red+blue

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.

LMS531 PRO Security Outdoor: "Alarm" connection


Table 40: LMS531 PRO Security Outdoor: Pin assignment of "Alarm" connection

Male/female connector	Contact	Short form	Signal description	Wire colors connecting cable part no. 6042732 ¹⁾
 Figure 57: M12 female connector, 12-pin, A-coded	1	Alarm A (OUT1)	Alarm output (relay), contact A	Brown
	2	Sab A (OUT4)	Sab output (relay), contact A	Blue
	3	Alarm B (OUT1)	Alarm output (relay), contact B	White
	4	Alarm R A	Alarm output, resistance monitoring, contact A	Green
	5	Error A (OUT2)	Fault output (relay), contact A	Pink
	6	Alarm R B	Alarm output, resistance monitoring, contact B	Yellow
	7	Disq. A (OUT3)	Disqualification output (relay), contact A	Black
	8	Error B (OUT2)	Fault output (relay), contact B	Gray
	9	Sab B (OUT4)	Sab output (relay), contact B	Red
	10	Disq. B (OUT3)	Disqualification output (relay), contact B	Violet
	11	Sab R A	Sabotage output, resistance monitoring, contact A	Gray+pink
	12	Sab R B	Sabotage output, resistance monitoring, contact B	Red+blue

¹⁾ Example values when using the specified connecting cable(s). Signal assignment and wire colors can vary when using other connecting cables.


6.4.4 Connections of the LMS511 with Harting male connector**LMS511 with Harting male connector: Pin assignment of the "Ethernet" RJ-45 female connector**

Table 41: LMS511 with Harting male connector: Pin assignment of the "Ethernet" RJ-45 female connector

Male/female connector	Contact	Short form	Signal description
 RJ-45	1	TX+	Sender+
	2	TX-	Sender-
	3	RX+	Receiver+
	6	RX-	Receiver-

LMS511 with Harting male connector: Pin assignment of the contact module

Table 42: LMS511 with Harting male connector: Pin assignment of the contact module

Male/female connector	Contact	Short form	Signal description
	1	V _S heat	Power supply heating
	2	V _S	Power supply sensor
	3	GND	Weight
	4	GND heat	Ground heating

6.5 Preparing electrical installation**6.5.1 SELV supply voltage**

To commission and operate the device you will need:

- SELV supply voltage DC 19.2 to 28.8 V according to IEC 60364-4-41

More data see ["Mechanics/electronics", page 111](#).

**WARNING****Risk of injury due to electric current!**

If the supply voltage is produced by a power supply unit, then insufficient electrical separation between input and output current circuit of the power supply unit may lead to an electric shock.

- Only use a power supply unit whose output circuit has safe electrical separation from the input circuit. For example with a safety transformer in accordance with EN 61558-1.

6.5.2 Wire cross-sections for LMS500 Indoor

The Indoor devices have screw terminals which are connected with the following wire cross-sections:

Table 43: Specification of the wire cross-sections for the screw terminals of the LMS500 Lite/PRO Indoor

Cable type	Minimum cross-section	Maximum cross-section
Flexible conductor (fine multi-stranded wires)	0.14 mm ²	1 mm ²
Rigid conductor (single wire)	0.14 mm ²	1.5 mm ²
Flexible conductor (fine multi-stranded wire) with ferrules	0.25 mm ²	0.5 mm ²

Wire cross-section

- All connections must be wired with copper cables.
- All communication cables must be stranded and shielded.
- For the cable calculation see "Example of maximum cable connection", page 74.

**NOTE**

With the LMS500, the external diameter of the joint cable must not exceed 9 mm due to the cable entry.

6.5.3 Wire cross-sections for LMS5x1 Outdoor

The Outdoor devices can be connected using the following optional accessories, see "Accessories", page 116:

- Standard cables up to 20 m with M12 male connectors
- For particularly long male cable connectors of over 20 m with/without M12 connectors, there is a compact connection unit for each device type.

Example of maximum cable connection**Prerequisites:**

- Steady state of the voltage supply
- Only applies for copper cable material
- For the line length calculation, the permissible voltage loss in the particular application must be specified.

Table 44: Length of cable and voltage drop

Cable properties	
$A = 0.75 \cdot 10^{-6} \text{ m}^2$	Cross-section of the cable surface [m ²]
$\rho = 1.72 \cdot 10^{-8} \Omega\text{m}$	Specific resistance of copper [Ωm]
$\alpha = 3.9 \cdot 10^{-3} \text{ K}^{-1}$	Temperature coefficient of copper [1/K]
Ambient conditions	
$T_0 = 20 \text{ }^\circ\text{C}$	Reference temperature [$^\circ\text{C}$]
$T = 80 \text{ }^\circ\text{C}$	Cable temperature [$^\circ\text{C}$]
Cable load	
$I = 2.5 \text{ A}$	Load current [A]
Voltage drop on the cable	
$\Delta V = 4.245 \text{ V}$	Voltage drop on the cable [V]
Formula for permissible length of cable	
$L = \frac{\Delta V \cdot A}{2 \cdot I \cdot \rho \cdot (1 + \alpha \cdot (T - T_0))} = 30 \text{ m}$	Permissible length of cable [m]

To check whether the voltage drop can be maintained with a calculated length of cable, the following calculation is possible:

Table 45: Voltage drop

Formula for the voltage drop to be considered	
$L = 30 \text{ m}$	Cable length [m]
$\Delta V = \frac{I \cdot 2 \cdot L}{A} \cdot \rho \cdot (1 + \alpha \cdot (T - T_0)) = 4.245 \text{ V}$	Voltage drop ΔV [V] Length of cable L [m] Cross-section of cable surface A [m ²] Specific resistance of copper [Ωm] Temperature coefficient of copper [1/K] Cable temperature [$^\circ\text{C}$]

The minimum voltage with which the device may be operated is the recommended 20 V see "Technical data", page 105.



NOTE

If the heating voltage supply cables are particularly long, it may be necessary to generally increase the input voltage (see formula for voltage drop) and install a 470 µF / 63 V capacitor between 24 V and 0 V (in the connection unit, close to the sensor). This allows for compensation for the voltage drop at the moment of switch-on.

6.5.4 Cable reserve on system plug

Allow for sufficient cable reserve of the supplied cables at the system plug. You can easily exchange the device with the cable reserve if needed.

Keep the cable reserve only long enough that the system plug cannot be accidentally plugged into an adjacent device when replacing the device! This prevents a device with an incorrect configuration being put into operation. Experience has shown that 200 to 300 mm of cable reserve on the device is ideal.

The reserve cable should be laid as a drip loop so no moisture (e.g., condensation) is directed towards the device but instead drips off the cable beforehand.

6.5.5 General conditions for data interfaces

The following table shows the maximum recommended length of cables depending on the selected data transmission rate.

Table 46: Maximum lengths of cables for the data interfaces

Interface type	Transfer rate	Maximum length of cable
RS-232	115.2 kBd	2 m
	38.4 ... 57.6 kBd	3 m
	Max. 19.2 kBd	10 m
RS-422	Max. 115.2 kBd	500 m
	Max. 38.4 kBd	1,200 m



NOTE

Use shielded cables (twisted pairs) with at least 0.25 mm².

To prevent interference factors, do not lay data cables over a longer route in parallel with voltage supply cables and motor cables, in cable channels, for example.

6.6 Performing the electrical installation

6.6.1 Connection to the auxiliary interface (USB) and the Ethernet interface of the device

Pre-assembled cables are available for configuring the device using the auxiliary interface (USB) and the Ethernet interface.



NOTE

The USB interface is used in industrial environments only as a service interface for temporary use (e.g. for configuration, troubleshooting). Use as a data interface (host) while the system is in operation is not supported.



NOTE

The recommended connecting cables and their associated technical data can be found on the online product page.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

6.6.2 LMS500: Wiring system plug



NOTE

Reduced enclosure rating! If the system plug is removed, the LMS500 no longer complies with enclosure rating IP65.

- To prevent damage from penetrating moisture and dirt, only open the system plug in a clean and dry environment.
- If necessary, pre-wire and mount the system plug in a suitable environment.

Prerequisites on device for enclosure rating IP65

- The system plug is attached to the device, its 2 screws are tightened.
- The cables in the cable entries correspond to the suitable diameter and are locked with the coupling nut. An unused cable entry is provided with a protective cap, which is locked with the coupling nut (as in the delivery condition).
- A corresponding cable is plugged into the M12 round connector (Ethernet) and locked. If the connection is not used, it must be covered with a tightly-fastened protective plug (as in the delivery condition).
- The black, round cover of the USB auxiliary interface ("USB" connection) on the front of the device is screwed in vertically and hand tight.

1. Make sure that the voltage supply for the LMS500 is switched off.
2. Remove system plug on the rear side of the device. To do so, loosen the two fixing screws (see figure 71, page 114) and carefully pull the system plug up out of the device vertically.
3. The two M16 cable entries (metal) have a ground connection to the device. If a shielded connecting cable is used, connect the shielding braid of the cable to the cable entry. To do this, shorten the shielding braid before the screw connection of the cable entry and push it back over the plastic insert of the cable entry.
4. Undo screw connection of the M16 cable entry.
5. Feed cables for the supply voltage and the digital outputs with a maximum outer diameter of Ø 10 mm through the plastic insert of the M16 cable entries.
6. Connect the wires to the two terminal blocks without tension and without pulling, see "Connections of the LMS500", page 64.
7. Connect the shielding braid of the cables to the cable entry.
8. Attach and tighten the screw connection of the M16 cable entry.
9. Carefully reattach the system plug to the LMS500.
10. Tighten the fixing screws of the system plug.

6.6.3 LMS511 / LMS531 / LMS581: Connecting M12 round connectors



NOTE

Prerequisites on device for enclosure rating IP67

- The system plug is attached to the device, its 2 screws are tightened.
- The device is only connected to the M12 round connectors provided.
- Use connecting cables with M12 round connectors that are compliant with enclosure rating IP67.
- The SICK cables attached to the M12 round connectors are locked. Any connections that are not being used must be fitted with protective caps or plugs that are screwed tight (as in the delivery condition).
- The black, round cover of the USB auxiliary interface ("USB" connection) on the front of the device is screwed in vertically and hand tight.

Pre-assembled cables can be ordered as accessories for connection to the M12 round connectors. These cables consist of the round connector and a 5, 10, or 20 m cable with an open end.

Torque screwdrivers with a defined torque are available as accessories for tightening and loosening M12 plug connections on the system plug.



NOTE

The recommended connecting cables and their associated technical data can be found on the online product page.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

6.6.4 Wiring the inputs and outputs




Figure 58: Activating digital inputs, non-floating

① External Switch




Figure 59: Activating digital inputs, volt-free

① External signal source



NOTE

The inputs require a switching voltage of at least 11 V. For this reason, the supply voltage must be at least 11 V.




Figure 60: Connection of encoder inputs (LMS511 PRO/Heavy Duty only)

① Encoder




Figure 61: Input circuit IN3 to IN4




Figure 62: Activating outputs 1 or 2 to a PLC (active LOW)




Figure 63: Activating outputs 3 to 6 to a PLC (active HIGH)




Figure 64: Resistance-monitored connection of the LMS531 Security outputs to an alarm system

① Alarm system

Wiring of the RS232 or RS422 interface

A shielded cable is required for connecting the RS-232 or the RS-422 interface.

**NOTE**

Observe the maximum length of cable according to [see "General conditions for data interfaces", page 75.](#)




Figure 65: Wiring of the RS232 or RS422 interface

7 Commissioning

7.1 Overview of the commissioning steps

1. Install the SOPAS ET configuration software.
2. Establish communication with the device.
3. Create an application-specific parameter set with SOPAS ET and save it permanently in the non-volatile device memory and on the computer.
4. Test the device for correct functioning.

7.2 SOPAS ET configuration software

The interactive configuration is performed using the SOPAS Engineering Tool (SOPAS ET) software. You can use this configuration software to parameterize and test the measuring properties, evaluation behavior, and output properties of the system as required. The configuration data are stored and archived as a parameter set (project file) on the computer.



NOTE

The most up-to-date version of the SOPAS ET software can be downloaded from www.sick.com/SOPAS_ET. The respective system requirements for installing SOPAS ET are also specified there.

Downloading and installing SOPAS ET

1. Start computer.
 2. Download and install the latest version of the SOPAS ET configuration software, as well as current device description files (*.sdd) for the device variant from the online product page for the software by following the instructions provided there.
 3. In this case, select the “Complete” option as suggested by the installation wizard. Administrator rights may be required on the computer to install the software.
 4. When the installation is finished, start the **SOPAS ET** program option. Path: Start > Programs > SICK > SOPAS ET Engineering Tool > SOPAS.
 5. Establish a connection between SOPAS ET and the device. In order to do this, select the desired communication interface for searching in the connection wizard. (Default Ethernet address: IP address: 192.168.0.1, subnet mask: 255.255.255.0).
- ✓ SOPAS ET establishes communication with the device and loads the associated device description file.

SOPAS ET default settings

Table 47: SOPAS ET default settings

Parameters	Value
Program interface language	English (you must restart the software after making any changes)
Units of length	Metric
User group (operating level)	Machine operator
Download the parameters to the device	Immediately after a change, temporarily in the RAM of the device
Upload the parameters from the device	Automated after online switching
Window arrangement	3 (project tree, help, working area)

7.3 Establishing communication with the device

**NOTE**

To communicate via Ethernet TCP/IP, the TCP/IP protocol on the computer must be active.

When connecting a PC/host, please adhere to the following order:

1. Connect the computer to the device with a data cable.
2. Switch on computer.
3. Switch on supply voltage of the device.
- ✓ The device performs a self-test and initializes itself.

Connecting data interfaces

Connect the device to the computer via one of the following data interfaces:

- USB
- Ethernet
- RS-232/RS-422

Starting SOPAS ET and calling up scan assistant

1. Start SOPAS ET.
2. In the main window under **Scan Assistant**, click on the **Configuration** button.
- ✓ The **Scan Assistant** dialog window appears.

Configuring the Ethernet connection**NOTE**

Deactivate all programs on your computer to access Ethernet or TCP/IP.

1. In the **Search settings** dialog box, select **Search by device family (recommended)**. Click on **>**.
 2. In the device family options, select **LMS5, LMS5xx / 25x** and click on **>**.
 3. Confirm the selected communication interface by clicking on **>**.
 4. If necessary, manually configure the IP addresses using **Add....** Click on **>**.
 5. Select COM ports, if necessary. Click on **>**.
 6. To save the search settings, enter a name and click on **Finish**.
-

**NOTE**

Save the parameter set as a project file (.sopas file with configuration data) on the computer so that it can be used as a basis for replacing a damaged device if necessary.

Configuring serial connection

1. In the **Scan Assistant** dialog box under **Serial Connection, Standard Protocol**, select the **Activate Serial Communication** checkbox.
2. Click the **Advanced...** button.
3. Select the following **PORT Settings**: 8 data bits, no parity, 1 stop bit.
4. Confirm the settings with **OK**.
- ✓ The **Advanced Scan Settings** dialog window is closed.
5. Confirm the settings in the **Scan Assistant** dialog window by clicking **OK**.
- ✓ The **Scan Assistant** dialog window closes.

Performing a scan

1. In the **Scan Assistant** dialog window, click the **Start Scan** button.
2. Select the listed devices and confirm by clicking **Add Device**.
- ✓ The connection is used to search for connected devices. SOPAS ET adds the devices found to the project tree and loads the current parameter set to the device via upload.

7.4 Initial commissioning

The device is adjusted to the situation on site using the SOPAS ET configuration software. To do this, SOPAS ET creates an application-specific parameter set of parameter values. For this purpose, the parameter set can first be loaded from the device (upload, initial commissioning: factory default setting). Or it is created independently, either based on the factory default settings or as a modification of an already existing parameter set of the device of the same type and firmware version.

The parameter set is then loaded into the device (download). This either happens immediately (**Download immediately** option in SOPAS ET) or manually (**Download all parameters to the device** command in SOPAS ET).



NOTE

After completing configuration, the changed parameter set must be permanently stored in the non-volatile memory of the device. As part of a backup concept for the created parameter values, we recommend saving the parameter set as a project file (*.sopas file with configuration data) on the computer for archival purposes.




Figure 66: Data storage principle

- ① Parameter set in the working memory of the device
- ② Permanently saved parameter set
- ③ Factory-set pre-settings of the device
- ④ Computer with SOPAS ET
- ⑤ Opened project file with current parameter set
- ⑥ Saved project file with archived parameter set (*.spr)
- ⑦ Hard drive

Device configuration

You can configure the device in two ways:

- Interactively using SOPAS ET. This section describes the interactive configuration.
- Using configuration telegrams, see ["Communicating data via telegrams"](#), page 55.

Interactive configuration with SOPAS ET

All configurable parameters of the device are collected together in a corresponding device description (.sdd file) for SOPAS ET. You can access these parameters via the project tree for the device description.

A content-sensitive explanation of each of the parameters is available directly next to the parameter via the ? button or in the online help (F1 key). The **Parameter Info** display window lists the valid range of values and the default setting (right-click when the pointer is located over the parameter).



NOTE

Software access to the device is protected by user levels and passwords. After successfully configuring the device, you should change the passwords so they can fulfill their protective function.

Table 48: Passwords

User levels	Password
Maintenance (Authorized Operator)	main
Authorized Client (Integrator)	client
Service	servicelevel
Operator	-

Table 49: User level and authorization

Operator	An Operator level user can view the basic device parameters. • No password required • Read only permissions • Not all parameters are visible
Maintenance (Authorized Operator)	A Maintenance (Authorized Operator) level user can view the application-specific device parameters. • Read only permissions • Not all parameters are visible • Can change the password for this user level
Authorized Client (Integrator)	A Authorized Client (Integrator) level user can configure the application-specific device parameters. • Access to most parameters • Can change the password for this user level as well as the password of the Maintenance (Authorized Operator) user level.
Service	A Service level user can configure all device parameters and view the status information. • Access to all parameters (incl. all expert functions) • Can change the password for this user level as well as the password of the Maintenance (Authorized Operator) and Authorized Client (Integrator) user level



NOTE

Change the passwords during initial commissioning to protect your device. A higher user level can change the password of a lower user level.



NOTE
If the password for the Service user level has been lost: see "Resetting the password for the Service user level", page 103.

Use the project tree in SOPAS ET to configure the necessary parameters for your application.



- NOTICE**
- Loss of configuration data in the connected device**
1. Do not switch off the voltage supply during the configuration of the device. Otherwise all parameters not yet saved permanently will be lost.
-
1. In the **Options** menu, select the **Log into device** command and log in as an **Authorized Client (Integrator)** using the password `client`.
 2. Configure the device for the required application using the parameters in SOPAS ET. Help on using the program user interface as well as for the different options can be found in SOPAS ET.

Resetting the configuration



NOTE
To reset the device to the delivery condition, use the **Factory defaults** option in SOPAS ET.

7.4.1 Parameterizing the LMS531 variants for security applications

Parameterization mode

The LMS531 can be parameterized via the simple **Standard** mode or via the more detailed **Expert** view mode. The expansion of the device structure depends on the selected mode.

Standard mode (simplified view)	Expert mode (detailed view)
LMS53x Security PRO (SN 21200090) - Quickstart - Field evaluation monitor - Field infringement logging - Service - Operating data - System status - Version	LMS53x Security PRO (SN 21200090) - Quickstart - Parameter - Basic settings - Filter - Contamination measurement - Evaluation fields - Evaluation cases - Security - Data processing - System performance - Network / Interfaces / IOs - Serial - Ethernet - CAN - Digital inputs - Digital outputs - External digital outputs - Display - Monitor - Field evaluation monitor - Scan view pro - Field infringement logging - Service - Operating data - System status - Version

When changing from expert mode back to standard mode, the program asks whether the factory defaults should be reloaded. It is recommended to respond **Yes**.

**NOTE**

If the factory defaults are not loaded, it is possible that settings on the quick start page no longer correspond to the expected default settings (for example, if the settings of an evaluation case are changed in **Expert** mode or an object size is not parameterized the same for all fields).

Quickstart

The **Quickstart** page contains all parameters that a customer requires to parameterize a standard safety application.

7.4.1.1 Default – Standard mode and Expertmode

Group	Parameter	Properties
Response (standard mode)	object size	40 mm NOTE The minimum object size for detection cannot be guaranteed over the entire scanning range due to the distance-dependent absolute measurement resolution. The detectable object size depends on the maximum distance to the outer field boundary. A parameterized field must therefore always be checked using the corresponding object size setting see " Minimum object size ", page 30.
	Response time	240 ms
Alarm signal (standard mode)	Holding time	3 s
Error signal (standard mode)	Holding time	3 s
Detection fields (evaluation fields)	9 predefined rectangular fields (PRO) 3 predefined rectangular fields (Lite)	LMS531 PRO: - Field 1: Rectangle 40 m x 20 m (symmetrical about a 90° beam) - Field 2-9: Rectangle 40 cm x 20 cm (symmetrical about a 90° beam) LMS531 Lite: - Field 1: Rectangle 40 m x 20 m (symmetrical about a 90° beam) - Field 2-3: Rectangle 40 cm x 20 cm (symmetrical about a 90° beam)
Evaluation cases (expert mode)	9 predefined evaluation cases 3 predefined evaluation cases	LMS531 PRO: - Evaluation case 1 - 9: Strategy - blanking - Evaluation case 10: Strategy - contour (manipulation protection is always active) LMS531 Lite: - Evaluation case 1 - 3: Strategy - blanking - Evaluation case 4: Strategy - contour (manipulation protection is always active)
	Response time	240 ms
	object size	40 mm
	Linked field	Evaluation case 1 is linked to detection field 1. Evaluation case 2 is linked to detection field 2. This logic is repeated for all fields.
	Connected output	Output 1: Alarm

Group	Parameter	Properties
Digital outputs (expert mode)	Function	Output 1 - Alarm: Application Output 2 - Fault: Device Ready
	Logic type	Output 1 - Alarm: Active low Output 2 - Fault: Active high
	Restart	Output 1 - Alarm: Time Output 2 - Fault: Time
	Restart delay	Output 1 - Alarm: 3 s Output 2 - Fault: 3 s

7.4.1.2 Detection fields/monitored areas

The LMS531 PRO contains 9 predefined fields and a tenth non-predrawn field. The LMS531 Lite contains 3 predefined fields and a fourth non-predrawn field.

All predefined fields can be changed.

- Field 1: Rectangle 40 m x 20 m (symmetrical about a 90° beam)
- Field 2 to 9 (LMS531 Lite: Field 2 and 3): Rectangle 40 cm x 20 cm (symmetrical about a 90° beam)
- Field 10 (LMS531 Lite: Field 4): Field not predrawn. **Contour as reference** function predefined in standard mode

For more information on detection fields, see ["Field application"](#), page 46.

7.4.1.3 Operating mode

The LMS531 has 3 different operating modes. These can be activated by switching the digital inputs 1 and 2.

- Input 1: Switches between **armed** and **disarmed**
- Input 2: Switches between **Walk-through test active** and **Walk-through test deactivated**

Input 1 Disarmed	Input 2: Walk-through test	Operating mode
0 V	0 V	Armed
24 V	0 V	Not sharp
0 V or 24 V	24 V	Walk-through test active

Meaning of the operating mode

- **Armed:** In this mode, the front panel (LEDs, display and USB interface) is deactivated. Field interruptions are not visible on the LEDs. If a field interruption is present, the alarm output switches and an internal alarm memory is set. The alarm memory is displayed in **Disarmed** mode.
- **Unarmed:** In this mode, the front panel (LEDs, display and USB interface) is active. The Q1 LED is on if the alarm memory has been set in **Armed** mode. If an object detection is detected in **Disarmed** mode, the alarm output switches however the Q1 LED remains off (the alarm memory is not set).
- **Walk-through test:** In this mode, the front panel (LEDs, display and USB interface) is active and an object detection is indicated on the Q1 LED (no alarm memory display). The alarm output switches.

The second **Walk-through test** input has a higher priority than the first **Disarmed** input. Therefore, when **Walk-through test** is activated, the device switches from **Armed** or **Disarmed** mode to **Walk-through test** mode.

7.4.1.4 Day/night switching (LMS531 Pro)

Input 3 is used for day/night switching of the evaluation cases. One or more evaluation cases can therefore be active during the day, while one or more other evaluation cases are used at night. To implement this, input 3 needs to be controlled by the system controller in such a way that, depending on the time of day, it is switched between Low = 0 V during the day and High = 24 V at night. To use day/night switching, activation in the evaluation case must be set to **Input**, and the night switching must be configured as follows:

Day/night switching	Input 3	Setting in evaluation case for night switching
Evaluation case active during the day	0 V	Active low
Evaluation case active at night	24 V	Active high
Evaluation case independent of input 3	0 V or 24 V	Not relevant

In standard mode, all evaluation cases have the same properties. Each evaluation case can be activated separately via input 3 (in standard mode). By default, the evaluation is set to **Always**.

7.4.1.5 Digital outputs and relay outputs

Outputs

By default, all evaluation cases are linked to the alarm output. The LMS531 Lite has two relay outputs and one digital output. The LMS531 PRO has four relay outputs.

	Lite	PRO	Function
Output 1	Alarm	Alarm	Relay
Output 2	Fault	Fault	Relay
Output 3	Sabotage	–	Digital
	–	Disqualification	Relay
Output 4	–	Sabotage	Relay

The relay outputs can be used as voltage-free outputs. Output 1 (alarm) as well as output 4 (sabotage) of the LMS531 PRO can be resistance monitored outputs [see figure 64, page 79](#).

Alarm

All existing fields are linked to digital output 1 (alarm) using the “OR” logic operator. The reset time can be parameterized. In **Standard** mode, this output assignment cannot be changed.

The duration of the switched alarm output can be set in different steps:

- 1 second
- 3 seconds (factory default)
- 10 seconds

In **Expert** mode, the evaluation result can be assigned to any output.

Fault

There are 2 ways to use this output.

- This signal is activated when an error occurs with the device.
- If the **Validity check** function is activated and has not yet finished with a “valid” result [see "Security - validity check", page 93](#). This is also activated optionally to 1.

This corresponds to the “Device Ready” function of the standard devices.

In **Standard** mode, the fault message is linked to output 2 (Fault) and cannot be changed.

The duration of the switched fault output can be set in different steps:

- 1 second
- 3 seconds (factory default)
- 10 seconds

In **Expert** mode, the fault message can be set for each evaluation case.

Disqualification

Freely available output. Not visible in **Standard** mode. In **Expert** mode, the disqualification message can be set in each evaluation case.

Sabotage

Freely available output. Not visible in **Standard** mode. In the **Expert** mode, the sabotage message can be set in each evaluation case.

7.4.1.6 EasyTeach

Configuration is performed by teaching in (EasyTeach) of the surrounding contour in order to automatically generate a field with any shape, including complex shapes. The device stores the shortest value measured during the teach-in phase as a field boundary for each angle.

Preparing EasyTeach

- Remove all objects that will not permanently be in the field of view in monitoring mode later on.
- Distance yourself sufficiently from the device during the teach-in phase and do not enter the monitored area, so that you are not detected as part of the field contour.

LITE mode

The EasyTeach function allows the customer to design a field by walking the field boundaries to be saved. It is important to make sure that the person doing the walkthrough is clearly detected at all times during the teach-in phase.

PRO mode

In PRO mode, the EasyTeach LITE function is available within a predefined field. EasyTeach can be activated via digital input 4 on the LMS531 PRO variant, and via digital input 3 on the LMS531 Lite variant. There are three modes for EasyTeach – they are INACTIVE, LITE and PRO (for LMS531 PRO only) and can be selected in the **Authorized customer (installer)** user level as well as in higher user levels.

Using the **Start EasyTeach** button, the respective input can be simulated and, as a result, the EasyTeach process can also triggered via SOPAS ET.

Input 3/4 - EasyTeach	EasyTeach activation
0 V	EasyTeach teach-in stopped
24 V	EasyTeach teach-in started

The **Minimum duration** parameter defines how long the teach-in process takes once the trigger (input 4 / input 3) has been activated.

**NOTE**

If the user has configured the Debounce Time value of the digital input, the length of the pulse for the EasyTeach trigger must be longer.

During teach-in, the **Q2** LED on the front of the device is switched on. Once the teach-in process has finished, the **Q2** LED flashes for 10 seconds and the field is saved permanently. If the **Automatic EasyTeach at device startup** option is activated, an EasyTeach is performed each time the device is restarted.

7.4.1.6.1**EasyTeach LITE**

EasyTeach LITE mode can be used to define a field. This is done by specifying the angle range, field number, field name, mode, and minimum distance to the contour of the field. This mode has two functions: **Evaluation field** or **Reference contour**.

7.4.1.6.2**EasyTeach PRO**

In EasyTeach PRO mode (LMS531 PRO), up to five EasyTeach fields can be created automatically as long as the EasyTeach input is active. These EasyTeach fields are taught in within previously defined boundaries (template fields).

Each EasyTeach PRO field is assigned its own template field.

Template field	EasyTeach PRO field
Field 1	Field 6
Field 2	Field 7
Field 3	Field 8
Field 4	Field 9
Field 5	Field 10


Application example: Entry to the company premises is to be monitored and reported at night. The field of view of the LMS531, however, is larger than the area to be monitored and limiting the scanning angle is not sufficient. The maximum area to be monitored is created as a template field. At the beginning of the night, the EasyTeach PRO function is used to teach the actual area to be monitored within the company premises (template field). Objects placed in the field of view during the day are detected and excluded from monitoring.

The first step is to create one or more template fields that define the maximum extent and boundaries of the EasyTeach fields. These can be created in the SOPAS ET field editor, or also generated using EasyTeach LITE. Next, all EasyTeach fields to be created must be defined or configured. Each EasyTeach field has its own parameters ([see "Examples of the EasyTeach PRO Detection field mode", page 91](#)). All activated fields are taught-in together as soon as input 4 has been activated.

The **Automatic reset to template field** option allows you to automatically reset a taught-in EasyTeach PRO field to the template field after a configured time. The condition for this is that the template field recognizes a status change from interrupted to clear.

Examples of the EasyTeach PRO Detection field mode



Area between the scanner and template field is clear:
EasyTeach PRO field (green). Created within a template field (gray) and with a separation of 200 mm to the scan line.



Object present in the area between the scanner and template field:
EasyTeach PRO field is created while an object is between the scanner and template field. No detection field is created in the shadow of the object.

EasyTeach PRO field (green): The evaluation case is parameterized with the manipulation protection disabled. The detection field remains free (green), even if an object is located between the device and detection field.

EasyTeach PRO field (yellow): The evaluation case is parameterized with the manipulation protection enabled. The detection field is interrupted (yellow) as soon as an object is located between the device and template field.




Example of the EasyTeach PRO Reference contour mode

Reference contour taught-in within a template field:


For Reference Contour mode, it is recommended to teach in a segmented template field as the reference contour. It is only necessary to ensure that the distance to the contour is within a sufficient tolerance of the desired value. This ensures that the scanning angles of the EasyTeach PRO field match those of the template field.

The scan line is a sufficient distance from the edge of the template field (gray) everywhere. The detection field is clear (green).

The scan line is closer to the front edge of the template field (gray) than defined in the teach-in parameters of the reference field contour. The EasyTeach PRO field (green) is drawn up to the edge of the template field.



For comparison: Reference contour created, limited by the start and stop angles and without using the limitation by a template field with EasyTeach PRO.




7.4.1.7 Special functions

Field editor - Teach-in manipulation protection

The field editor has an additional **Teach-in manipulation protection** teach-in mode.

This manipulation protection field is designed to detect when the front screen of the LMS531 has been covered or when the LMS531 has been moved from its original position.



Basically, a contour is created as a reference field that always starts from the LMS531. In “Expert mode”, this field can be changed in the **Evaluation fields** section. The **Contour** evaluation strategy must be selected in the evaluation case.

In the following settings, the **Distance** parameter controls how far the teach-in points can be from the contour (positive distance). In the figure above, the offset distance to the contour is 100 mm.

This **Distance** setting allows a tolerance in case of vibrations of the LMS531 (e.g., mounted on the pole) or the reference object (e.g., fence). If the LMS531 is rotated or moved from its original position and the new target is outside the boundary of the manipulation protection contour (green line on the image above), the output 1 **Alarm** is triggered.

Security - validity check

This function can be used to detect manipulation within the monitored field areas.

This function is used for final testing and prevents an incorrect setup of the detection fields. The validity check confirms that all programmed fields and contours of the LMS531 are free of obstacles or shadows and are fully visible from the position of the sensor. This operation can only be performed if there is a connection to the LMS531. The “Teach-in validity area” function must be run once at the end. The validity check is a part of the VdS certification. If no additional validation of the valid measurement points is required, the validity check can remain disabled.

In **Expert mode**, this function is located under the main menu **Parameters, Security** or directly on the **Quickstart** page in **Standardmode**.

The following status can be displayed:

- **Pending:** The validity check has not yet been performed (new fields have been defined, existing fields have been changed or deleted).
- **Invalid:** The taught-in contour is invalid (e.g., the required number of valid measuring beams in succession (50%) has not been reached).
- **Valid:** The contour was taught in successfully. Validity means that each laser beam is checked for valid and stable measured values. This test is only performed, however, for the angular ranges in which detection fields have been defined. This ensures that sufficient measured values are available for the sensor to evaluate.

During the validity check, all setup fields are checked for validity.

If all fields are valid, the fault output is cleared and therefore the fault signal is removed. If the configured detection fields are not found to be valid, the error output at the fault output remains activated and generates an error message.

The outputs change from yellow to gray in the SOPAS ET user interface. Manipulations within the monitored field areas are detected and prevented by this function. If a manipulation (masking) lasts at least 10 seconds, an error is triggered. As soon as the manipulation is no longer present, the error signal is canceled and the error output of the sensor becomes free again. If the scan configuration is changed, the validity check is set to inactive and must be taught in again.

Flashing of Q2 LED - When the validity check is triggered in the **Armed** state. If the device is covered or the front screen is removed during a valid validity check, this is indicated by the Q2 LED flashing in **Disarmed** mode.



NOTE

If new fields are defined or existing fields are changed or deleted, the validity check must be performed again. If this action is not performed by the installer, the error output remains active.


Front panel - display activation

The front panel display can be activated/deactivated depending on the operating mode, i.e. it is deactivated in **Armed** mode and activated in **Disarmed** and **Walk-through test** mode.

Automatic field adjustment

This function was developed for specific scenarios. When the LMS531 is used to monitor a facade, for example, a field is viewed down to ground level. In case of snowfall, the snow will gradually build up in such a way that it could interrupt the detection field.

With the **Automatic field adjustment** function, the field automatically adjusts to the shape of the slow-growing snow.



An evaluation case can be configured to automatically adjust the linked field under certain circumstances (e.g., grass growth or snow accumulation).

The following settings are displayed in the parameterization wizard of an evaluation case:

- Enable/disable automatic field adjustment
- Configured the output to signal field adjustment
- Setting the maximum possible speed

When this feature is enabled, the LMS531 evaluates the field edge for any slow encroachment into the setup field. The speed of encroachment is determined by the speed setting. If the specified speed is exceeded, the selected evaluation output is triggered.

When snow or grass begins to “touch” the field, the automatic field adjustment is triggered. When this triggering occurs, the sensor can signal this triggering via the selected output.

The adjustment of field points is triggered by at least one scan point “touching” the edge of the field.

The following field points are adjusted in this case:

- All field points that “touch” the edge of the field and at the same time do not exceed the speed (Note: The speed is only taken into account if the field is adapted to the sensor)
- All surrounding field points in the near range are adjusted to smooth the shape.



NOTE

If a point is displayed in the center of the field and not at the edges, it is considered an intrusion and the alarm output is triggered.

Recording of object detections

Each interruption in a defined detection field is recorded in the object detections table. The details of the interruption include the position and angle values as well as a time stamp.

To make the object detections visible in the field evaluation monitor, they must be enabled in the **Object detections** tab. The parallel view of the field evaluation monitor and the object detections table allows individual or even multiple field interruption points to be marked and made recognizable by a red color.

7.5 Connecting and performing a test measurement

Use the graphic scan view in SOPAS ET to verify the generated measured values and the measuring range online.

1. In the project tree, select **LMS...**, **Monitor**, **Scan view pro**.
2. Compare the measurement line with the required result.



NOTE

- The **Pro scan display** in the **Monitor** depends on the available processing power of the computer and is not a real time display. For this reason not all measured values are displayed. The same restriction also applies to saving the displayed measured values in a file.

3. After successful completion of the test measurement, save the configuration permanently in the device: Menu **LMS...**, **Parameters**, **Save permanently**.

Commissioning tests

The commissioning tests can be used to check whether the cables are correctly connected to the device.

1. Log in at the **Service** user level
2. Menu: **LMS5xx.../Commissioning acceptance tests.**
3. In the window for the commissioning tests, you can query or control specific connection pins:
 - Check the status of the digital inputs
 - Switch the outputs “high” or “low”
 - Check the voltage supply for the integrated heater
 - Check the 7-segment display

**NOTE**

At the start of the commissioning test, all outputs are set “low”.

8 Maintenance

8.1 Cleaning



NOTICE

Equipment damage due to improper cleaning.

Improper cleaning may result in equipment damage.

- Only use recommended cleaning agents and tools.
- Never use sharp objects for cleaning.

- ▶ Clean the viewing window at regular intervals and in the event of contamination. First, remove any solid deposits with oil-free compressed air or, if necessary, with a mixture of water and a few drops of a commercially available rinsing agent and a soft brush, and then rinse. If required, remove the drying residue with cleaning cloths that are suitable for optics and plastic cleaning agent.



NOTICE

If the inspection window is scratched or damaged (cracked or broken), the lens must be replaced. Contact SICK Support to arrange this.

- If the inspection window is cracked or broken, take the device out of operation immediately for safety reasons and have it repaired by SICK.

8.2 Maintenance plan



NOTE

No maintenance is required to ensure compliance with the laser class.

Depending on the assignment location, the following preventive maintenance tasks may be required for the device at regular intervals:

Table 50: Maintenance plan

Maintenance work	Interval	To be carried out by
Check device and connecting cables for damage at regular intervals.	Depends on ambient conditions and climate.	Specialist
Clean housing and viewing window.	Depends on ambient conditions and climate.	Specialist
Check the screw connections and plug connectors.	Depends on the place of use, ambient conditions or operating requirements. Recommended: At least every 6 months.	Specialist
Check the mounting accessories and vibration dampers used.	Depends on the place of use, ambient conditions or operating requirements. Recommended: At least every 6 months.	Specialist
Check that all unused connections are sealed with protective caps.	Depends on ambient conditions and climate. Recommended: At least every 6 months.	Specialist

8.3 Device replacement

Faulty or damaged devices must be dismantled and replaced with new or repaired devices of the **same type**.

As all external cable connections terminate in the system plug or the round connectors, there is no need to repeat the electrical installation when the device is replaced. The replacement device can simply be connected.



NOTE

Disconnect the power to the system!

While the device is connected, the system may start unintentionally.

Make sure that the entire system is disconnected from the voltage supply during all exchange processes.

8.3.1

Exchange of the LMS500 Lite/PRO or LMS511 Heavy Duty when reusing the previous system plug (parameter cloning)




Figure 67: Removing system plug

- ① System plug
- ② Seals



NOTE

When the **QC passed** seal is broken, the device loses its warranty.

If your device is still within the warranty period, weigh up if you should replace the system plug yourself or send the device to SICK for repair. After the warranty period has expired, the seal can be broken without a second thought.

**NOTICE****Danger of damage due to environmental influences!**

While the system plug is removed from the device, the device and contacts are unprotected and the enclosure rating no longer meets IP65, IP67.

- Replacement of devices with removable system plug (its removal and installation) must only be performed in a clean, dry and dust-free environment. For this purpose, move the device from the outdoor area to a corresponding indoor area, if necessary.
- To prevent damage to the devices, firmly attach the existing system plug to the replacement device immediately after replacement.
- Also, immediately attach the remaining, non-wired system plug for the replacement device firmly to the removed (and potentially defective) device.
- Make sure that the inlay sealing, the supporting surface opposite, and all the electrical contacts of the system connector are free from dirt and moisture.

1. Switch off the voltage supply to the LMS5xx.
2. Dismantle the device from the bracket. If necessary, mark the alignment appropriately.
3. If the device is provided with a protection hood/weather protection hood, remove it from the LMS5xx.
4. LMS511 Heavy Duty: Break the **Remove for cloning** seal at the rear on the device system plug.
5. Recommendation: Turn the device upside down while disconnecting the system plug to avoid dirt falling into the electrical connections.
6. Loosen 2 screws and remove the old system plug including wired cables/fixed cables at the sensor.
7. Make sure that the inlay sealing, the supporting surface opposite, and all the electrical contacts are undamaged and free from dirt and moisture. If necessary, clean the corresponding elements.
8. Remove the unwired system plug from the corresponding replacement device.
9. Replace the previous system plug including cables at the rear of the replacement device and mount it.
10. If necessary, remount the protection hood/weather protection hood to the replacement device.
11. Re-mount the replacement device to the bracket [see "Mounting", page 57](#) and check alignment.
12. Automatically configure replacement device [see "Parameter cloning \(LMS500 Lite/PRO and LMS511 Heavy Duty\)", page 100](#).

**NOTE**

In the case of a complete device replacement, including the system connector (LMS500: rewiring!), the replacement device must be configured manually. This is done using the parameter set of the previous device stored on your computer according to the safety concept [see "Commissioning", page 81](#).

8.3.2 Complete replacement of the LMS5x1 (without reuse of the previous system plug)

1. Switch off the voltage supply.
2. Loosen round connectors on device and remove connecting cables.
3. Dismantle the device from the bracket. If necessary, mark the alignment appropriately.
4. If the device is provided with a protection hood/weather protection hood, remove it.
5. If necessary, remount the protection hood/weather protection hood to the respective replacement device.

6. Mount the replacement device to the bracket (see ["Mounting", page 57](#)) and check alignment.
7. Reconnect and tighten all connecting cables on the replacement device.
8. Manually configure the replacement device using the parameter set of the previous device stored on your computer according to the backup concept (see ["Commissioning", page 81](#)).

8.3.3 Parameter cloning (LMS500 Lite/PRO and LMS511 Heavy Duty)



NOTE

The parameter cloning function can only be used between devices of the same type.

Functionality

When the supply voltage is switched on, the device starts up and organizes its current parameter values as follows:

- Initial commissioning of a brand-new device: The device starts up with the default setting. The cloning parameter memory of the system connector contains the default setting.
- For each adjustment to the function configuration of the device: The device saves the parameter values permanently in its internal, non-volatile parameter memory. Additionally, it always saves a permanent copy of the parameter set in the cloning parameter memory of the system plug. (This is initiated using SOPAS ET and the **Save permanently** function.) The parameter set remains saved in the system plug even if the voltage supply is interrupted.
- The next time it is started up, the device transfers the parameter set from the cloning parameter memory to its RAM see ["Initial commissioning", page 83](#).

If a device is replaced, after start-up the replacement device checks whether there is a plausible parameter set in the system plug. If so, the device loads this parameter set to its RAM ("cloning plug gains" strategy).

As the existing system plug continues to be in use, the LMS500 Lite/PRO and the LMS511 Heavy Duty therefore make it possible for the last parameter values used in the system plug to be passed on to a replacement device of the same type automatically (cloning).

Cloning involves the replacement device accepting all the adjustable parameters, including field evaluation settings and the IP address. Accordingly, the process overwrites all the existing parameter values in the device. The exceptions in this case are the following parameters, which are always device-specific: serial number, MAC address, operating hours counter, and error memory.



NOTE

Testing the device for application suitability by means of acceptance after device replacement

If the replacement device is going on to be used unchanged, with the existing system plug and the parameter values saved in it for the application, acceptance by qualified safety personnel is not required. However, a test based on the regulations for daily testing, or a functional test, must be carried out.

If the replacement device will continue to be used with a system plug that is different from the previous one, the existing configuration must be transferred to the sensor using SOPAS ET. In this case, acceptance by qualified safety personnel may be required (depending on the system; e.g., Security).

9 Troubleshooting

9.1 Repairs

Repair work on the device may only be performed by qualified and authorized personnel from SICK AG. Interruptions or modifications to the device by the customer will invalidate any warranty claims against SICK AG.

9.2 Returns

- ▶ Only send in devices after consulting with SICK Service.
- ▶ The device must be sent in the original packaging or an equivalent padded packaging.



NOTE

To enable efficient processing and allow us to determine the cause quickly, please include the following when making a return:

- Details of the contact person
- Description of the application
- Description of the fault that occurred

9.3 General faults, warnings, and errors

The following sections describe possible faults and troubleshooting measures to correct them. For faults that cannot be rectified using the information below, please contact SICK Service. To find your agency, see the final page of this document.



NOTE

Before calling, make a note of all type label data such as type designation, serial number, etc., to ensure faster assistance.

9.3.1 LED fault indicators




Table 51: LED fault indicators

Display	Possible causes	Troubleshooting
③ and ① off	Supply voltage missing or too low	Check the voltage supply and activate, if necessary.
① lights up	Device not ready	- Note the error indicated on the 7-segment display or run diagnostics using SOPAS ET. - Switch off the device and turn it on again, if necessary.
② lights up	Viewing window slightly contaminated (warning)	Clean the viewing window.
① lights up and ② flashes at 1 Hz	Viewing window heavily contaminated (error)	Clean the viewing window.

9.3.2 Indicators in the 7-segment display

Display	Possible causes	Troubleshooting
–	Not an error	Device is in measuring mode
P flashes	Firmware update is being run	Wait until firmware update has finished.
E and Zahl alternating	Device error	Contact SICK Service.
0	Connection to synchronization main interrupted	Reconnect to the synchronization sub.
1	Temperature too low (only for Indoor device)	The ambient temperature is too low for measurement mode.
3	Heating not connected or temperature too low (only for Outdoor device)	- Wait until the device has warmed up. - Check heating connection. - Contact SICK Service.
Each segment flashes once in sequence	Device powers up.	Wait until the device has started.
Other displays	Display is controlled by system controller	See the system controller documentation or contact the supplier of the system controller.

9.3.3 Detailed fault analysis

The device reports any errors that occur in a number of ways. Fault output is staggered, allowing for an increasingly detailed level of analysis:

Telegram

Communication errors can occur when transmitting telegrams to the device. The device then returns a fault code. A description of the communication errors can be found in the Telegram Listing, [see "Telegram listing \(EN\)", page 117](#).

System log

Information about the status of the device is displayed in the system log.

SOPAS ET: Project tree, LMS..., Service, System Status

Reserved distance values

A description of the reserved distance values can be found in the Telegram Listing ([LMDscandata - reserved values](#), Telegram Listing [see "Telegram listing \(EN\)", page 117](#)).

Field evaluation monitor

With the field evaluation monitor, you can analyze if and how detection fields are interrupted and how the outputs of the device behave.

SOPAS ET: **Project tree, LMS..., Monitor, Field evaluation monitor.**

Field evaluation logging

With field evaluation logging, you can record any object detection that occurs. The field evaluation logging helps with diagnosing longer periods of time, analyzing faults, or optimizing processes.

SOPAS ET: **Project tree, LMS..., Monitor, Recording of object detections.**

9.3.4 Resetting the password for the Service user level

If you have forgotten the password of the **Service** user level, you can reset it with the assistance of SICK.



NOTE

The responsible SICK sales company or the responsible SICK service partner carefully checks each code request to reset the password. A risk of deception by third parties nevertheless exists. The operating entity should therefore take suitable security measures.

The operating entity should also take suitable measures to limit, as best as possible, access to the product. This includes, in particular, physical access as well as access to the software interfaces of the product.

Requesting an unlock code

1. Open SOPAS ET.
2. Open the device window.
3. Open the device name (LMS5xx_...) > **Password > Reset Service password.**
- ✓ The **Reset password** window appears.
4. Enter the relevant data.
 - ① **NOTE** | Do not press **Generate** if an unlock code has already been requested from SICK. Only press this button if a new device code is required when inquiring again.
5. Click **Generate e-mail with data.**
- ✓ Your SICK subsidiary will create the unlock code based on the information provided and send it to you.

The code is only valid once for the reset process. You can close the window by clicking on the x without interrupting the reset process. If you select **Cancel** or enter an incorrect code several times, the current reset process is terminated. The requested code is no longer valid. The process must be restarted.
6. Wait for the unlock code: The dialog box can be closed and the device switched off.

Entering the unlock code

Prerequisite

- SICK has sent an unlock code.
1. Open SOPAS ET.
 2. Open the device window.
 3. Open the device name (LMS5xx_...) > **Password > Reset Service password.**
 - ✓ The **Reset password** window appears.
 4. Click **Next.**
 5. Enter the code sent by SICK.

6. Click **Ok**.
- ✓ Password has been reset to the default password `servicelevel`. Parameters are not changed.

Assigning a new password for the Service user level

1. Open SOPAS ET.
2. Log on to the device with the **Service** user level and the default password `servicelevel`.
3. Open the device name (LMS5xx_...) > **Password** > **Change password**.
4. Assign the new password for the **Service** user level.

9.4 Disposal

If a device can no longer be used, dispose of it in an environmentally friendly manner in accordance with the applicable country-specific waste disposal regulations. Do not dispose of the product along with household waste.



NOTICE

Danger to the environment due to improper disposal of the device.

Disposing of devices improperly may cause damage to the environment.

Therefore, observe the following information:

- Always observe the national regulations on environmental protection.
- Separate the recyclable materials by type and place them in recycling containers.

10 Technical data



NOTE

The relevant online product page for your product, including technical data, dimensional drawing, and connection diagrams, can be downloaded, saved, and printed from the Internet.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**
{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

Please note: This documentation may contain further technical data.

10.1 Features

	LMS500	LMS511/LMS581	LMS531
Application	Indoor	Outdoor	Outdoor, Security
Resolution	High resolution	Standard resolution, high resolution (type-dependent)	Standard resolution
Light source	Infrared (905 nm ± 10 nm)		
Laser class	Laser class 1, EN 60825-1:2014+A11:2021; IEC 60825-1:2014; CAN/CSA-E60825-1:2015-11 Complies with 21 CFR 1040.10 and 1040.11 except for conformance with IEC 60825-1 Ed. 3 as described in Laser Notice No. 56, dated May 8, 2019.		
Aperture angle	190°		
Scanning frequency	Lite: 25 Hz ... 75 Hz PRO/Heavy Duty: 25 Hz ... 100 Hz		
Angular resolution	Lite: 0.25°, 0.50°, 1° PRO/Heavy Duty: 0.1667°, 0.25°, 0.3333°, 0.5°, 0.6667°, 1° Exclusively in Interlaced mode: 0,042°, 0,083°		
Scan field flatness	Scan field flatness combined: ± 0.72° Typical conical error: 1 sigma value -0.11° ± 0.10° Typical tilt: 1 sigma value +0.15° ± 0.08°		
Field sets	Lite: 4 PRO/Heavy Duty: 10		
Simultaneous evaluation cases	Lite: 4 PRO/Heavy Duty: 10		
Heating	self-heating	Self-heating with additional integrated heating	
Working range	0.2 m ... 80 m (HR and SR) 0.2 m ... 130 m (SR Extended Range)		
Scanning range with 10% radiance factor	0.7 m ... 26 m	0.7 m ... 26 m (HR) 1.0 m ... 40 m (SR) 1.0 m ... 52 m (SR Extended Range)	1.0 m ... 40 m (SR) 1.0 m ... 52 m (SR Extended Range)
High resolution measurement accuracy ¹⁾	± 12 mm		–
Standard resolution measurement accuracy ²⁾	–	± 24 mm	

	LMS500	LMS511/LMS581	LMS531
High resolution spot size	Divergence: 4.7 mrad at the viewing window: 13.5 mm in 26 m: 136 mm in 40 m: 202 mm		–
Standard resolution spot size	–	Divergence: 11.9 mrad at the viewing window: 13.5 mm in 26 m: 322 mm in 40 m: 489 mm	
Number of echoes evaluated	Lite: 2 PRO/Heavy Duty: 5		

- 1) Measured in test environment (like LMS2xx): Temperature = 23 °C, Remission = 100% at 6 m distance
 2) Measured in test environment (like LMS2xx): Temperature = 23 °C, Remission = 10% at 20 m distance

Working range diagrams




Figure 68: LMS5xx high resolution working range, unit m (ft), decimal separator: period

- ① Scanning range in m
 ② Max. scanning range 80 m
 ③ Scanning range for objects up to 10% remission 26 m




Figure 69: LMS5xx standard resolution working range, unit m (ft), decimal separator: period

- ① Scanning range in m
- ② Max. scanning range 80 m
- ③ Scanning range for objects up to 10% remission 40 m




Figure 70: Working range of LMS5xx Standard Resolution Extended Range, unit m (ft), decimal separator: period

- ① Scanning range in m
- ② Max. scanning range: 130 m
- ③ Scanning range for objects up to 10% remission factor: 52 m

10.2 Performance

	LMS500	LMS511/LMS581	LMS531
Response time ¹⁾	Lite: typ. ≥ 13 ms PRO/Heavy Duty: typ. ≥ 10 ms		
Power-up delay	25 s – 60 s (above 0° C)		
Systematic error 1 Echo High Resolution ²⁾	± 25 mm (1 m ... 10 m) ± 35 mm (10 m ... 20 m)		–
Systematic error 1 Echo Standard Resolution ²⁾	–	± 25 mm (1 m ... 10 m) ± 35 mm (10 m ... 20 m) ± 50 mm (20 m ... 30 m)	
Statistical error 1 Echo High Resolution ²⁾	7 mm (1 m ... 10 m) 9 mm (10 m ... 20 m)		–
Statistical error 1 Echo Standard Resolution ²⁾	–	6 mm (1 m ... 10 m) 8 mm (10 m ... 20 m) 14 mm (20 m ... 30 m)	

	LMS500	LMS511/LMS581	LMS531
Integrated application	Field evaluation with flexible fields, data output		
Filter	Echo filter, fog filter, particle filter, fixed average filter, glare filter		
Parameter cloning via system plug	Lite, PRO	Heavy Duty	–

- ¹⁾ Depending on the selected filter settings, scanning frequency, angular resolution and the object size.
²⁾ After what distance from the first echo full accuracy measurements can be taken again depends on the target that reflected the first echo.
 Ambient conditions: Good visibility, temperature range = 0 °C to 60 °C, remission = 10 to 20,000%, ambient brightness < 70 klux.

10.3 Interfaces

	LMS500	LMS511/LMS581	LMS531
Ethernet	TCP/IP, UDP/IP Function: Host/AUX, NTP Data transmission rate: 10/100 Mbit/s Standard IP address: 192.168.0.1		
Serial (RS-232, RS-422) ¹⁾	Function: Host/AUX Data transmission rate: 9.6 kBaud ... 500 kBaud Galvanic separation: yes Length of cable at 38.4 kBd and a cable cross-section of 0.25 mm ² : 15 m		
CAN-Bus ¹⁾	PRO, Heavy Duty Function: Output extension ¹⁾ Synchronization of data transmission rate: 20 kBit/s, 500 kBit/s, 1 MBit/s		
USB	Mini-USB Function: AUX		

	LMS500	LMS511/LMS581	LMS531
Digital inputs ¹⁾	Lite Quantity: 2 Function: Digital input		Lite Quantity: 3 Function: Digital input
	PRO, Heavy Duty Quantity: 4 Function: Digital input, encoder (HTL), synchronization		PRO, Heavy Duty Quantity: 4 Function: Digital input
	Input 1/2 Input voltage: 11 V ... 30 V Voltage for HIGH: 11 V ... 30 V Voltage for LOW: 0 V ... 5 V Input capacity: 15 nF Static input current: 6 mA ... 15 mA Input 3/4 Input voltage: 11 V ... 30 V Voltage for HIGH: 11 V ... 30 V Voltage for LOW: -3 V ... 5 V Input capacity: 1 nF Duty cycle (Ti/T): 0.5 Input frequency: 100 kHz Encoder HTL / dual-channel incremental encoder with 90° phase offset Speed range that can be sampled: from +100 mm/s to +20,000 mm/s From -100 mm/s to -20,000 mm/s Number of pulses per cm: At least 50 Recommended length of cable of the incremental encoder: max. 10 m		

	LMS500	LMS511/LMS581	LMS531
Digital outputs ¹⁾	Lite Quantity: 3 Function: Digital output		Lite Quantity: 3 Function: 2x relay, 1x digital output
	PRO, Heavy Duty Quantity: 6 Function: Digital output		PRO, Heavy Duty Quantity: 4 Function: Relay
	LMS500/511/531 digital outputs 1+2 ²⁾ Typ. Output voltage DC: $V_{SOUT} - 1,5 \text{ V}$ Max. switching current under continuous load: 0.25 A Internal resistance: $0.55 \Omega \dots 2.0 \Omega$ Maximum loss power: 500 mW LMS500/511 digital outputs 3-6 ³⁾ Typ. Output voltage DC: $V_{SOUT} - 2 \text{ V}$ Max. switching current: 100 mA LMS531 Lite digital output 3 ³⁾ Typ. DC output voltage: $V_{SOUT} - 2 \text{ V}$ Max. switching current: 100 mA LMS531 relay outputs Max. load voltage DC: 40 V Max. switching current under continuous load: 0.5 A Internal resistance: $0.34 \Omega \dots 0.7 \Omega$ Maximum loss power: 400 mW Output capacity: 450 pF Power-up delay: 1.3 ms ... 5 ms Switch-off time: 0.1 ms ... 0.5 ms Max. switching frequency: 5 Hz		
Optical indicators	5 LEDs (additional 7-segment display)		

¹⁾ Not applicable to LMS511 with Harting connector see "Connections of the LMS511 with Harting male connector", page 72.

²⁾ To increase the number of outputs, an extension module is required, which is available as an accessory.

³⁾ Outputs are short-circuit protected (no overload protection).

10.4 Mechanics/electronics

	LMS500	LMS511/ LMS581 ¹⁾	LMS531
Electrical connection	1 system plug with screw terminal 1 x Mini USB port behind a screw connection	4 x M12 round connectors ²⁾ 1 x Mini USB port behind a screw connection	
Electrical safety	According to IEC 61010-1:2010 as well as UL 61010-1:2012 / R:2015-07		
Supply voltage (V _S out)	24 V DC ± 20% SELV supply voltage according to IEC 60364-4-41		
Permissible residual ripple	± 5%		
Power consumption	P _{max} combined: 35 W P _{max} sensor: 22 W P _{max} heating: - P _{max} output: 13 W (total output of all OSSDs)	P _{max} combined: 95 W P _{max} sensor: 22 W P _{max} heating: 60 W P _{max} output: 13 W (total output of all OSSDs)	P _{max} combined: 83 W P _{max} sensor: 22 W P _{max} heating: 60 W P _{max} output: 1 W (total output of all OSSDs)

	LMS500	LMS511/ LMS581 ¹⁾	LMS531
Start-up current	The start-up current depends on the supply voltage and the length of cable. This will be a multiple of the continuous load current. Example: For 24 V on the device and a 5 m cable, the peak start-up current is approx. 14 A. The rise/fall time ratio is approx. 12 µs / 240 µs.		
Screw terminal	Rigid wire cross-circuit: 0.14 ... 1.5 mm ² Flexible wire cross-circuit: 0.14 ... 1.0 mm ² Stripping length of the wires: 5 mm Screw tightening torque 0.22 ... 0.3 Nm	–	
Housing material	AlSi12		
Housing color	Light blue (RAL 5012) Black (RAL 9005)	Grey (RAL 7032) Black (RAL 9005)	
Viewing window	Material: Polycarbonate, scratch-resistant coating on the exterior		
M12 round connector ²⁾	Lite, PRO: Brass, nickel-plated Heavy Duty: Stainless steel 1.4404 (V4A)		Lite: Brass, nickel-plated PRO, Heavy Duty: Stainless steel 1.4404 (V4A)
Enclosure rating	IP65 (EN 60529, Section 14.2.7)	IP65 (EN 60529, Section 14.2.7) IP67 (EN 60529, Section 14.2.7)	
Protection class	III (DIN EN 61140:2016-11)		
Weight	3.7 kg		
Dimensions	160 mm x 155 mm x 185 mm		

¹⁾ For connecting the sensor voltage supply, heating voltage supply, Ethernet. Suitable for Harting Han® 3 A RJ45 +4p type cable plug connector.

²⁾ Table content not applicable to LMS511 with Harting connector [see "Connections of the LMS511 with Harting male connector", page 72](#).

This variant comes with:

- 1x Harting connector, suitable for Harting Han® 3 A RJ45 +4p type cable plug; material zinc
- 1 x Mini USB port behind a screw connection

10.5 Ambient data

	LMS500	LMS511/LMS581	LMS531
Radiance factor	2% ... > 1,000% (reflectors ¹⁾)		
Electromagnetic compatibility (EMC) ²⁾	Radiation emitted: IEC 61000-6-3:2020 / EN 61000-6-3:2007+A1:2011 Electromagnetic immunity: IEC 61000-6-2:2016 / EN IEC 61000-6-2:2019		

	LMS500	LMS511/LMS581	LMS531
Chemical resistance	Salt spray test according to DIN EN ISO 9227 NSS: 2006-10-01 test duration: 240 h, test temperature: 35 °C, 5% NaCl solution Kesternich test according to DIN EN ISO 6988: 1997-3 - KFW 0.2 S test cycle duration: 24 h, number of cycles: 5, concentration: 0.067% SO2		
Vibration resistance	According to IEC 60068-2-6 (2007-12) 10 Hz ... 150 Hz: amplitude 0.35 mm to 5 g, 20 cycles		
Shock resistance	Single shock according to IEC 60068-2-27 (2008-02) 15 g, 11 ms, 6 shocks per axis continuous shock according to IEC 60068-2-27 (2008-02) 10 g, 16 ms, 1,000 shocks per axis		
Impact resistance	IK05, IK06, IK07 according to DIN EN 50102-09.1997		
Ambient operating temperature	0 °C ... +50 °C	LMS511 Lite/PRO, LMS531 Lite: -30 °C ... +50 °C Without heating, at switch-on: 0 °C ... +50 °C Without heating, during operation: -10 °C ... +50 °C ³⁾ LMS511 Heavy Duty, LMS531 PRO, LMS531 Heavy Duty: -40 °C ... +60 °C Without heating, at switch-on: 0 °C ... +60 °C Without heating, during operation: -10 °C ... +60 °C ³⁾	
Storage temperature	-40 °C ... +70 °C (max. 24 h)		
Relative humidity	Max. 95%, non-condensing according to DIN EN 60068-2-61, method 1		
Ambient light immunity	70 klx		

- ¹⁾ Corresponds to Diamond Grade 3000X™ (approx. 1,250 cd/lx × m²)
- ²⁾ This specification applies to all devices with hardware version II.
For all devices with hardware version I or an unspecified hardware version, the following applies:
- Radiation emitted: EN 61000-6-4:2007+A1:2011, IEC 61000-6-4:2018 / EN IEC 61000-6-4:2019
 - Electromagnetic immunity: EN 61000-6-2:2005+AC:2005, IEC 61000-6-2:2016 / EN IEC 61000-6-2:2019
- The hardware version of device can be found on the type designation label [see figure 6, page 20](#).
- ³⁾ When operating the device without heating, a warning message may occur due to no voltage supply for the heating being connected.

10.6 Dimensional drawings




Figure 71: Device dimensions LMS500; unit: mm (inch), decimal separator: period

- ① Area to be kept free while mounting the device: approx. 100 mm
- ② 2x cable glands for cables from 5-12 mm
- ③ 4x threaded mounting hole M8x9 (glued in with high-strength screw adhesive)
- ④ Minimum area to be kept free during operation of the device
- ⑤ 4x threaded mounting hole M6x8 (glued in with high-strength screw adhesive)
- ⑥ Horizontal measurement origin




Figure 72: LMS511 / LMS531 / LMS581 device dimensions; unit: mm (inch), decimal separator: period

- ① Area to be kept free while mounting the device: approx. 100 mm
- ② 4x M12 round connector
- ③ 4x threaded mounting hole M8x9 (glued in with high-strength screw adhesive)
- ④ Minimum area to be kept free during operation of the device
- ⑤ 4x threaded mounting hole M6x8 (glued in with high-strength screw adhesive)
- ⑥ Horizontal measurement origin

NOTE
Dimensional drawings of accessories such as mounting kits and protection hoods can be found on the product page.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

11 Accessories



NOTE

On the product page you will find accessories and, if applicable, related installation information for your product.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

Support Portal



NOTE

In the SICK Support Portal (support.sick.com) you will find, besides useful service and support information for your product, further detailed information on the available accessories and their use.

12 Annex

12.1 Declarations of conformity and certificates

You can download declarations of conformity and certificates via the product page.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

12.2 Telegram listing (EN)

Contents

12.2.1.1	About this document.....	120
12.2.1.1.1	Information on the telegram listing.....	120
12.2.1.1.2	Explanation of symbols.....	121
12.2.1.2	Communication format.....	121
12.2.1.2.1	Binary telegram (CoLa B).....	121
12.2.1.2.2	ASCII telegram (CoLa A).....	122
12.2.1.2.3	Variable types.....	122
12.2.1.2.4	Command basics.....	123
12.2.1.2.5	Log in: Required user level.....	124
12.2.1.3	Workflows.....	124
12.2.1.3.1	Parameterize the scan.....	124
12.2.1.3.2	Set timestamp/data angle.....	124
12.2.1.3.3	Common telegrams.....	125
12.2.1.4	Telegrams.....	126
12.2.1.4.1	Log in [sMN SetAccessMode]	126
12.2.1.4.2	Basic Settings.....	127
12.2.1.4.2.1	Set frequency and angular resolution/measurement sectors [sMN mLMPsetscancfg].....	128
12.2.1.4.2.2	Read for frequency and angular resolution [sRN LMPscancfg].....	131
12.2.1.4.2.3	Set scan configuration [sMN mCLsetscancfglist].....	132
12.2.1.4.2.4	Activate standby mode [sMN LMCstandby].....	135
12.2.1.4.2.5	Start measurement [sMN LMCstartmeas].....	135
12.2.1.4.2.6	Stop measurement [sMN LMCstopmeas].....	136
12.2.1.4.2.7	Autostart measurement [sWN LMPautostartmeas].....	137
12.2.1.4.2.8	Load factory defaults [sMN mSCloadfacdef].....	138
12.2.1.4.2.9	Load application defaults [sMN mSCloadappdef].....	139
12.2.1.4.2.10	Change password [sMN SetPassword].....	140
12.2.1.4.2.11	Check password [sMN CheckPassword].....	141
12.2.1.4.2.12	Set contamination measurement settings [sWN LCMcfg]....	142
12.2.1.4.2.13	Read contamination measurement settings [sRN LCMcfg]..	143
12.2.1.4.2.14	Read contamination measurement detailed values [sRN CMContLvIM].....	144
12.2.1.4.2.15	Read contamination status of the device [sRN LCMstate]...	145

12.2.1.4.2.16	Save parameters permanently [sMN mEEwriteall].....	146
12.2.1.4.2.17	Set to run [sMN Run].....	147
12.2.1.4.2.18	Reboot device [sMN mSCreboot].....	148
12.2.1.4.3	Measurement output telegram.....	148
12.2.1.4.3.1	Configure the data content for the scan [sWN LMDscanda- tacfg].....	148
12.2.1.4.3.2	Configure aperture angle of the scandata for output [sWN LMPoutputRange].....	150
12.2.1.4.3.3	Read for actual output range [sRN LMPoutputRange].....	152
12.2.1.4.3.4	Poll one telegram [sRN LMDscandata].....	153
12.2.1.4.3.5	Send data permanently [sEN LMDscandata].....	154
12.2.1.4.4	Time stamp.....	162
12.2.1.4.4.1	Set time synchronization [sWN TSCRole].....	162
12.2.1.4.4.2	Set time stamp [sMN LSPsetdatetime].....	163
12.2.1.4.4.3	Read time stamp and status of the measurement function [sRN STIm]s].....	165
12.2.1.4.4.4	Set NTP (Network Time Protocol) parameters.....	166
12.2.1.4.5	Filters.....	173
12.2.1.4.5.1	Set particle filter [sWN LFPparticle].....	173
12.2.1.4.5.2	Set average filter [sWN LFPmeanfilter].....	174
12.2.1.4.5.3	Set echo filter [sWN FREchoFilter].....	175
12.2.1.4.5.4	Set fog filter [sWN CLFogFilterEn].....	175
12.2.1.4.5.5	Read for enabled fog filter [sRN CLFogFilterEn].....	176
12.2.1.4.5.6	Set sensitivity fog filter [sWN MCSenseLevel].....	177
12.2.1.4.5.7	Activate/deactivate “fog filter operating radius active” [sWN FogFilterMaxRangeEnable].....	178
12.2.1.4.5.8	Execute the “Teach from 90° angle” button [sMN Teach- FogFilterMaxRange].....	179
12.2.1.4.5.9	Setting of the value “Fog filter operating radius active up to” [sWN FogFilterMaxRange].....	180
12.2.1.4.6	Encoder.....	181
12.2.1.4.6.1	Set increment source [sWN LICsrc].....	181
12.2.1.4.6.2	Set encoder settings [sWN LICencset].....	182
12.2.1.4.6.3	Set encoder resolution [sWN LICencres].....	182
12.2.1.4.6.4	Set fixed speed [sWN LICFixVel].....	183
12.2.1.4.6.5	Read speed threshold [sRN LICSpTh].....	184
12.2.1.4.6.6	Read encoder speed [sRN LICencsp].....	185
12.2.1.4.7	Inputs and Outputs.....	186
12.2.1.4.7.1	Read state of the ports [sRN LIDportstate].....	186
12.2.1.4.7.2	Read state of the inputs [sRN LIDinputstate].....	188
12.2.1.4.7.3	Read state of the outputs [sRN LIDoutputstate].....	189
12.2.1.4.7.4	Receive outputstate by event [sEN LIDoutputstate].....	190
12.2.1.4.7.5	Set output state [sMN mDOSetOutput].....	192
12.2.1.4.7.6	Change output 6/3 function [sWN DO6Fnc / DO3Fnc].....	193
12.2.1.4.7.7	Set synchronization mode [sWN SYMode].....	194
12.2.1.4.7.8	Set synchronization phase [sWN SYPhase].....	195
12.2.1.4.7.9	Change input 4 function [sWN DO3And4Fnc].....	196

12.2.1.4.7.10	Set debouncing time for input x [sWN DI3DebTim].....	196
12.2.1.4.7.11	Read status of external sync signal [sRN SYextmon].....	197
12.2.1.4.7.12	Reset output counter [sMN LIDrstoutpcnt].....	198
12.2.1.4.8	Status.....	199
12.2.1.4.8.1	Read firmware version [sRN DeviceIdent].....	199
12.2.1.4.8.2	Read the device state [sRN SCdevicestate].....	200
12.2.1.4.8.3	Read device order number [sRN DIornr].....	201
12.2.1.4.8.4	Read device type [sRN DItype].....	202
12.2.1.4.8.5	Read operating hours [sRN ODoprh].....	203
12.2.1.4.8.6	Read power on counter [sRN ODpwrc].....	204
12.2.1.4.8.7	Read temperature [sRN OPcurtmpdev].....	204
12.2.1.4.8.8	Set device name [sWN LocationName].....	205
12.2.1.4.8.9	Read device name [sRN LocationName].....	206
12.2.1.4.8.10	Read heating state [sRN OPheatstateext].....	207
12.2.1.4.9	Interfaces.....	208
12.2.1.4.9.1	Set IP address [sWN EIIPAddr].....	208
12.2.1.4.9.2	Read IP address [sRN EIIPAddr].....	209
12.2.1.4.9.3	Set Ethernet gateway [sWN Elgate].....	210
12.2.1.4.9.4	Read Ethernet gateway [sRN Elgate].....	211
12.2.1.4.9.5	Set IP mask [sWN Elmask].....	212
12.2.1.4.9.6	Read IP mask [sRN Elmask].....	213
12.2.1.4.9.7	Read MAC address [sRN EIMacAdr].....	214
12.2.1.4.9.8	Set baud rate for host interface [sWN SIHstBaud].....	215
12.2.1.4.9.9	Read baud rate of host interface [sRN SIHstBaud].....	216
12.2.1.4.9.10	Set interface type [sWN SIHstHw].....	217
12.2.1.4.9.11	Read interface type [sRN SIHstHw].....	218
12.2.1.4.9.12	Set Host/ UDP port number [sWN EIHstPort, sWN EIUDP-Port].....	218
12.2.1.4.9.13	Set Host port Command Language (CoLa dialect) [sWN EIHstCola].....	220
12.2.1.4.9.14	Enable/Disable Front Panel [sWN LMLfpn].....	221
12.2.1.4.9.15	Set function front panel [sWN LMLfpFcn].....	223
12.2.1.4.9.16	Set 7-segment display to specific symbol or number [sMN mLMLSetDisp].....	224
12.2.1.4.10	Application.....	226
12.2.1.4.10.1	Request status change of monitoring fields on event [sEN ECRChangeArr].....	226
12.2.1.4.10.2	Individual request of monitoring fields to their status changes – ECR xy [sRN ECRxy].....	229
12.2.1.4.10.3	Request SOPAS field data structure [sMN mLFEgetField]....	232
12.2.1.4.10.4	Request minimal and maximal perpendicular distance once [sRN LFEperpdistresult].....	237
12.2.1.4.10.5	Request minimal and maximal perpendicular distance continiously on event [sEN LFEperpdistresult].....	240
12.2.1.4.10.6	Request latest field infringement info [sRN LFEinfringementinfo].....	243

12.2.1.4.10.7	Request field infringement info continously on event [sEN LFEinfringementinfo].....	246
12.2.1.5	Diagnostics.....	248
12.2.1.5.1	SOPAS error codes.....	248

12.2.1.1 About this document

12.2.1.1.1 Information on the telegram listing



NOTE

In case you prefer to use complete drivers instead of single telegrams, the following options are available:

C++ drivers: https://github.com/SICKAG/sick_scan_xd

ROS drivers: https://github.com/SICKAG/sick_scan_xd

ROS2 drivers: https://github.com/SICKAG/sick_scan_xd



NOTE

Telegrams that are not described in this document for the device should not be implemented as they may either be incompatible or cause undesired effects.



NOTE

CoLa 2 is a SICK specific communication protocol which is used for communication between SICK devices and SICK specific tools and services only.

Please read this chapter carefully before beginning to use the telegram listing.

The telegram listing shows how to send telegrams via a terminal program using the SICK protocol CoLa A (ASCII and hexadecimal values, with TCP port 2111 or 2112) or CoLa B (binary/hexadecimal values, with TCP port 2112 only) to the device . This comprises the query of the current device state or certain parameter values, how to modify parameter values and the way in which the device confirms or responds to commands/telegrams.

The devices generally support automatic IP address discovery.

Default IP address is:

- 192.168.0.1

Subnet mask is 255.255.255.0.

IP ports:

- 2111: CoLa A (fixed)
- 2112: CoLa A (can be switched to CoLa B)
- 2213: UDP

The telegram listing does not or only in a few exceptional cases differentiate between individual device versions or sub product families such as LMS5xx Lite and LMS5xx PRO. Most parameter changes also require certain user levels. Additionally, commands may change during the product lifecycle and development process with a new firmware.

This document is based on the following firmware version (or newer):

- V2.30.1

If commands do not seem to work, please verify that your device version supports this functionality, that the minimum required user level has been selected and check on updates of this documentation.

12.2.1.1.2 Explanation of symbols



NOTE

... highlights useful tips and recommendations as well as information for efficient and trouble-free operation.



Telegram to device



Telegram from device



Unformatted example to copy and paste

12.2.1.2 Communication format

12.2.1.2.1 Binary telegram (CoLa B)

The binary telegram is a basic protocol of the scanner (CoLa B). All values are in hexadecimal code and grouped into pairs of two digits (= 1 byte). The string consists of four parts: header, data length, data and checksum (CS). It is highly recommended to use this protocol especially for measurement data, as the transmitted data amount is only about half as much as with CoLa A).

The header indicates with 4 × STX (02 02 02 02) the start of the telegram.

The data length defines the size of the data part (command part) by indicating the number of digit pairs in the third part. The size of the data length itself is 4 bytes, which means that the data part might have a maximum of $16^8 = 4,294,967,295$ digit pairs (bytes).

The data part comprises the actual command with letters and characters converted to Hex (according to the ASCII chart) and the parameters of either decimal numbers converted to Hex or fixed Hex values with a specific, intrinsic meaning (no conversion). There is always a space (20) between the command and the parameters, but not between the different parameter values.

The checksum finally serves to verify that the telegram has been transferred correctly. The length of the checksum is 1 byte, CRC8. It is calculated with XOR.

Table 52: Example: Binary telegram

02 02 02 02	00 00 00 17	73 4D 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 03 F4 72 47 44	B3
Header	Length	Data	CS

This is an example telegram for setting the user level “Authorized Client”:

- Header = 02 02 02 02
- Length = 23 bytes (17h)
- Data:
 - 73 4D 4E 20 = sMN = start of Sopas command (and space)
 - 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 = Set Access Mode = the actual command for setting the user level (and space)
 - 03 = fixed Hex value meaning user level “Authorized Client”
 - F4 72 47 44 = fixed Hex value, serving as password for the selected user level “Authorized Client”
- Checksum = B3 from XOR calculation

12.2.1.2.2 ASCII telegram (CoLa A)

The ASCII telegram is an alternative to the binary telegram, suitable especially to parametrize the sensor. However, due to the variable string length of ASCII telegrams, the Binary telegram is still recommended when using scanners with a PLC.

The ASCII telegram has the advantage that commands can be written in plaintext. The string consists only of two parts: the framing and the data part.

The framing indicates with <STX> and <ETX> the start and stop of each telegram.

The data part comprises the actual command with letters and characters (plaintext), parameter values either in decimal (special indicator required) or in hexadecimal (example: a frequency of 25 Hz = +2500 (decimal) = 09C4 (Hex)) and fixed hexadecimal values with a specific, intrinsic meaning.



NOTE

Leading zeros are deleted in ASCII. Therefore a space is always required between all command parts and parameter parts.

As further alternative within CoLa A, depending on the preferences of the user, all values can be written directly in Hex. This means however a 1:1 conversion of all letters and characters including numbers and fixed hexadecimal values via the ASCII chart.



NOTE

The device will confirm parameter values always in hexadecimal code, regardless of the code sent.

Table 53: Example: ASCII telegram

ASCII	<STX>	sMN{SPC}SetAccessMode{SPC}03{SPC}F4724744	<ETX>
Hex	02	73 4D 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 30 33 20 46 34 37 32 34 37 34 34	03
	Start	Data	Stop

This is again an example telegram for setting the user level “Authorized Client”. As only fixed hexadecimal parameter values are needed, the option to use parameter values in decimal code with special indicator cannot be applied here:

- Framing = <STX> = telegram start = 02 (Hex)
- Data:
 - sMN = start of Sopas command (and blank) = 73 4D 4E 20 (Hex)
 - SetAccessMode = the actual command for setting the user level (and blank) = 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 (Hex)
 - 03 = fixed Hex value meaning user level “Authorized Client” (and blank) = 30 33 20 (Hex)
 - F4 72 47 44 = fixed Hex value, serving as password for the selected user level “Authorized Client” = 46 34 37 32 34 37 34 34 (Hex)
- Framing = <ETX> = telegram stop = 03 (Hex)

12.2.1.2.3 Variable types

Variable type	Length (byte)	Value range	Sign
Bool_1	1	0 or 1	No
Uint_8	1	0 ... 255	No
Int_8	1	-128 ... +127	Yes
Uint_16	2	0 ... 65,535	No
Int_16	2	-32,768 ... +32,767	Yes

Variable type	Length (byte)	Value range	Sign
UInt_32	4	0 ... 4,294,967,295	No
Int_32	4	-2,147,483,648 ... +2,147,483,647	Yes
Enum_8	1	Certain values defined in a list of Choices (0 ... 255)	No
Enum_16	2	Certain values defined in a list of Choices (0 ... 65535)	No
String	Context-dependent	Strings are not terminated in zeroes	
FlexString	array of visible characters with preceeding current length (UInt length) (array of 8 bit)	See description of String and FlexArray	
Real	4	Float according to IEEE754 (see www.h-schmidt.net/FloatConverter/IEEE754de.html)	Yes

Data length is always given in Bytes!

Struct	A structure is a sequence of further types. These types can be of a Basic-Type, Structs again or an Array.
Array	An Array is a repetition of a type. The length of the array is defined with each Array. The types can be of a BasicType, a Struct or an Array again (n-dimensional).
Flex Array	A FlexArray is a repetition of a type with a variable length. The maximum length of the array is defined with each FlexArray. The current length of the FlexArray is transferred as a UInt preceeding the Array itself. The types can be of a BasicType, a Struct or an Array again (n-dimensional).

12.2.1.2.4

Command basics

SOPAS communication is a index based communication and can be identified with telegram beginning of: sRI, sWI, sMI, sAI, sEI, sSI. Since the parallel usage of one port might be confusing, the usage of separate ports is advised.

Every response telegram starts with a separat framed string:

<STX>sSI 2 1<ETX><STX>"Answer"<ETX>

Description	Value ASCII	Value Hex	Value Binary
Start of text	<STX>	02	02 02 02 02 + given length
End of text	<ETX>	03	Calculated checksum
Read	sRN	73 52 4E	
Write	sWN	73 57 4E	
Method	sMN	73 4D 4E	
Event	sEN	73 45 4E	
Answer	sRA sWA sAN sEA sSN	73 52 41 73 57 41 73 41 4E 73 45 41 73 53 4E	
Space	{SPC}	20	20

If values are divided into two parts (e.g. measurement data), they are documented according to LSB 0 (e.g. 00 07), output however is according to MSB (e.g. 07 00).

**NOTE**

Every write command (sWN) has a read (sRN) counter part even if it may not be described in the Telegram Listing. You can verify the current parameters this way, e.g. read the current IP address via `sRN EIIPAddr` see ["Read IP address \[sRN EIIPAddr\]", page 209](#).

12.2.1.2.5**Log in: Required user level**

Task	Required user level
Change sensor parameters	Authorized Client
Requests or queries (e.g. for measurement data or device state)	None
Manage passwords	Service

In general, every sWN command for changing parameters requires to log in to the device first see ["Log in \[sMN SetAccessMode\]", page 126](#). When being logged in, any desired parameter valid for this user level can be changed. All changes become active only after having logged off again from the device via the sMN Run command see ["Set to run \[sMN Run\]", page 147](#).

In this document, a required, specific user level is indicated in the telegram structure head line.

12.2.1.3 Workflows**12.2.1.3.1****Parameterize the scan**

Log in: `sMN SetAccessMode` see ["Log in \[sMN SetAccessMode\]", page 126](#)

Set frequency and resolution: `sMN mLMPsetscancfg` see ["Set frequency and angular resolution/measurement sectors \[sMN mLMPsetscancfg\]", page 128](#)

Configure scandata content: `sWN LMDscandatacfg` see ["Configure the data content for the scan \[sWN LMDscandatacfg\]", page 148](#)

Configure scandata output: `sWN LMPoutputRange` see ["Configure aperture angle of the scandata for output \[sWN LMPoutputRange\]", page 150](#)

Store parameters: `sMN mEEwriteall` see ["Save parameters permanently \[sMN mEE-writeall\]", page 146](#)

Log out: `sMN Run` see ["Set to run \[sMN Run\]", page 147](#)

Request scan:

`sRN LMDscandata` see ["Poll one telegram \[sRN LMDscandata\]", page 153](#)

`sEN LMDscandata` see ["Send data permanently \[sEN LMDscandata\]", page 154](#)

(Device output ...)

12.2.1.3.2**Set timestamp/data angle**

Log in: `sMN SetAccessMode` see ["Log in \[sMN SetAccessMode\]", page 126](#)

SOPAS command: `sMN LSPsetdatetime` see ["Set time stamp \[sMN LSPsetdatetime\]", page 163](#)

Log out: `sMN Run` see ["Set to run \[sMN Run\]", page 147](#)

12.2.1.3.3

Common telegrams

The following telegrams are valid for a wide range of non-safe LiDAR sensors from SICK. Please refer to the telegram listing of the respective device for a detailed description of all valid telegrams.

"Log in [sMN SetAccessMode]", page 126
"Set frequency and angular resolution/measurement sectors [sMN mLMpsetscancfg]", page 128
"Start measurement [sMN LMCstartmeas]", page 135
"Stop measurement [sMN LMCstopmeas]", page 136
"Load factory defaults [sMN mSCloadfacdef]", page 138
"Load application defaults [sMN mSCloadappdef]", page 139
"Change password [sMN SetPassword]", page 140
"Check password [sMN CheckPassword]", page 141
"Reboot device [sMN mSCreboot]", page 148
"Save parameters permanently [sMN mEEwriteall]", page 146
"Set to run [sMN Run]", page 147
"Configure the data content for the scan [sWN LMDscandatacfg]", page 148
"Configure aperture angle of the scandata for output [sWN LMPoutputRange]", page 150
"Read for actual output range [sRN LMPoutputRange]", page 152
"Poll one telegram [sRN LMDscandata]", page 153
"Send data permanently [sEN LMDscandata]", page 154
"Set particle filter [sWN LFPparticle]", page 173
"Read state of the inputs [sRN LIDinputstate]", page 188
"Read state of the outputs [sRN LIDoutputstate]", page 189
"Receive outputstate by event [sEN LIDoutputstate]", page 190
"Set output state [sMN mDOSetOutput]", page 192
"Read firmware version [sRN DeviceIdent]", page 199
"Read the device state [sRN SCdevicestate]", page 200
"Read device order number [sRN DIornr]", page 201
"Read device type [sRN DItype]", page 202
"Read operating hours [sRN ODoprh]", page 203
"Read power on counter [sRN ODpwr]", page 204
"Set device name [sWN LocationName]", page 205
"Read device name [sRN LocationName]", page 206
"Reset output counter [sMN LIDrstoutpcnt]", page 198
"Set IP address [sWN EIIpAddr]", page 208
"Read IP address [sRN EIIpAddr]", page 209
"Set Ethernet gateway [sWN Elgate]", page 210
"Read Ethernet gateway [sRN Elgate]", page 211
"Set IP mask [sWN Elmask]", page 212
"Read IP mask [sRN Elmask]", page 213
"Set Host/ UDP port number [sWN EIHstPort, sWN EIUDPPort]", page 218
"Set Host port Command Language (CoLa dialect) [sWN EIHstCola]", page 220

12.2.1.4 Telegrams

Telegrams listed in this document are described in the following basic structure:

Table 54: Telegram structure: "Command type" "Command"

Telegram structure: "Command type" "Command" (Minimum required user level. If nothing is stated, no user level required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Lists the different parts of the telegram.	Describes the corresponding telegram parts.	Defines the type of the variable.	Defines the length in byte.	Gives further information regarding the values in CoLa A/ CoLa B if necessary.	Defines the value of the telegram part in CoLa A (ASCII).	Defines the value of the telegram part in CoLa B (Binary).



NOTE

Commands are colored blue, parameters orange for further differentiation.

Table 55: Example: "Command type" "Command"

CoLa A	<"Start of text">"Command type value (ASCII)""space""Command value (ASCII)""space""Parameter value (ASCII)""space""Parameter value (ASCII)"<"End of text">	
	Copy example with framing (ASCII)	
	Copy example without framing (ASCII)	
	Copy example with framing (Hex)	
CoLa B	"Start of text and given length" "Command type value (Binary)""space""Command value (Binary)""space""Parameter value (Binary)""Parameter value (Binary)""Calculated checksum"	
	Copy example without framing (Binary)	

Table 56: Telegram structure: "Command type" "Command" (Answer)

Telegram structure: "Command type" "Command"						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Lists the different parts of the telegram.	Describes the corresponding telegram parts.	Defines the type of the variable.	Defines the length in byte.	Gives further information regarding the values in CoLa A/ CoLa B if necessary.	Defines the value of the telegram part in CoLa A (ASCII).	Defines the value of the telegram part in CoLa B (Binary).

Table 57: Example: "Command type" "Command" (Answer)

CoLa A	<"Start of text">"Command type value (ASCII)" "space" "Command value (ASCII)" "space" "Parameter value (ASCII)" "space" "Parameter value (ASCII)" <"End of text">					
	<"Start of text">"Command type value (Hex)" "space" "Command value (Hex)" "space" "Parameter value (Hex)" "space" "Parameter value (Hex)" <"End of text">					
CoLa B	"Start of text and given length" "Command type value (Binary)" "space" "Command value (Binary)" "space" "Parameter value (Binary)" "Parameter value (Binary)" "Calculated checksum"					

12.2.1.4.1 Log in [sMN SetAccessMode]



NOTE

- An automated hash-value calculator can be found in SOPAS ET under menu "password". Required userlevel 'Service' (see "Change password [sMN SetPassword]", page 140).

A log in to the device is necessary to change parameters. In most cases, the user level 'Authorized client' is needed. Changed parameters will be reset to the previous state via a reboot unless they are saved. To save parameter changes the command "sMN mEEwriteall" (see "Save parameters permanently [sMN mEEwriteall]", page 146) must be sent before log out.

Table 58: Telegram structure: sMN SetAccessMode

Telegram structure: sMN SetAccessMode						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	User level	String	13		SetAccessMode	53 65 74 41 63 63 65 73 73 4D 6F 64 65
User level	Select user level	Int_8	1	Maintenance: Authorized client: Service:	2 3 4	02 03 04
Password	Hash value for the selected user level	Uint_32	4	Maintenance: Authorized client: Service:	B21ACE26 F4724744 81BE23AA	B2 1A CE 26 F4 72 47 44 81 BE 23 AA

Table 59: Example: sMN SetAccessMode - Log in as "Authorized client" with password "F4724744"

CoLa A	<STX>sMN{SPC}SetAccessMode{SPC}3{SPC}F4724744<ETX>					
	<STX>sMN SetAccessMode 3 F4724744<ETX>					
	sMN SetAccessMode 3 F4724744					
	02 73 4D 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 30 33 20 46 34 37 32 34 37 34 34 03					
CoLa B	02 02 02 02 00 00 00 17 73 4D 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 03 F4 72 47 44 B3					
	73 4D 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 03 F4 72 47 44					

Table 60: Telegram structure: sAN SetAccessMode

Telegram structure: sAN SetAccessMode						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	User level	String	13		SetAccessMode	53 65 74 41 63 63 65 73 73 4D 6F 64 65
Change user level	Changed level	Bool_1	1	Error: Success:	0 1	00 01

Table 61: Example: sAN SetAccessMode

CoLa A	<STX>sAN{SPC}SetAccessMode{SPC}1<ETX>					
	02 73 41 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 31 03					
CoLa B	02 02 02 02 00 00 00 13 73 41 4E 20 53 65 74 41 63 63 65 73 73 4D 6F 64 65 20 01 38					

12.2.1.4.2 Basic Settings

12.2.1.4.2.1 Set frequency and angular resolution/measurement sectors [sMN mLMPsetscancfg]

NOTE
Please note that the new values will be activated only after log out (from the user level), when re-entering the Run mode (see "Set to run [sMN Run]", page 147).

NOTE
Start angle and stop angle are fixed values and not changeable only in the data output!

Coordination system:

(-5° to 185°), front = 90°




Table 62: Telegram structure: sMN mLMPsetscancfg

Telegram structure: sMN mLMPsetscancfg (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Configuration of scan frequency and angular resolution	String	14		mLMPsets-cancfg	6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67
Scan frequency	[1/100 Hz]	Uint_32	4	25 Hz: 35 Hz: 50 Hz: 75 Hz: 100 Hz:	+2500d (9C4h) +3500d (DACH) +5000d (1388h) +7500d (1D4Ch) +10000d (2710h)	00 00 09 C4 00 00 0D AC 00 00 13 88 00 00 1D 4C 00 00 27 10
Reserved	-	Int_16	2	Always:	+1 (0001h)	00 01

Telegram structure: sMN mLMPsetscancfg (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Angular resolution	[1/10000°]	Uint_32	4	0.042°: 0.083°: 0.1667°: 0.25°: 0.333°: 0.5°: 0.667°: 1°:	+0417d (01A1h) +0833d (0341h) +1667d (683h) +2500d (9C4h) +3333d (D05h) +5000d (1388h) +6667d (1A0Bh) +10000d (2710h)	00 00 01 A1 00 00 03 41 00 00 06 83 00 00 09 C4 00 00 0D 05 00 00 13 88 00 00 1A 0B 00 00 27 10
Start angle	[1/10000°] (Values are fixed)	Int_32	4	Fixed: -5°	-50000d (FFF3CB0h)	FF FF 3C B0
Stop angle	[1/10000°] (Values are fixed)	Int_32	4	Fixed: +185°	+1850000d (1C3A90h)	00 1C 3A 90

**NOTE**

For measurement data output at 0.083° and 0.042°:

- With an angular resolution of 0.083° or 0.042°, it is recommended to compensate the systematic error of the angular position. To calibrate the sensor in the system a correction table should be established in the customer's system software.
- This table ensures the mapping of an indicated angle in the scan data telegram on an angle in the real system environment.
- The calibration could be done, e.g. with a test object or with a reference scan on the system structure with known geometry. The table should comprise the complete field of view which is relevant for the application.

Example**NOTE**

Scan angle can not be changed here, only in the data output!




Figure 73: Example - 1 measurement sector of 190°

Table 63: Example: sMN mLMPsetscancfg - 50 Hz scan frequency, 0.5° angular resolution, -5° start angle (fixed), +185° stop angle (fixed)

CoLa A	<STX>sMN{SPC}mLMPsetscancfg{SPC}+5000{SPC}+1{SPC}+5000{SPC}-50000{SPC}+1850000<ETX> Alternatively: <STX>sMN{SPC}mLMPsetscancfg{SPC}1388{SPC}1{SPC}1388{SPC}FFFF3CB0{SPC}1C3A90<ETX>	
	<STX>sMN mLMPsetscancfg +5000 +1 +5000 -50000 +1850000<ETX> Alternatively: <STX>sMN mLMPsetscancfg 1388 1 1388 FFFF3CB0 1C3A90<ETX>	
	sMN mLMPsetscancfg +5000 +1 +5000 -50000 +1850000 Alternatively: sMN mLMPsetscancfg 1388 1 1388 FFFF3CB0 1C3A90	
	02 73 4D 4E 20 6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67 20 2B 35 30 30 30 20 2B 31 20 2B 35 30 30 30 20 2D 35 30 30 30 20 2B 31 38 35 30 30 30 03 Alternatively: 02 73 4D 4E 20 6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67 20 31 33 38 38 20 31 20 31 33 38 38 20 46 46 46 46 33 43 42 30 20 31 43 33 41 39 30 03	
CoLa B	02 02 02 02 00 00 00 25 73 4D 4E 20 6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67 20 00 00 13 88 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90 68	
	25 73 4D 4E 20 6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67 20 00 00 13 88 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90	

Table 64: Telegram structure: sAN mLMPsetscancfg

Telegram structure: sAN mLMPsetscancfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Info of scan frequency and angular resolution	String	14		mLMPsets-cancfg	6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67
Status code	Accepted when value is 0	Enum_8	1	No error: Frequency error: Resolution error: Resolution and scan area/ frequency error: Scan area error: Other errors:	0 1 2 3 4 5	00 01 02 03 04 05
Scan frequency	[1/100 Hz]	Uint_32	4	25 Hz: 35 Hz: 50 Hz: 75 Hz: 100 Hz:	9C4h DACH 1388h 1D4Ch 2710h	00 00 09 C4 00 00 0D AC 00 00 13 88 00 00 1D 4C 00 00 27 10
Reserved	-	Int_16	2	Always:	1h	00 01

Telegram structure: sAN mLMPsetscancfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Angular resolution	[1/10000°]	Uint_32	4	0.042°: 0.083°: 0.1667°: 0.25°: 0.333°: 0.5°: 0.667°: 1°:	01A1h 0341h 683h 9C4h D05h 1388h 1A0Bh 2710h	00 00 01 A1 00 00 03 41 00 00 06 83 00 00 09 C4 00 00 0D 05 00 00 13 88 00 00 1A 0B 00 00 27 10
Start angle	[1/10000°]	Int_32	4	Fixed: -5°	FFFF3CB0h	FF FF 3C B0
Stop angle	[1/10000°]	Int_32	4	Fixed: +185°	1C3A90h	00 1C 3A 90

Table 65: Example: sAN mLMPsetscancfg

	<STX>sAN{SPC}mLMPsetscancfg{SPC}0{SPC}1388{SPC}1{SPC}1388{SPC}FFFF3CB0{SPC}1C3A90<ETX>	
CoLa A	02 73 41 4E 20 6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67 20 30 20 31 33 38 38 20 31 20 31 33 38 38 20 46 46 46 46 33 43 42 30 20 31 43 33 41 39 30 03	
CoLa B	02 02 02 02 00 00 00 26 73 41 4E 20 6D 4C 4D 50 73 65 74 73 63 61 6E 63 66 67 20 00 00 00 13 88 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90 64	

12.2.1.4.2.2 Read for frequency and angular resolution [sRN LMPscancfg]

Read the scanning frequency, angular resolution and aperture angle of the device. Values show the information of the values before any filters are applied. Therefore aperture angle is always showing the maximum, scanning frequency and angular resolution may also be static depending on device family.

Table 66: Telegram structure: sRN LMPscancfg

Telegram structure: sRN LMPscancfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Info of scan frequency and angular resolution	String	10		LMPscancfg	4C 4D 50 73 63 61 6E 63 66 67

Table 67: Example: sRN LMPscancfg

CoLa A	<STX>sRN{SPC}LMPscancfg<ETX>	
	<STX>sRN LMPscancfg<ETX>	
	sRN LMPscancfg	
	02 73 52 4E 20 4C 4D 50 73 63 61 6E 63 66 67 03	
CoLa B	02 02 02 02 00 00 00 0E 73 52 4E 20 4C 4D 50 73 63 61 6E 63 66 67 63	
	73 52 4E 20 4C 4D 50 73 63 61 6E 63 66 67	

Table 68: Telegram structure: sRA LMPscancfg

Telegram structure: sRA LMPscancfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Info of scan frequency and angular resolution	String	10		LMPscancfg	4C 4D 50 73 63 61 6E 63 66 67
Scan frequency	[1/100 Hz]	Uint_32	4	25 Hz: 35 Hz: 50 Hz: 75Hz: 100 Hz:	9C4h DACH 1388h 1D4Ch 2710h 7D0h	00 00 09 C4 00 00 0D AC 00 00 13 88 00 00 1D 4C 00 00 27 10
Reserved	-	Int_16	2	Always:	1	00 01
Angular resolution	[1/10000°]	Uint_32	4	0.042°: 0.083°: 0.1667°: 0.25°: 0.333°: 0.5°: 0.667°: 1°:	1A1h 341h 683h 9C4h D05h 1388h 1A0Bh 2710h	00 00 01 A1 00 00 03 41 00 00 06 83 00 00 09 C4 00 00 0D 05 00 00 13 88 00 00 1A 0B 00 00 27 10
Start angle	[1/10000°]	Int_32	4	Fixed: -5°	FFFF3CB0h	FF FF 3C B0
Stop angle	[1/10000°]	Int_32	4	Fixed: +185°	1C3A90h	00 1C 3A 90

Table 69: Example: sRA LMPscancfg - 50 Hz scan frequency, 0.5° angular resolution, -5° start angle, +185° stop angle

	<STX>sRA{SPC}LMPscancfg{SPC}1388{SPC}1{SPC}1388{SPC}FFFF3CB0{SPC}1C3A90<ETX>
CoLa A	02 73 52 41 20 4C 4D 50 73 63 61 6E 63 66 67 20 31 33 38 38 20 31 20 31 33 38 38 20 46 46 46 46 33 43 42 30 20 31 43 33 41 39 30 03
CoLa B	02 02 02 02 00 00 00 21 73 52 41 20 4C 4D 50 73 63 61 6E 63 66 67 20 00 00 13 88 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90 77

12.2.1.4.2.3 Set scan configuration [sMN mCLsetscancfglist]

Sets the device to a defined scan configuration, consisting of scan frequency, angular resolution, sector definition and interlace mode with one parameter.

The interlace mode allows to achieve a higher angular resolution by combining scans with lower resolution. The individual scans are shifted to each other.

The command `mCLsetscancfglist` selects combinations of scan resolution, scan frequency and resolution. If the scan area will not match to the application then an adjustment is possible by the command `mLMPsetscancfg` (see "Set frequency and angular resolution/measurement sectors [sMN mLMPsetscancfg]", page 128).

Variant switching table:

Default is 190° field of view from -5 to 185°. Filtering have to be set via data transmission output.

Table 70: Interlace mode for sMN mCLsetscancfglist for LMS5xx

Mode in Hex	Mode in Dec	Interlaced	Scan freq.	Resolution
0	0	0x	25Hz	0,167°
1	1	0x	25Hz	0,25°
2	2	0x	35Hz	0,25°
3	3	0x	35Hz	0,5°
4	4	0x	50Hz	0,333°
5	5	0x	50Hz	0,5°
6	6	0x	75Hz	0,5°
7	7	0x	75Hz	1°
8	8	0x	100Hz	0,667°
9	9	0x	100Hz	1°
A	10	2x	50Hz	0,167°
B	11	2x	75Hz	0,25°
C	12	2x	100Hz	0,167°
D	13	2x	100Hz	0,333°
E	14	2x	100Hz	0,5°
F	15	2x	25Hz	0,083°
10	16	4x	25Hz	0,042°

**NOTE**

After sending this telegram, it will take 30 seconds to process the new configuration in the sensor.

**NOTE**

For measurement data output at 0.083° and 0.042°:

- With an angular resolution of 0.083° or 0.042°, it is recommended to compensate the systematic error of the angular position. To calibrate the sensor in the system a correction table should be established in the customer's system software.
- This table ensures the mapping of an indicated angle in the scan data telegram on an angle in the real system environment.
- The calibration could be done, e.g. with a test object or with a reference scan on the system structure with known geometry. The table should comprise the complete field of view which is relevant for the application.

Table 71: Telegram structure: sMN mCLsetscancfglist

Telegram structure: sMN mCLsetscancfglist (user level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sMN	73 4D 4E
Command	Set scan configuration	String	17		mCLsetscancfg-list	6D 43 4C 73 65 74 73 63 61 6E 63 66 67 6C 69 73 74

Telegram structure: sMN mCLsetscancfglist (user level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Mode	Scan configuration	Enum_8	1	25 Hz, 0.167° 25 Hz, 0.25° 35 Hz, 0.25° 35 Hz, 0.5° 50 Hz, 0.333° 50 Hz, 0.5° 75 Hz, 0.5° 75 Hz, 1.0° 100 Hz, 0.667° 100 Hz, 1.0° 50 Hz, 0.167° interl. 75 Hz, 0.25° interl. 100 Hz, 0.167° interl. 100 Hz, 0.333° interl. 100 Hz, 0.5° interl. 25 Hz, 0.083° interl. 100 Hz, 0.042° interl.	0d 1d 2d 3d 4d 5d 6d 7d 8d 9d 10d 11d 12d 13d 14d 15d 16d	00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10

Table 72: Example: sMN mCLsetscancfglist 5

CoLa A	<STX>sMN{SPC}mCLsetscancfglist{SPC}5<ETX>					
	<STX>sMN mCLsetscancfglist 5<ETX>					
	sMN mCLsetscancfglist 5					
	02 73 4D 4E 20 6D 43 4C 73 65 74 73 63 61 6E 63 66 67 6C 69 73 74 20 35 03					
CoLa B	02 02 02 02 00 00 00 17 73 4D 4E 20 6D 43 4C 73 65 74 73 63 61 6E 63 66 67 6C 69 73 74 20 05 0A					
	73 4D 4E 20 6D 43 4C 73 65 74 73 63 61 6E 63 66 67 6C 69 73 74 20 05					

Table 73: Telegram structure: sAN mCLsetscancfglist

Telegram structure: sAN mCLsetscancfglist						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Set scan configuration	String	17		mCLsetscancfglist	6D 43 4C 73 65 74 73 63 61 6E 63 66 67 6C 69 73 74
Status code	Result	Enum_8	1	Ok: Frequency error: Resolution error: Frequency and resolution combination error: Range error: General error:	0d 1d 2d 3d 4d 5d	00 01 02 03 04 05

Table 74: Example: sAN mCLsetscancfglist 0

CoLa A	<STX>sAN{SPC}mCLsetscancfglist{SPC}0<ETX>					
	02 73 41 4E 20 6D 43 4C 73 65 74 73 63 61 6E 63 66 67 6C 69 73 74 20 30 03					
CoLa B	02 02 02 02 00 00 00 14 73 41 4E 20 4F 50 68 65 61 74 73 74 61 74 65 65 78 74 20 00 03					

12.2.1.4.2.4 Activate standby mode [sMN LMCstandby]

Shut off the laser in order to extend the lifetime of laser diode and reduce motor speed to 25 Hz.

Table 75: Telegram structure: sMN LMCstandby

Telegram structure: sMN LMCstandby (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Set device to standby	String	10		LMCstandby	4C 4D 43 73 74 61 6E 64 62 79

Table 76: Example: sMN LMCstandby

CoLa A	<STX>sMN[SPC]LMCstandby<ETX>					
	<STX>sMN LMCstandby<ETX>					
	sMN LMCstandby					
	02 73 4D 4E 20 4C 4D 43 73 74 61 6E 64 62 79 03					
CoLa B	02 02 02 02 00 00 00 0E 73 4D 4E 20 4C 4D 43 73 74 61 6E 64 62 79 65					
	73 4D 4E 20 4C 4D 43 73 74 61 6E 64 62 79					

Table 77: Telegram structure: sAN LMCstandby

Telegram structure: sAN LMCstandby						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Set device to standby	String	10		LMCstandby	4C 4D 43 73 74 61 6E 64 62 79
Status code	Accepted when value is 0	Enum_8	1	Success: Not allowed:	0 1	00 01

Table 78: Example: sAN LMCstandby

CoLa A	<STX>sAN[SPC]LMCstandby[SPC]0<ETX>					
	02 73 41 4E 20 4C 4D 43 73 74 61 6E 64 62 79 20 30 03					
CoLa B	02 02 02 02 00 00 00 10 73 41 4E 20 4C 4D 43 73 74 61 6E 64 62 79 20 00 49					

12.2.1.4.2.5 Start measurement [sMN LMCstartmeas]

Start the laser and (unless in Standby mode) the motor of the device

Table 79: Telegram structure: sMN LMCstartmeas

Telegram structure: sMN LMCstartmeas (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E

Telegram structure: sMN LMCstartmeas (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Start measurement	String	12		LMCstartmeas	4C 4D 43 73 74 61 72 74 6D 65 61 73

Table 80: Example: sMN LMCstartmeas

CoLa A	<STX>sMN[SPC]LMCstartmeas<ETX>					
	<STX>sMN LMCstartmeas<ETX>					
	sMN LMCstartmeas					
	02 73 4D 4E 20 4C 4D 43 73 74 61 72 74 6D 65 61 73 03					
CoLa B	02 02 02 02 00 00 00 10 73 4D 4E 20 4C 4D 43 73 74 61 72 74 6D 65 61 73 68					
	73 4D 4E 20 4C 4D 43 73 74 61 72 74 6D 65 61 73					

Table 81: Telegram structure: sAN LMCstartmeas

Telegram structure: sAN LMCstartmeas						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Start measurement	String	12		LMCstartmeas	4C 4D 43 73 74 61 72 74 6D 65 61 73
Status code	Accepted when value is 0	Enum_8	1	Success: Not allowed:	0 1	00 01

Table 82: Example: sAN LMCstartmeas

CoLa A	<STX>sAN[SPC]LMCstartmeas[SPC]0<ETX>					
	02 73 41 4E 20 4C 4D 43 73 74 61 72 74 6D 65 61 73 20 30 03					
CoLa B	02 02 02 02 00 00 00 12 73 41 4E 20 4C 4D 43 73 74 61 72 74 6D 65 61 73 20 00 44					

12.2.1.4.2.6 Stop measurement [sMN LMCstopmeas]

Shut off the laser and the motor is running at the set up frequency.

Table 83: Telegram structure: sMN LMCstopmeas

Telegram structure: sMN LMCstopmeas (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Stop measurement	String	11		LMCstopmeas	4C 4D 43 73 74 6F 70 6D 65 61 73

Table 84: Example: sMN LMCstopmeas

CoLa A	<STX>sMN[SPC]LMCstopmeas<ETX>	
	<STX>sMN LMCstopmeas<ETX>	
	sMN LMCstopmeas	
	02 73 4D 4E 20 4C 4D 43 73 74 6F 70 6D 65 61 73 03	
CoLa B	02 02 02 02 00 00 00 0F 73 4D 4E 20 4C 4D 43 73 74 6F 70 6D 65 61 73 10	
	73 4D 4E 20 4C 4D 43 73 74 6F 70 6D 65 61 73	

Table 85: Telegram structure: sAN LMCstopmeas

Telegram structure: sAN LMCstopmeas						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Stop measurement	String	11		LMCstopmeas	4C 4D 43 73 74 6F 70 6D 65 61 73
Status code	Accepted when value is 0	Enum_8	1	No error: Not allowed:	0 1	00 01

Table 86: Example: sAN LMCstopmeas

CoLa A	<STX>sAN[SPC]LMCstopmeas[SPC]0<ETX>	
	02 73 41 4E 20 4C 4D 43 73 74 6F 70 6D 65 61 73 20 30 03	
CoLa B	02 02 02 02 00 00 00 11 73 41 4E 20 4C 4D 43 73 74 6F 70 6D 65 61 73 20 00 3C	

12.2.1.4.2.7 Autostart measurement [sWN LMPautostartmeas]

This parameter defines whether the scanner will start to rotate directly and measure when powering up or remain in idle mode. The changed setting (saved with the command `sMN mEEwriteall`, see "Save parameters permanently [sMN mEEwriteall]", page 146) will be then be active with the next power-up cycle.

In case autostart is deactivated, the sensor will remain in idle mode with the laser switched off and a motor speed of 25 Hz.

Table 87: Telegram structure: sWN LMPautostartmeas

Telegram structure: sWN LMPautostartmeas (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Autostart measurement	String	16		LMPautostart-meas	4C 4D 50 61 75 74 6F 73 74 61 72 74 6D 65 61 73
Status code	Activate / Deactivate Autostart	Bool_1	1	Autostart off: Autostart on:	0 1	00 01

Table 88: Example: sWN LMPautostartmeas 1

CoLa A	<STX>sWN{SPC}LMPautostartmeas{SPC}1<ETX>		
	<STX>sWN LMPautostartmeas 1<ETX>		
	sWN LMPautostartmeas 1		
	02 73 57 4E 20 4C 4D 50 61 75 74 6F 73 74 61 72 74 6D 65 61 73 20 31 03		
CoLa B	02 02 02 02 00 00 00 16 73 57 4E 20 4C 4D 50 61 75 74 6F 73 74 61 72 74 6D 65 61 73 20 01 4F		
	73 57 4E 20 4C 4D 50 61 75 74 6F 73 74 61 72 74 6D 65 61 73 20 01		

Table 89: Telegram structure: sWA LMDautostartmeas

Telegram structure: sWA LMPautostartmeas						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Autostart measurement	String	16		LMPautostart-meas	4C 4D 50 61 75 74 6F 73 74 61 72 74 6D 65 61 73

Table 90: Example: sWA LMPautostartmeas

CoLa A	<STX>sWA[SPC]LMPautostartmeas<ETX>		
	02 73 57 41 20 4C 4D 43 73 74 61 72 74 6D 65 61 73 03		
CoLa B	02 02 02 02 00 00 00 15 73 57 41 20 4C 4D 50 61 75 74 6F 73 74 61 72 74 6D 65 61 73 20 41		

12.2.1.4.2.8 Load factory defaults [sMN mSCloadfacdef]

**NOTE**

The Factory-Reset (Load factory defaults) deletes the entire parametrization of the device. All parameters, settings and system applications will be set to default. The Host port command language (CoLa dialect) will be set to CoLa A by default.

Table 91: Telegram structure: sMN mSCloadfacdef

Telegram structure: sMN mSCloadfacdef (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Load factory defaults	String	13		mSCloadfacdef	6D 53 43 6C 6F 61 64 66 61 63 64 65 66

Table 92: Example: sMN mSCloadfacdef

CoLa A	<STX>sMN[SPC]mSCloadfacdef<ETX>	
	<STX>sMN mSCloadfacdef<ETX>	
	sMN mSCloadfacdef	
	02 73 4D 4E 20 6D 53 43 6C 6F 61 64 66 61 63 64 65 66 03	

CoLa B	02 02 02 02 00 00 00 11 73 4D 4E 20 6D 53 43 6C 6F 61 64 66 61 63 64 65 66 28	
	73 4D 4E 20 6D 53 43 6C 6F 61 64 66 61 63 64 65 66	

Table 93: Telegram structure: sAN mSCloadfacdef

Telegram structure: sAN mSCloadfacdef					 	
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Load factory defaults	String	13		mSCloadfacdef	6D 53 43 6C 6F 61 64 66 61 63 64 65 66

Table 94: Example: sAN mSCloadfacdef

CoLa A	<STX>sAN{SPC}mSCloadfacdef<ETX>
	02 73 4D 4E 20 6D 53 43 6C 6F 61 64 66 61 63 64 65 66 03
CoLa B	02 02 02 02 00 00 00 12 73 41 4E 20 6D 53 43 6C 6F 61 64 66 61 63 64 65 66 20 04

12.2.1.4.2.9 Load application defaults [sMN mSCloadappdef]

**NOTE**

The Application-Reset (Load application defaults) deletes only the user parametrization of the Fields, Evaluation cases (EVC) and parameters under the header “Application”. Other parameters like Interface settings, Echo Filter, etc. remain unaffected.

Table 95: Telegram structure: sMN mSCloadappdef

Telegram structure: sMN mSCloadappdef (User level 'Authorized client' required)					 	
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Load application defaults	String	13		mSCloadappdef	6D 53 43 6C 6F 61 64 61 70 70 64 65 66

Table 96: Example: sMN mSCloadappdef

CoLa A	<STX>sMN{SPC}mSCloadappdef<ETX>					
	<STX>sMN mSCloadappdef<ETX>					
	sMN mSCloadappdef					
	02 73 4D 4E 20 6D 53 43 6C 6F 61 64 61 70 70 64 65 66 03					
CoLa B	02 02 02 02 00 00 00 11 73 4D 4E 20 6D 53 43 6C 6F 61 64 61 70 70 64 65 66 2D					
	73 4D 4E 20 6D 53 43 6C 6F 61 64 61 70 70 64 65 66					

Table 97: Telegram structure: sAN mSCloadappdef

Telegram structure: sAN mSCloadappdef						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Load application defaults	String	13		mSCloadappdef	6D 53 43 6C 6F 61 64 61 70 70 64 65 66

Table 98: Example: sAN mSCloadappdef

CoLa A	<STX>sAN{SPC}mSCloadappdef<ETX>
	02 73 41 4E 20 6D 53 43 6C 6F 61 64 61 70 70 64 65 66 03
CoLa B	02 02 02 02 00 00 00 12 73 41 4E 20 6D 53 43 6C 6F 61 64 61 70 70 64 65 66 20 01

12.2.1.4.2.10 Change password [sMN SetPassword]

Changing the log in password for a specific user level.



NOTE

If logged in with a higher user level you may set the password for lower user levels as well.

Table 99: Telegram structure: sMN SetPassword

Telegram structure: sMN SetPassword (Same user level or higher required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Set password request	String	13		SetPassword	53 65 74 50 61 73 73 77 6F 72 64
User level	User level that the password will be applied to	Int_8	1	Maintenance: Authorized client: Service:	2 3 4	02 03 04
Password	Hash value of the new password	Uint_32	4		<Hash value>	

Set password for 'Authorized client' to "testtest" (hash value = 1920E4C9).

Table 100: Example: sMN SetPassword

CoLa A	<STX>sMN{SPC}SetPassword{SPC}3{SPC}1920E4C9<ETX>					
	<STX>sMN SetPassword 3 1920E4C9<ETX>					
	sMN SetPassword 3 1920E4C9					
	02 73 4D 4E 20 53 65 74 50 61 73 73 77 6F 72 64 20 33 20 31 39 32 30 45 34 43 39 03					
CoLa B	02 02 02 02 00 00 00 15 73 4D 4E 20 53 65 74 50 61 73 73 77 6F 72 64 20 03 19 20 E4 C9 1A					
	73 4D 4E 20 53 65 74 50 61 73 73 77 6F 72 64 20 03 19 20 E4 C9					

Calculating the hash value of the password

- Login in SOPAS ET with user level "Service" to the device.
- Select [Device] > Password > Calculate Hash value.





Table 101: Telegram structure: sAN SetPassword

Telegram structure: sAN SetPassword						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Set password requested	String	13		SetPassword	53 65 74 50 61 73 73 77 6F 72 64
Success	Confirmation	Int_8	1	Failed: Success:	0 1	00 01

Table 102: Example: sAN SetPassword

CoLa A	<STX>sAN{SPC}SetPassword{SPC}1<ETX>					
	02 73 4D 4E 20 53 65 74 50 61 73 73 77 6F 72 64 20 01 03					
CoLa B	02 02 02 02 00 00 00 11 73 41 4E 20 53 65 74 50 61 73 73 77 6F 72 64 20 01 00					

12.2.1.4.2.11 Check password [sMN CheckPassword]

Check the password for a specific user level, e.g. to verify if it has been changed correctly.

Table 103: Telegram structure: sMN CheckPassword

Telegram structure: sMN CheckPassword (Same User level or higher required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Check password request	String	13		CheckPassword	43 68 65 63 6B 50 61 73 73 77 6F 72 64
User level	User level to check the password for	Int_8	1	Maintenance: Authorized client: Service:	2 3 4	02 03 04
Password	Hash value of the password to be checked	Uint_32	4		<Hash value>	

Check password "testtest" for 'Authorized client'.

Table 104: Example: sMN CheckPassword

CoLa A	<STX>sMN[SPC]CheckPassword[SPC]3[SPC]1920E4C9<ETX>	
	<STX>sMN CheckPassword 3 1920E4C9<ETX>	
	sMN CheckPassword 3 1920E4C9	
	02 73 4D 4E 20 43 68 65 63 6B 50 61 73 73 77 6F 72 64 20 33 20 31 39 32 30 45 34 43 39 03	
CoLa B	02 02 02 02 00 00 00 17 73 4D 4E 20 43 68 65 63 6B 50 61 73 73 77 6F 72 64 20 03 19 20 E4 C9 1E	
	73 4D 4E 20 43 68 65 63 6B 50 61 73 73 77 6F 72 64 20 03 19 20 E4 C9	

Table 105: Telegram structure: sAN CheckPassword

Telegram structure: sAN CheckPassword						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Check password request	String	13		CheckPassword	43 68 65 63 6B 50 61 73 73 77 6F 72 64
Success	Confirmation	Int_8	1	Failed: Success:	0 1	00 01

Table 106: Example: sAN CheckPassword

CoLa A	<STX>sAN[SPC]CheckPassword[SPC]1<ETX>	
	02 73 41 4E 20 43 68 65 63 6B 50 61 73 73 77 6F 72 64 20 31 03	
CoLa B	02 02 02 02 00 00 00 13 73 41 4E 20 43 68 65 63 6B 50 61 73 73 77 6F 72 64 20 01 04	

12.2.1.4.2.12 Set contamination measurement settings [sWN LCMcfg]

Define if and how early the device shall signal a potential contamination of the optics cover so that it may be cleaned preventively [see "Contamination measurement", page 31](#).

Table 107: Telegram structure: sWN LCMcfg

Telegram structure: sWN LCMcfg (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command		String	6		LCMcfg	4C 43 4D 63 66 67
Strategy	Strategy code	Enum_8	1	Inactive: High available Available: Sensitive: Semi-sensitive:	0 1 2 3 4	00 01 02 03 04
Response time	Time lapse	Uint_16	2		+1d ... +60d (01h ... 3Ch)	00 01 ... 00 3C
Threshold warning	Threshold value	Uint_16	2		0d ... +100d (00h ... 64h)	00 00 ... 00 64
Threshold error	Threshold value	Uint_16	2		0d ... +100d (00h ... 64h)	00 00 ... 00 64

Table 108: Example: sWN LCMcfg

CoLa A	<STX>sWN{SPC}LCMcfg{SPC}1{SPC}+30{SPC}+65{SPC}+45<ETX>					
	<STX>sWN LCMcfg 1 +30 +65 +45<ETX>					
	sWN LCMcfg 1 +30 +65 +45					
	02 73 57 4E 20 4C 43 4D 63 66 67 20 31 20 2B 33 30 20 2B 36 35 20 2B 34 35 03					
CoLa B	02 02 02 02 00 00 00 18 73 57 4E 20 4C 43 4D 63 66 67 20 01 00 1E 00 41 00 2D 39					
	73 57 4E 20 4C 43 4D 63 66 67 20 01 00 1E 00 41 00 2D					

Table 109: Telegram structure: sWA LCMcfg

Telegram structure: sWA LCMcfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command		String	6		LCMcfg	4C 43 4D 63 66 67

Table 110: Example: sWA LCMcfg

CoLa A	<STX>sWA{SPC}LCMcfg<ETX>					
	02 73 57 41 20 4C 43 4D 63 66 67 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 41 20 4C 43 4D 63 66 67 20 45					

12.2.1.4.2.13 Read contamination measurement settings [sRN LCMcfg]

Read which contamination measurement strategy is currently active [see "Contamination measurement", page 31](#).

Table 111: Telegram structure: sRN LCMcfg

Telegram structure: sRN LCMcfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command		String	6		LCMcfg	4C 43 4D 63 66 67

Table 112: Example: sRN LCMcfg

CoLa A	<STX>sRN{SPC}LCMcfg<ETX>					
	<STX>sRN LCMcfg<ETX>					
	sRN LCMcfg					
	02 73 52 4E 20 4C 43 4D 63 66 67 03					
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 4C 43 4D 63 66 67 6F					
	73 52 4E 20 4C 43 4D 63 66 67					

Table 113: Telegram structure: sRA LCMcfg

Telegram structure: sRA LCMcfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command		String	6		LCMcfg	4C 43 4D 63 66 67
Strategy	Strategy code	Enum_8	1	Inactive: High available: Available: Sensitive: Semi-sensitive:	0 1 2 3 4	00 01 02 03 04
Response time	Time lapse	Uint_16	2		+1d ... +60d (00h ... 3Ch)	00 00 ... 00 3C
Threshold warning	Threshold value	Uint_16	2		0d ... +100d (00h ... 64h)	00 00 ... 00 64
Threshold error	Threshold value	Uint_16	2		0d ... +100d (00h ... 64h)	00 00 ... 00 64

Table 114: Example: sRA LCMcfg

CoLa A	<STX>sRA[SPC]LCMcfg[SPC]1[SPC]1[SPC]1E[SPC]46<ETX>					
	02 73 57 41 20 4C 43 4D 63 66 67 20 31 20 31 20 31 45 20 34 36 03					
CoLa B	02 02 02 02 00 00 00 12 73 52 41 20 4C 43 4D 63 66 67 20 01 00 01 00 1E 00 46 18					

12.2.1.4.2.14 Read contamination measurement detailed values [sRN CMContLvIM]

Get the individual visibility levels in percentage values of all 7 measurement sensors along the optics cover.

Table 115: Telegram structure: sRN CMContLvIM

Telegram structure: sRN CMContLvIM						
Telegram part	Description	Variable	Length	Additional data	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command		String	10		CMContLvIM	43 4D 43 6F 6E 74 4C 76 6C 4D 6C

Table 116: Example: sRN CMContLvIM

CoLa A	<STX>sRN[SPC]CMContLvIM<ETX>					
	<STX>sRN CMContLvIM<ETX>					
	sRN CMContLvIM					
	02 73 52 4E 20 43 4D 43 6F 6E 74 4C 76 6C 4D 03					
CoLa B	02 02 02 02 00 00 00 0E 73 52 4E 20 43 4D 43 6F 6E 74 4C 76 6C 4D 6C					
	73 52 4E 20 43 4D 43 6F 6E 74 4C 76 6C 4D					

Table 117: Telegram structure: sRA CMContLvIM

Telegram structure: sRA CMContLvIM						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command		String	10		CMContLvIM	43 4D 43 6F 6E 74 4C 76 6C 4D
Contamination data for different channels	[% of transparency] in order of the different channels	Uint_8	1	Order of 6 channels: 5°/35°/70°/110°/145°/175°	0d ... +100d (00h ... 64h)	00 ... 64

5° - to 110°-channel: 100 %, 145° - and 175°-channel only 84 % availability:

Table 118: Example for LMS5xx: sRA CMContLvIM

CoLa A	<STX>sRA{SPC}CMContLvIM{SPC}64{SPC}64{SPC}64{SPC}64{SPC}54{SPC}54{SPC}<ETX> 02 73 52 41 20 43 4D 43 6F 6E 74 4C 76 6C 4D 20 64 64 64 64 54 54 03
CoLa B	02 02 02 02 00 00 00 15 73 52 41 20 43 4D 43 6F 6E 74 4C 76 6C 4D 20 64 64 64 64 54 54 43

12.2.1.4.2.15 Read contamination status of the device [sRN LCMstate]

Read the current result of the contamination measurement.

Table 119: Telegram structure: sRN LCMstate

Telegram structure: sRN LCMstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Status of LMS	String	8		LCMstate	4C 43 4D 73 74 61 74 65

Table 120: Example: sRN LCMstate

CoLa A	<STX>sRN{SPC}LCMstate<ETX>					
	<STX>sRN LCMstate<ETX>					
	sRN LCMstate					
	02 73 52 4E 20 4C 43 4D 73 74 61 74 65 03					
CoLa B	02 02 02 02 00 00 00 0C 73 52 4E 20 4C 43 4D 73 74 61 74 65 7A					
	73 52 4E 20 4C 43 4D 73 74 61 74 65					

Table 121: Telegram structure: sRA LCMstate

Telegram structure: sRA LCMstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41

Telegram structure: sRA LCMstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Status of LMS	String	8		LCMstate	4C 43 4D 73 74 61 74 65
Status code		Enum_8	1	No contamination: Contamination warning: Contamination error: Contamination measurement functionality defective:	0 1 2 3	00 01 02 03

Table 122: Example: sRA LCMstate

CoLa A	<STX>sRA{SPC}LCMstate{SPC}0<ETX>	
	02 73 52 41 20 4C 43 4D 73 74 61 74 65 20 30 03	
CoLa B	02 02 02 02 00 00 00 0E 73 52 41 20 4C 43 4D 73 74 61 74 65 20 00 55	

12.2.1.4.2.16 Save parameters permanently [sMN mEEwriteall]

Save all parameter changes of the device. Must be sent before logging off and/ or hardware rebooting of the device. Else all changes will be lost.

Table 123: Telegram structure: sMN mEEwriteall

Telegram structure: sMN mEEwriteall (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Store parameters permanently	String	11		mEEwriteall	6D 45 45 77 72 69 74 65 61 6C 6C

Table 124: Example: sMN mEEwriteall

CoLa A	<STX>sMN{SPC}mEEwriteall<ETX>	
	<STX>sMN mEEwriteall<ETX>	
	sMN mEEwriteall	
	02 73 4D 4E 20 6D 45 45 77 72 69 74 65 61 6C 6C 03	
CoLa B	02 02 02 02 00 00 00 0F 73 4D 4E 20 6D 45 45 77 72 69 74 65 61 6C 6C 21	
	73 4D 4E 20 6D 45 45 77 72 69 74 65 61 6C 6C	

Table 125: Telegram structure: sAN mEEwriteall

Telegram structure: sAN mEEwriteall						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Store parameters permanently	String	11		mEEwriteall	6D 45 45 77 72 69 74 65 61 6C 6C

Telegram structure: sAN mEEwriteall						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Status code	Accepted when value is 1	Bool_1	1	Error: Success:	0 1	00 01

Table 126: Example: sAN mEEwriteall

CoLa A	<STX>sAN{SPC}mEEwriteall{SPC}1<ETX>					
	02 73 41 4E 20 6D 45 45 77 72 69 74 65 61 6C 6C 20 31 03					
CoLa B	02 02 02 02 00 00 00 11 73 41 4E 20 6D 45 45 77 72 69 74 65 61 6C 6C 20 01 0C					

12.2.1.4.2.17 Set to run [sMN Run]

Log out from device and activate all parameter changes.

Table 127: Telegram structure: sMN Run

Telegram structure: sMN Run						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Start the device	String	3		Run	52 75 6E

Table 128: Example: sMN Run

CoLa A	<STX>sMN{SPC}Run<ETX>					
	<STX>sMN Run<ETX>					
	sMN Run					
	02 73 4D 4E 20 52 75 6E 03					
CoLa B	02 02 02 02 00 00 00 07 73 4D 4E 20 52 75 6E 19					
	73 4D 4E 20 52 75 6E					

Table 129: Telegram structure: sAN Run

Telegram structure: sAN Run						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Start the device	String	3		Run	52 75 6E
Status code	Accepted when value is 1	Bool_1	1	Error: Success:	0 1	00 01

Table 130: Example: sAN Run

CoLa A	<STX>sAN{SPC}Run{SPC}1<ETX>					
	02 73 41 4E 20 52 75 6E 20 31 03					
CoLa B	02 02 02 02 00 00 00 09 73 41 4E 20 52 75 6E 20 01 34					

12.2.1.4.2.18 Reboot device [sMN mSCreboot]

This command includes saving all parameters.

Table 131: Telegram structure: sMN mSCreboot

Telegram structure: sMN mSCreboot (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Reboot device	String	9		mSCreboot	6D 53 43 72 65 62 6F 6F 74

Table 132: Example: sMN mSCreboot

CoLa A	<STX>sMN{SPC}mSCreboot<ETX>																
	<STX>sMN mSCreboot<ETX>																
	sMN mSCreboot																
	02 73 4D 4E 20 6D 53 43 72 65 62 6F 6F 74 03																
CoLa B	02 02 02 02 00 00 00 0D 73 4D 4E 20 6D 53 43 72 65 62 6F 6F 74 2C																
	73 4D 4E 20 6D 53 43 72 65 62 6F 6F 74																

Table 133: Telegram structure: sAN mSCreboot

Telegram structure: sAN mSCreboot						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Reboot device	String	9		mSCreboot	6D 53 43 72 65 62 6F 6F 74

Table 134: Example: sAN mSCreboot

CoLa A	<STX>sAN{SPC}mSCreboot<ETX>				
	02 73 41 4E 20 6D 53 43 72 65 62 6F 6F 74 03				
CoLa B	02 02 02 02 00 00 00 0E 73 41 4E 20 6D 53 43 72 65 62 6F 6F 74 20 00				

12.2.1.4.3 Measurement output telegram

12.2.1.4.3.1 Configure the data content for the scan [sWN LMDscandatacfg]

Configuration of the channels (e.g. distance) and information that will be send by the device as measurement data (output data format).

 **NOTE**
For actually transmitting encoder values, the type of encoder has to be selected beforehand (see "Encoder", page 181).

Table 135: Telegram structure: sWN LMDscandatacfg

Telegram structure: sWN LMDscandatacfg (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Configure scandata	String	14		LMDscandatacfg	4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67
Data channel	Defines the telegram content (DIST)	Uint_8	2	Set via Echo Filter, therefore: Other values than 0 will be ignored.	0	00 00
RSSI	Enable or disable the output of RSSI values	Uint_8	1	RSSI disabled: RSSI enabled:	0 1	00 01
Resolution	Resolution of RSSI	Enum_8	1	8 Bit:	0	00
Unit	Unit of RSSI	Enum_8	1	Digits:	0	00
Encoder	Encoder data	Uint_8	2	No encoder: Channel 1:	0 0 1 0	00 00 01 00
Reserved	-	Bool_1	1	Always:	0	00
Device name	Sends the device name	Bool_1	1	No: Yes:	0 1	00 01
Reserved	-	Bool_1	1	Always:	0	00
Time	Sends time stamp information	Bool_1	1	No: Yes:	0 1	00 01
Output rate	Sends the output rate	Uint_16	2	All scans: Each 2 nd scan: Max. Each 50000 th scan:	+1d (1h) +2d (2h) +50000d (C350h)	00 01 00 02 C3 50

Example 1: RSSI enabled, resolution 8Bit, no encoder and all scans

Table 136: Example 1: sWN LMDscandatacfg

CoLa A	<STX>sWN{SPC}LMDscanda- tacfg{SPC}01{SPC}00{SPC}1{SPC}0{SPC}0{SPC}00{SPC}00{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0+1<ETX>	
	<STX>sWN LMDscandatacfg 01 00 1 0 0 00 00 0 0 0 0 +1<ETX>	
	sWN LMDscandatacfg 01 00 1 0 0 00 00 0 0 0 0 +1	
	02 73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 30 31 20 30 30 20 31 20 30 20 30 20 30 30 20 30 30 20 30 20 30 20 30 20 30 20 30 20 2B 31 03	
CoLa B	02 02 02 02 00 00 00 20 73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 01 00 01 00 00 00 00 00 00 00 00 00 01 43	
	73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 01 00 01 00 00 00 00 00 00 00 00 01	

Example 2: RSSI enabled, resolution 8Bit, no encoder and output rate each 10th scan

Table 137: Example 2: sWN LMDscandatacfg

CoLa A	<STX>sWN{SPC}LMDscanda- tacfg{SPC}01{SPC}00{SPC}1{SPC}0{SPC}0{SPC}00{SPC}00{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0+10<ETX>	
	<STX>sWN LMDscandatacfg 01 00 1 0 0 00 00 0 0 0 0 +10<ETX>	
	sWN LMDscandatacfg 01 00 1 0 0 00 00 0 0 0 0 +10	
	02 73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 30 31 20 30 30 20 31 20 30 20 30 20 30 30 20 30 30 20 30 20 30 20 30 20 30 20 30 20 2B 31 30 03	
CoLa B	02 02 02 02 00 00 00 20 73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 01 00 01 00 00 00 00 00 00 00 00 00 0A 48	
	73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 01 00 01 00 00 00 00 00 00 00 00 0A	

Example 3: RSSI disabled, resolution 8Bit, encoder active, each 10th scan

Table 138: Example3: sWN LMDscandatacfg

CoLa A	<STX>sWN{SPC}LMDscanda- tacfg{SPC}01{SPC}00{SPC}0{SPC}0{SPC}0{SPC}01{SPC}00{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}+10<ETX>	
	<STX>sWN LMDscandatacfg 01 00 0 0 0 01 00 0 0 0 0 +10<ETX>	
	sWN LMDscandatacfg 01 00 0 0 0 01 00 0 0 0 0 +10	
	02 73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 30 31 20 30 30 20 31 20 30 20 30 20 30 31 20 30 30 20 30 20 30 20 30 20 30 20 30 20 2B 31 30 03	
CoLa B	02 02 02 02 00 00 00 20 73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 01 00 00 00 00 01 00 00 00 00 00 00 0A 48	
	73 57 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 01 00 00 00 00 01 00 00 00 00 00 00 0A	

Table 139: Telegram structure: sWA LMDscandatacfg

Telegram structure: sWA LMDscandatacfg						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Configure scandata	String	14		LMDscandatacfg	4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67

Table 140: Example: sWA LMDscandatacfg

CoLa A	<STX>sWA{SPC}LMDscandatacfg<ETX>
	02 73 57 41 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 03
CoLa B	02 02 02 02 00 00 00 13 73 57 41 20 4C 4D 44 73 63 61 6E 64 61 74 61 63 66 67 20 4D

12.2.1.4.3.2 Configure aperture angle of the scandata for output [sWN LMPoutputRange]

Select start and stop angle of the measurement data output. In general only one output range can be configured.



NOTE

Verify the definition of the angle positions for your product.

Table 141: Telegram structure: sWN LMPoutputRange

Telegram structure: sWN LMPoutputRange (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional Details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Change output angle range	String	14		LMPoutputRange	4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65
Reserved	-	Int_16	2	Always:	1	00 01
Angular resolution ¹⁾	[1/10000°]	UInt_32	4	0.1667°: 0.25°: 0.333°: 0.5°: 0.667°: 1°:	+1667d (683h) +2500d (9C4h) +3333d (D05h) +5000d (1388h) +6667d (1A0Bh) +10000d (2710h)	00 00 06 83 00 00 09 C4 00 00 0D 05 00 00 13 88 00 00 1A 0B 00 00 27 10
Start angle	[1/10000°]	Int_32	4	Fixed: -5°	-50000d (FFFF3CB0h)	FF FF 3C B0
Stop angle	[1/10000°]	Int_32	4	Fixed: +185°	+1850000d (1C3A90h)	00 1C 3A 90

1) Angular resolution can not be changed here, it is taken automatically from the basic scan settings!

The angular resolution is not exactly 0.1667 degree, and this value should not be used for calculations. The result is an angular resolution of 1/6 of a degree (six measurements per degree). When used for calculations a customer should recover the real value, e.g. by double $\text{AngRes} = 2.0 / \text{round}(2.0 / \text{GivenAngRes})$.




Figure 74: Example - 1 measurement sector of 190°

Table 142: Example: sWN LMPoutputRange - set output data for angular resolution at 0.50° and range from -5° to 185°

CoLa A	<STX>sWN{SPC}LMPoutputRange{SPC}1{SPC}+5000{SPC}-50000{SPC}+1850000<ETX>	
	<STX>sWN LMPoutputRange 1 +5000 -50000 +1850000<ETX>	
	sWN LMPoutputRange 1 +5000 -50000 +1850000	
	02 73 57 4E 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 20 31 20 2B 35 30 30 30 20 2D 35 30 30 30 30 20 2B 31 38 35 30 30 30 03	
CoLa B	02 02 02 02 00 00 00 21 73 57 4E 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 20 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90 DB	
	73 57 4E 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 20 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90	

Table 143: Telegram structure: sWA LMPoutputRange

Telegram structure: sWA LMPoutputRange						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Change output angle range	String	14		LMPoutpu- tRange	4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65

Table 144: Example: sWA LMPoutputRange

CoLa A	<STX>sWA[SPC]LMPoutputRange<ETX>					
	02 73 57 41 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 03					
CoLa B	02 02 02 02 00 00 00 13 73 57 41 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 20 74					

12.2.1.4.3.3 Read for actual output range [sRN LMPoutputRange]

Read the defined angular resolution and current aperture angle for data output.

Table 145: Telegram structure: sRN LMPoutputRange

Telegram structure: sRN LMPoutputRange						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Output range	String	14		LMPoutpu- tRange	4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65

Table 146: Example: sRN LMPoutputRange

CoLa A	<STX>sRN[SPC]LMPoutputRange<ETX>					
	<STX>sRN LMPoutputRange<ETX>					
	sRN LMPoutputRange					
	02 73 52 4E 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 03					
CoLa B	02 02 02 02 00 00 00 12 73 52 4E 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 5E					
	73 52 4E 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65					

Table 147: Telegram structure: sRA LMPoutputRange

Telegram structure: sRA LMPoutputRange						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Output range	String	14		LMPoutpu- tRange	4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65

Telegram structure: sRA LMPoutputRange						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Reserved		Int_16	2	Always:	1h	00 01
Angular resolution	[1/10000°]	UInt_32	4	0.1667°: 0.25°: 0.333°: 0.5°: 0.667°: 1°:	683h 9C4h D05h 1388h 1A0Bh 2710h	00 00 06 83 00 00 09 C4 00 00 0D 05 00 00 13 88 00 00 1A 0B 00 00 27 10
Start angle	[1/10000°]	Int_32	4	Fixed: -5°	FFFF3CB0h	FF FF 3C B0
Stop angle	[1/10000°]	Int_32	4	Fixed: +185°	1C3A90h	00 1C 3A 90

Table 148: Example: sRA LMPoutputRange – device output set at 0.5° angular resolution and range from -5° to +185°

	<STX>sRA{SPC}LMPoutputRange{SPC}1{SPC}1388{SPC}FFFF3CB0{SPC}1C3A90<ETX>					
CoLa A	02 73 52 41 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 20 31 20 31 33 38 38 20 46 46 46 46 33 43 42 30 20 31 43 33 41 39 30 03					
CoLa B	02 02 02 02 00 00 00 21 73 52 41 20 4C 4D 50 6F 75 74 70 75 74 52 61 6E 67 65 20 00 01 00 00 13 88 FF FF 3C B0 00 1C 3A 90 D1					

12.2.1.4.3.4 Poll one telegram [sRN LMDscandata]

Asking the device for the measurement values of the last valid scan. The device will respond, even if currently no measurement data is created (e.g. due to standby or log in).

NOTE
After changing the scanning frequency, there will be no data telegram or answer from the device for up to 30 seconds. The same applies when the device is powering up or rebooting.

Table 149: Telegram structure: sRN LMDscandata

Telegram structure: sRN LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Only one telegram	String	11		LMDscandata	4C 4D 44 73 63 61 6E 64 61 74 61 61

Table 150: Example: sRN LMDscandata

CoLa A	<STX>sRN{SPC}LMDscandata<ETX>					
	<STX>sRN LMDscandata<ETX>					
	sRN LMDscandata					
	02 73 52 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 03					
CoLa B	02 02 02 02 00 00 00 0F 73 52 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 05					
	73 52 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61					

Table 151: Telegram structure: sRA LMDscandata

Telegram structure: sRA LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Find complete telegram structure of the answer in "Send data permanently [sEN LMDscandata]", page 154.						

12.2.1.4.3.5 Send data permanently [sEN LMDscandata]

Start/ stop continuous retrieval of measurement data from device. Data will be transmitted as configured in "Configure the data content for the scan [sWN LMDscandatacfg]", page 148 as soon as measurement data is generated by the device. No data is generated when there is an active log in, the laser is shut off (e.g. in Standby mode), the motor is stopped or in case of certain error modes (e.g. Device not ready).

NOTE
After changing the scanning frequency, there will be no data telegram or answer from the device for up to 30 seconds. The same applies when the device is powering up or rebooting.

Table 152: Telegram structure: sEN LMDscandata

Telegram structure: sEN LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Event	String	3		sEN	73 45 4E
Command	Data telegram	String	11		LMDscandata	4C 4D 44 73 63 61 6E 64 61 74 61
Measurement	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 153: Example: sEN LMDscandata

CoLa A	<STX>sEN{SPC}LMDscandata{SPC}1<ETX>					
	<STX>sEN LMDscandata 1<ETX>					
	sEN LMDscandata 1					
	02 73 45 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 20 31 03					
CoLa B	02 02 02 02 00 00 00 11 73 45 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 20 01 3C					
	73 45 4E 20 4C 4D 44 73 63 61 6E 64 61 74 61 20 01					

Table 154: Telegram structure: sEA LMDscandata

Telegram structure: sEA LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sEA	73 45 41
Command	Data telegram	String	11		LMDscandata	4C 4D 44 73 63 61 6E 64 61 74 61
Measurement	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 155: Example: Confirmation of sEA LMDscandata

CoLa A	<STX>sEA{SPC}LMDscandata{SPC}1<ETX>
	02 73 45 41 20 4C 4D 44 73 63 61 6E 64 61 74 61 20 31 03
CoLa B	02 02 02 02 00 00 00 11 73 45 41 20 4C 4D 44 73 63 61 6E 64 61 74 61 20 01 3C

Telegram stream

The answer to the telegram will be followed by the scandata:

Table 156: Telegram structure: Datastream of sRA LMDscandata/sSN LMDscandata

Telegram structure: sRA LMDscandata / sSN LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3	Answer to sRN LMDscandata: Answer to sEN LMDscandata:	sRA sSN	73 52 41 73 53 4E
Command	Data telegram	String	11		LMDscandata	4C 4D 44 73 63 61 6E 64 61 74 61
Version number	For detecting format changes by the version.	Uint_16	2		1h ... FFFFh	00 01 ... FF FF
Device						
Device number	Defined with SOPAS	Uint_16	2		0h ... FFFFh	00 00 ... FF FF
Serial number	Production period (year, calendar week, number): YYWWxxxx	Uint_32	4		0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
Device status	(See values column)	Uint_8	2 x 1	Ok: Error: Pollution warning: Pollution warning with device error: Pollution error with no device error: Pollution error with device error:	0 0 1 0 2 0 3 0 4 0 5 0	00 00 01 00 02 00 (00 10 00 00) 03 00 (00 11 00 00) 04 00 (01 00 00 00) 05 00 (01 01 00 00)
Status info						
Telegram counter	Number of measurement telegrams finished in the scanner and given to the interface. Does not count how many telegrams were really given out; is relevant if not all scans are delivered from the scan core.	Uint_16	2		0h ... FFFFh	00 00 ... FF FF
Scan counter	Number of scans which were created in the device; counts how many scans were really done.	Uint_16	2		0h ... FFFFh	00 00 ... FF FF

Telegram structure: sRA LMDscandata / sSN LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Time since start up in μ s	Counting the time since power up the device; starting with 0. In the output telegram this is the time at the zero index before the measurement itself starts.	Uint_32	4		0h ... FFFFFFFh	00 00 00 00 ... FF FF FF FF
Time of transmission in μ s	Time in μ s when the complete scan is transmitted to the buffer for data output; starting with 0 at scanner bootup.	Uint_32	4		0h ... FFFFFFFh	00 00 00 00 ... FF FF FF FF
Status of digital inputs	Low byte represents input 1.	Uint_8	2 x 1	All inputs low: All inputs high:	0 0 3 0	00 00 03 00
Status of digital outputs	Low byte represents output 1.	Uint_8	2 x 1	All outputs low: All internal outputs high: All outputs high (incl. Ext. Out):	0 0 3F 0 3F FF	00 00 3F 00 3F FF
Reserved	-	Uint_16	2	Always:	0	00 00 00 00
Frequencies						
Scan frequency	[1/100 Hz]	Uint_32	4	25 Hz: 35 Hz: 50 Hz: 75 Hz: 100 Hz:	9C4h DACH 1388h 1A0Bh 2710h	09 C4 0D AC 13 88 1A 0B 27 10
Measurement frequency	Inverse of the time between two measurement shots (in 100 Hz).	Uint_32	4	Example: 50 Hz, 0.5° (360/0.5)/(1/50) = 36 kHz	00000000h ... FFFFFFFh	00 00 00 00 ... FF FF FF FF
Encoder						
Amount of encoder	If 0, then next two telegram parts are missing.	Enum_16	2		0 ... 3	00 00 ... 00 03
Encoder position	Info in ticks	Uint_32	4	Only filled if parameter is activated	0h ... FFFFFFFh	00 00 00 00 ... FF FF FF FF
Encoder speed or milligrad/sec	mm/sec or milligrad/sec	Uint_16	2	Only filled if parameter is activated	0h ... FFFFh	00 00 ... FF FF
16 bit output channel (Distance)						
Amount of 16 bit channels	Number of 16 bit channels that provide measured data	Enum_16	2	Output channels	1 or 5	01 or 05
Content	Defines the content of the output channel Radial distance values (DIST) in mm	String	5	(with Software $\geq$ V1.10 only) Distance values of first pulse: Distance values of second pulse: Distance values of third pulse: Distance values of fourth pulse: Distance values of fifth pulse:	DIST1 DIST2 DIST3 DIST4 DIST5	44 49 53 54 31 44 49 53 54 32 44 49 53 54 33 44 49 53 54 34 44 49 53 54 35

Telegram structure: sRA LMDscandata / sSN LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Scale factor	Scale factor or factor of the measurement values (this depends on the angular resolution)	Real as float according to IEEE754	4	Factor x 1: Factor x 2:	3F800000h 40000000h	3F 80 00 00 40 00 00 00
Reserved	-	Real as float according to IEEE754	4	Always:	00000000	00 00 00 00
Start angle	[1/10000°]	Int_32	4	Fixed: -5°	FFFF3CB0h	FF FF 3C B0
Size of single angular step	Output format in degree: 1/10000°	Uint_16	2	(depends on the angular resolution see "Configure aperture angle of the scandata for output [sWN LMPoutputRange]", page 150)	683h ... 2710h	06 83 ... 27 10
Amount of data	Defines the number of items on measured output	Uint_16	2		0h ... FFFFh	00 00 ... FF FF
Data_1 Data_n	Data stream starting Data_1 to Data_n	Uint_16	2		0h ... FDE8h	00 00 00 00 ... 00 00 FD E8
8 bit output channel (RSSI)						
Amount of 8 bit channels	Number of 8 bit channels that provide measured data	Enum_16	2	Deactivated: Output channels:	0 1 or 5	00 01 or 05
Content	Defines the content of the output channel (RSSI)	String	5	(with Software ≥V1.10 only) Energy values of first pulse: Energy values of second pulse: Energy values of third pulse: Energy values of fourth pulse: Energy values of fifth pulse:	RSSI1 RSSI2 RSSI3 RSSI4 RSSI5	52 53 53 49 31 52 53 53 49 32 52 53 53 49 33 52 53 53 49 34 52 53 53 49 35
Scale factor	Scale factor of the RSSI values (this depends on the angular resolution)	Real as float according to IEEE754	4		3F800000h	3F 80 00 00
Reserved	-	Real as float according to IEEE754	4	Always:	00000000h	00 00 00 00
Start angle	Output format: [1/10000°]	Uint_32	4	Fixed: -5°	FFFF3CB0h	FF FF 3C B0
Size of single angular step	Output format: 1/10000°	Uint_16	2	(depends on the angular resolution see "Configure aperture angle of the scandata for output [sWN LMPoutputRange]", page 150)	683h ... 2710h	06 83 ... 27 10

Telegram structure: sRA LMDscandata / sSN LMDscandata						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Amount of data	Defines the number of items on measured output	Uint_16	2		0h ... FFFFh	00 00 ... FF FF
Data_1 Data_n	Data stream starting Data_1 to Data_n	Uint_8	1		00h ... FFh	00 ... FF
Reserved						
Reserved	-	Enum_16	2	Always:	0	00 00
Name						
Name	Device name	Enum_16	2	No device name defined: Device name defined:	0 1	00 00 00 01
Length	Length of name	Uint_16	2	Only filled if parameter is activated	0h ... Fh	00 ... 0F
Name	Device name in characters	String	16		20h ... 7Ah	20 ... 7A
Reserved						
Reserved	-	Enum_16	2	Always:	0	00 00
Time						
Time	Transmits a time stamp	Enum_16	2	No time: Time:	0 1	00 00 00 01
Year	1970 to 2037	Uint_16	2	Only filled if parameter is activated	7B2h ... 07F5h	07 B2 ... 07 F5
Month	1 to 12	Uint_8	1		0h ... Ch	00 ... 0C
Day	Day of month 1 to 31	Uint_8	1		0h ... 1Fh	00 ... 1F
Hour	0 to 23	Uint_8	1		0h ... 17h	00 ... 17
Minute	0 to 59	Uint_8	1		0h ... 3Bh	00 ... 3B
Second	0 to 59	Uint_8	1		0h ... 3Bh	00 ... 3B
Microsecond	0 to 999999	Uint_32	4		0h ... F423Fh	00 00 00 00 ... 00 0F 42 3F
Reserved						
Reserved	-	Uint_16	2	Always:	0	00 00

LMDscandata - reserved values

Valid distance measurement values are values starting from 16d upwards; everything below has the following meaning:

DIST	RSSI	Description
0d	0h	Invalid measurement value; caused by very low remission (extremely dark object), object distance not within measurement range (too close or too far away) or selected filter settings at device
1d	FFFFh (16Bit output) FFh (8Bit output)	Invalid measurement value, device was dazzled or blinded, e.g. by measuring into the sun
2d	0h	Implausible measurement values (not used for LMS5xx)
3d	0h	Value was set to invalid by a filter (Echo Filter, Particle Filter) (not used for LMS5xx)
4d – 15d	0h	Reserved, currently not in use
≥16d	>0h	Valid measurement values

max. measurement value: Dez: 65 000 mm → Hex: FDE8

max. measurement value: Dez: 80 000 mm → Hex: 9C40 with scale factor 2 → 13880

max. measurement value: Dez: 130 000 mm → Hex: FDE8 with scale factor 2 → 1F8D0

Higher measurement values will be given out with a zero, that means no measurement value detected.

Calculation and amount of data

Example how to calculate the amount of data for a measurement telegram.

Sizes of values and telegram parts:

- one measurement value: 5 byte (4 byte value itself, 1 byte space after the value)
- one RSSI value: 3 byte (2 byte value itself, 1 byte space after the value)
- telegram header: 81 byte
- telegram end: 12 byte

Calculation of number of Measurement values depends always on the resolution:

$0.5^\circ = 2$ measurements per degree

$0.25^\circ = 4$ measurements per degree

Always one additional measurement for the last measurement

Number of measurement values = Number of degrees × measurements per degree + 1

Example for measurement of 56° in 0.5° resolution (without RSSI data):

$56 \times 2 + 1 = 113$ Measurement values

Amount of Data for these measurement values:

$113 \times 5 \text{ Byte} = 565 \text{ Byte}$

Calculation of amount of data per telegram:

Data of one Telegram = Header + Measurements + end of telegram

81 Byte + 113 Measurements + 12 Byte

81 Byte + $(113 \times 5 \text{ Byte}) + 12 \text{ Byte} = 658 \text{ Byte per Telegram} (= 5264 \text{ Bit} (658 \times 8 \text{ Bit}))$

Possible amount for delivery with special Speed:

Number of telegrams per second = Speed ÷ telegram size

Speed Example:

$115200 \text{ Bit/s} = 11520 \text{ Byte/s} = 11,52 \text{ Byte/s}$

$11520 \text{ (Byte/s)} \div 658 \text{ Byte} = 17,5 \text{ Telegrams/s}$

Telegram size with 0.25° resolution:

Degrees: 270°

Resolution: 0.25°

Measurement values = $270 \times 4 + 1 = 1081$

Data per telegram = 81 Byte + $(1081 \times 5 \text{ Byte}) + 12 \text{ Byte} = 5498 \text{ Byte} (= 43984 \text{ Bit})$

Telegram size with 0.5° resolution:

Degrees: 270°

Resolution: 0.5°

Measurement values = $270 \times 2 + 1 = 541$

Data per telegram = 81 Byte + $(541 \times 5 \text{ Byte}) + 12 \text{ Byte} = 2798 \text{ Byte} (= 22384 \text{ Bit})$

As a result in that configuration a 10 MBit connection will not be enough. With a 100 MBit Hub, 3-4 scanner can be used, with a 1 GBit Hub accordingly more.

Example of a telegram stream

Table 157: Telegram structure: sRA LMDscandata (Example)

Telegram structure: sRA LMDscandata (Example)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRA	73 52 41

Telegram structure: sRA LMDscandata (Example)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Data telegram	String	11		LMDscandata	4C 4D 44 73 63 61 6E 64 61 74 61
Version number	For detecting format changes by the version	Uint_16	2		1	00 01
Device						
Device number	Defined with SOPAS	Uint_16	2		1	00 01
Serial number	Production period (year, calendar week, number): YYWWxxxx	Uint_32	4		89A27Fh	00 89 A2 7F
Device status	(See values column)	Uint_8	2 x 1	Ok:	0 0	00 00
Status info						
Telegram counter	Number of measurement telegrams finished in the scanner and given to the interface. Does not count how many telegrams were really given out; is relevant if not all scans are delivered from the scan core.	Uint_16	2		343h	03 43
Scan counter	Number of scans which were created in the device; counts how many scans were really done.	Uint_16	2		347h	03 47
Time since start up in μ s	Counting the time since power up the device; starting with 0. In the output telegram this is the time at the zero index before the measurement itself starts.	Uint_32	4		27477BA9h	27 47 7B A9
Time of transmission in μ s	Time in μ s when the complete scan is transmitted to the buffer for data output; starting with 0 at scanner bootup.	Uint_32	4		2747813Bh	27 47 81 3B
Status of digital inputs	Low byte represents input 1.	Uint_8	2 x 1		0 0	00 00
Status of digital outputs	Low byte represents output 1.	Uint_8	2 x 1	Corresponds to status 0111	7 0	07 00
Reserved	-	Uint_16	2	Always:	0	00 00
Frequencies						

Telegram structure: sRA LMDscandata (Example)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Scan frequency	[1/100 Hz]	Uint_32	4	5000/100 = 50 Hz	1388h	00 00 13 88
Measurement frequency	Inverse of the time between two measurement shots (in 100 Hz). Example: 50 Hz, 0.5° resolution → 720 shots/20 ms → 36 kHz Example: 12.5 Hz, 0.04° resolution → 9000 shots/80 ms → 112.5 kHz	Uint_32	4		168h	00 00 01 68
Encoder						
Amount of encoder	If 0, then next two values are missing.	Enum_16	2	No encoder data	0	00 00
16 bit output channel (Distance)						
Amount of 16 bit channels	Number of 16 bit channels that provide measured data	Enum_16	2		1	00 01
Content	Defines the content of the output channel Unit of radial distance values (DIST) is mm	String	5		DIST1	44 49 53 54 31
Scale factor	Scale factor or factor of the measurement values (this depends on the angular resolution)	Real as float according to IEEE754	4	Floating Point: Value = 1	3F800000h	3F 80 00 00
Reserved	-	Real as float according to IEEE754	4	Always:	00000000	00 00 00 00
Start angle	[1/10000°]	Uint_32	4	100000/10000 = 10°	186A0h	00 01 86 A0
Size of single angular step	Output format in degree: 1/10000°	Uint_16	2	5000/10000 = 0.5° 400/10000 = 0.04°	1388 h	13 88
Amount of data	Defines the number of items on measured output	Uint_16	2	21 Measurement points	15h	00 15
Data_1 Data_21	Data stream starting Data_1 to Data_21	Uint_16	2	Measurement data Min. 22 mm: 16h Max. 20000 mm: 4E20h	8A1 8A5 8AB 8AC 8A6 8AC 8B6 8C8 8C2 8C9 8CB 8C4 8E4 8E1 8EB 8E0 8F5 908 8FC 907 906	08 A1 08 A5 08 AB 08 AC 08 A6 08 AC 08 B6 08 C8 08 C2 08 C9 08 CB 08 C4 08 E4 08 E1 08 EB 08 E0 08 F5 09 08 08 FC 09 07 09 06
8 bit output channel (RSSI)						

Table 160: Example: sWN TSCRole

CoLa A	<STX>sWN{SPC}TSCRole{SPC}1<ETX>					
	<STX>sWN TSCRole 1<ETX>					
	sWN TSCRole 1					
	02 73 57 4E 20 54 53 43 52 6F 6C 65 20 31 03					
CoLa B	02 02 02 02 00 00 00 0D 73 57 4E 20 54 53 43 52 6F 6C 65 20 01 1B					
	73 57 4E 20 54 53 43 52 6F 6C 65 20 01					

Table 161: Telegram structure: sWA TSCRole

Telegram structure: sWA TSCRole						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set NTP role	String	7		TSCRole	54 53 43 52 6F 6C 65

Table 162: Example: sWA TSCRole

CoLa A	<STX>sWA{SPC}TSCRole<ETX>					
	02 73 57 41 20 54 53 43 52 6F 6C 65 03					
CoLa B	02 02 02 02 00 00 00 0C 73 57 41 20 54 53 43 52 6F 6C 65 20 15					

12.2.1.4.4.2 Set time stamp [sMN LSPsetdatetime]

The data format in the telegram is: +2009{SPC}+7{SPC}+22{SPC}+12{SPC}+0{SPC}+0{SPC}+0.

The numbers represent year, month, day, hour, minute, second, microsecond.

If plus is used up-front the data it is interpreted as an integer decimal number, without the plus it's the scanner reads the data as hex format.

The answer is always in ASCII format.



NOTE

There is no real time clock inside the device. When the scanner is switched off and after a reboot, the time has to be set again. However, it is possible to analyze the Off-time in order to evade this issue.

Table 163: Telegram structure: sMN LSPsetdatetime

Telegram structure: sMN LSPsetdatetime (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Set time stamp	String	14		LSPsetdatetime	4C 53 50 73 65 74 64 61 74 65 74 69 6D 65
Year		Uint_16	2		+1970d ... +2099d (07B2h ... 0833h)	07 B2 ... 08 33

Telegram structure: sMN LSPsetdatetime (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Month		Uint_8	1		+1d ... +12d (01h ... 0Ch)	01 ... 0C
Day		Uint_8	1		+1d ... +31d (01h ... 1Fh)	00 ... 1F
Hour		Uint_8	1		+0d ... +23d (00h ... 17h)	00 ... 17
Minute		Uint_8	1		+0d ... +59d (00h ... 3Bh)	00 ... 3B
Second		Uint_8	1		+0d ... +59d (00h ... 3Bh)	00 ... 3B
Microsecond		Uint_32	4		+0d ... +999999d (00000000h ... 000F423Fh)	00 00 00 00 ... 00 0F 42 3F

Table 164: Example 1: sMN LSPsetdatetime

CoLa A	<STX>sMN{SPC}LSPsetdatetime{SPC}7D9{SPC}2{SPC}11{SPC}10{SPC}22{SPC}0{SPC}0<ETX>	
	<STX>sMN LSPsetdatetime 7D9 2 11 10 22 0 0<ETX>	
	sMN LSPsetdatetime 7D9 2 11 10 22 0 0	
	02 73 4D 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 37 44 39 20 32 20 31 31 20 31 30 20 32 32 20 30 20 30 03	
CoLa B	02 02 02 02 00 00 00 1E 73 4D 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 07 D9 02 11 10 22 00 00 00 00 00 A3	
	73 4D 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 07 D9 02 11 10 22 00 00 00 00 00	

Table 165: Example 2: sMN LSPsetdatetime

CoLa A	<STX>sMN{SPC}LSPsetdatetime{SPC}+2010{SPC}+01{SPC}+26{SPC}+10{SPC}+35{SPC}0{SPC}0<ETX>	
	<STX>sMN LSPsetdatetime +2010 +01 +26 +10 +35 0 0<ETX>	
	sMN LSPsetdatetime +2010 +01 +26 +10 +35 0 0	
	02 73 4D 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 2B 32 30 31 30 20 2B 30 31 20 2B 32 36 20 2B 31 30 20 2B 33 35 20 2B 30 30 20 2B 30 30 30 03	
CoLa B	02 02 02 02 00 00 00 1E 73 4D 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 07 DA 01 1A 0A 23 00 00 00 00 00 A3	
	73 4D 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 07 DA 01 1A 0A 23 00 00 00 00 00	

Table 166: Telegram structure: sAN LSPsetdatetime

Telegram structure: sAN LSPsetdatetime						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Set time stamp	String	14		LSPsetdatetime	4C 53 50 73 65 74 64 61 74 65 74 69 6D 65

Telegram structure: sAN LSPsetdatetime						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Status code	Code number	Enum_8	1	Success:	0	00

Table 167: Example 1, 2: sAN LSPsetdatetime

CoLa A	<STX>sAN{SPC}LSPsetdatetime{SPC}0<ETX>					
	02 73 41 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 30 03					
CoLa B	02 02 02 02 00 00 00 14 73 41 4E 20 4C 53 50 73 65 74 64 61 74 65 74 69 6D 65 20 00 50					

Activate time stamp in the output string format or on SOPAS page “data processing”.

12.2.1.4.4.3 Read time stamp and status of the measurement function [sRN STlms]

Table 168: Telegram structure: sRN STlms

Telegram structure: sRN STlms						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Status and time	String	5		STlms	53 54 6C 6D 73

Table 169: Example: sRN STlms

CoLa A	<STX>sRN{SPC}STlms<ETX>					
	<STX>sRN STlms<ETX>					
	sRN STlms					
	02 73 52 4E 20 53 54 6C 6D 73 03					
CoLa B	02 02 02 02 00 00 00 09 73 52 4E 20 53 54 6C 6D 73 3A					
	73 52 4E 20 53 54 6C 6D 73					

Table 170: Telegram structure: sRA STlms

Telegram structure: sRA STlms						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Status and time	String	5		STlms	53 54 6C 6D 73
Status code	Status of the measurement function.	Enum_16	2	Boot cycle: Ready: Measurement active: FW Update: Error:	0 ... 5 6 7 8 10	00 00 ... 00 05 00 06 00 07 00 08 00 0A
Reserved	-	Uint_8	1	Always:	0	00

Telegram structure: sRA STlms						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Length of time parameter		Uint_16	2		0d ... +65535d (00h ... FFFFh)	00 00 ... FF FF
Time	HH HH	Uint_16	2		0d ... 99d	00 00 ... 00 63
	:	Uint_8	1		:	3A
	MM MM	Uint_16	2		0d ... 99d	00 00 ... 00 63
	:	Uint_8	1		:	3A
	SS SS	Uint_16	2		0d ... 99d	00 00 ... 00 63
Length of date parameter		Uint_16	2		0d ... +65535d (00h ... FFFFh)	00 00 ... FF FF
Date	DD DD	Uint_16	2		0d ... 99d	00 00 ... 00 63
	.	Uint_8	1		.	2E
	MM MM	Uint_16	2		0d ... 99d	00 00 ... 00 63
	.	Uint_8	1		.	2E
	YY YY YY YY	Uint_32	4		0d ... 9999d	00 00 00 00 ... 00 00 27 0F
LED1		Uint_16	2	Inactive: Active:	0 1	00 00 00 01
LED2		Uint_16	2	Inactive: Active:	0 1	00 00 00 01
LED3		Uint_16	2	Inactive: Active:	0 1	00 00 00 01
Reserved	-	Uint_16	3 × 2	Always:	0 0 0	00 00 00 00 00 00

Table 171: Example: sRA STlms

CoLa A	<STX>sRA{SPC}STlms{SPC}7{SPC}0{SPC}8{SPC}16:36:54{SPC}10{SPC}17.03.2030{SPC}0{SPC}0{SPC}0<ETX>
CoLa B	02 02 02 02 00 00 00 2F 73 52 41 20 53 54 6C 6D 73 20 00 07 00 00 08 00 10 3A 00 24 3A 00 36 00 0A 00 11 2E 00 03 2E 00 00 07 EE 00 00 00 00 00 00 00 00 00 00 00 17

12.2.1.4.4.4 Set NTP (Network Time Protocol) parameters

12.2.1.4.4.4.1 Set time synchronization interface [sWN TSCTCInterface]

Define the interface for device time synchronization.

Table 172: Telegram structure: sWN TSCTCInterface

Telegram structure: sWN TSCTCInterface (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set time synchronization interface	String	14		TSCTCInterface	54 53 43 54 43 49 6E 74 65 72 66 61 63 65

Telegram structure: sWN TSCTCInterface (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Variable data	Time synchronization interface data	Uint_8	1	Ethernet: CAN:	0 1	00 01

Table 173: Example: sWN TSCTCInterface

CoLa A	<STX>sWN[SPC]TSCTCInterface[SPC]0<ETX>					
	<STX>sWN TSCTCInterface 0<ETX>					
	sWN TSCTCInterface 0					
	02 73 57 4E 20 54 53 43 54 43 49 6E 74 65 72 66 61 63 65 20 30 03					
CoLa B	02 02 02 02 00 00 00 14 73 57 4E 20 54 53 43 54 43 49 6E 74 65 72 66 61 63 65 20 00 7C					
	73 57 4E 20 54 53 43 54 43 49 6E 74 65 72 66 61 63 65 20 00					

Table 174: Telegram structure: sWA TSCTCInterface

Telegram structure: sWA TSCTCInterface						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set time synchronization interface	String	14		TSCTCInterface	54 53 43 54 43 49 6E 74 65 72 66 61 63 65

Table 175: Example: sWA TSCTCInterface

CoLa A	<STX>sWA[SPC]TSCTCInterface<ETX>					
	02 73 57 41 20 54 53 43 54 43 49 6E 74 65 72 66 61 63 65 03					
CoLa B	02 02 02 02 00 00 00 13 73 57 41 20 54 53 43 54 43 49 6E 74 65 72 66 61 63 65 20 73					

12.2.1.4.4.2 Set time server IP address [sWN TSCTCSrvAddr]

Define the IP address from which the device will receive the time synchronization.

Table 176: Telegram structure: sWN TSCTCSrvAddr

Telegram structure: sWN TSCTCSrvAddr (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set time server IP address	String	12		TSCTCSrvAddr	54 53 43 54 43 53 72 76 41 64 64 72

Telegram structure: sWN TSCTCSrvAddr (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
IP address data	Set values	Uint_8	1	First part of IP address	0 ...+255d (00...FF)	00 ... FF
				Second part of IP address	0 ...+255d (00...FF)	00 ... FF
				Third part of IP address	0 ...+255d (00...FF)	00 ... FF
				Fourth part of IP address	0 ...+255d (00...FF)	00 ... FF

Table 177: Example: sWN TSCTCSrvAddr 192.168.0.11

CoLa A	<STX>sWN{SPC}TSCTCSrvAddr{SPC}C0{SPC}A8{SPC}00{SPC}0B<ETX>										
	<STX>sWN TSCTCSrvAddr C0 A8 00 0B<ETX>										
	sWN TSCTCSrvAddr C0 A8 00 0B										
	02 73 57 4E 20 54 53 43 54 43 53 72 76 41 64 64 72 20 43 30 20 41 38 20 30 30 20 30 42 03										
CoLa B	02 02 02 02 00 00 00 15 73 57 4E 20 54 53 43 54 43 53 72 76 41 64 64 72 20 C0 A8 00 0B 3E										
	73 57 4E 20 54 53 43 54 43 53 72 76 41 64 64 72 20 C0 A8 00 0B										

Table 178: Telegram structure: sWA TSCTCSrvAddr

Telegram structure: sWA TSCTCSrvAddr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set time server IP address	String	12		TSCTCSrvAddr	54 53 43 54 43 53 72 76 41 64 64 72

Table 179: Example: sWA TSCTCSrvAddr

CoLa A	<STX>sWA{SPC}TSCTCSrvAddr<ETX>					
	02 73 57 41 20 54 53 43 54 43 53 72 76 41 64 64 72 03					
CoLa B	02 02 02 02 00 00 00 11 73 57 41 20 54 53 43 54 43 53 72 76 41 64 64 72 20 52					

12.2.1.4.4.4.3 Set time zone [sWN TSCTCtimezone]

Table 180: Telegram structure: sWN TSCTCtimezone

Telegram structure: sWN TSCTCtimezone (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set time zone	String	13		TSCTCtimezone	54 53 43 54 43 74 69 6D 65 7A 6F 6E 65

Telegram structure: sWN TSCTCtimezone (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Time zone data	Set values in number of hours relative to GMT, hex specially coded	Int_8	1	[GMT-12:00]	+0d (00h)	00
				...	...	...
				[GMT]	+12d (0Ch)	0C
				... [GMT+12:00]	+24d (18h)	18

Table 181: Example: sWN TSCTCtimezone GMT -11 hours

CoLa A	<STX>sWN{SPC}TSCTCtimezone{SPC}+1<ETX>										
	<STX>sWN TSCTCtimezone +1<ETX>										
	sWN TSCTCtimezone +1										
	02 73 57 4E 20 54 53 43 54 43 74 69 6D 65 7A 6F 6E 65 20 2B 31 03										
CoLa B	02 02 02 02 00 00 00 13 73 57 4E 20 54 53 43 54 43 74 69 6D 65 7A 6F 6E 65 20 0D 3F										
	73 57 4E 20 54 53 43 54 43 74 69 6D 65 7A 6F 6E 65 20 0D										

Table 182: Telegram structure: sWA TSCTCtimezone

Telegram structure: sWA TSCTCtimezone						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set time zone	String	13		TSCTCtimezone	54 53 43 54 43 74 69 6D 65 7A 6F 6E 65

Table 183: Example: sWA TSCTCtimezone

CoLa A	<STX>sWA[SPC]TSCTCtimezone<ETX>					
	02 73 57 41 20 54 53 43 54 43 74 69 6D 65 7A 6F 6E 65 03					
CoLa B	02 02 02 02 00 00 00 12 73 57 41 20 54 53 43 54 43 74 69 6D 65 7A 6F 6E 65 20 3D					

12.2.1.4.4.4 Set update time [sWN TSCTCupdatetime]

Define the time period after which the sensor will attempt to get the current system time for the TSC server.

Table 184: Telegram structure: sWN TSCTCupdatetime

Telegram structure: sWN TSCTCupdatetime (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set update time of synchronization	String	15		TSCTCupdate-time	54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65

Telegram structure: sWN TSCTCupdatetime (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Update time of synchronization	Set values in seconds	Uint_32	4		+1d ... +3600d (01h ... 0E10h)	00 00 00 00 ... 00 00 0E 10

Table 185: Example: sWN TSCTCupdatetime 600 s

CoLa A	<STX>sWN{SPC}TSCTCupdatetime{SPC}+600<ETX>					
	<STX>sWN TSCTCupdatetime +600<ETX>					
	sWN TSCTCupdatetime +600					
	02 73 57 4E 20 54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65 20 2B 36 30 30 03					
CoLa B	02 02 02 02 00 00 00 18 73 57 4E 20 54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65 20 00 00 02 58 67					
	73 57 4E 20 54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65 20 00 00 02 58					

Table 186: Telegram structure: sWA TSCTCupdatetime

Telegram structure: sWA TSCTCupdatetime						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set update time of synchronization	String	15		TSCTCupdatetime	54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65

Table 187: Example: sWA TSCTCupdatetime

CoLa A	<STX>sWA{SPC}TSCTCupdatetime<ETX>					
	02 73 57 41 20 54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65 03					
CoLa B	02 02 02 02 00 00 00 14 73 57 41 20 54 53 43 54 43 75 70 64 61 74 65 74 69 6D 65 20 32					

12.2.1.4.4.5 Read for maximum offset time [sRN TSCTCmaxoffset]

Estimate the offset of the time synchronization.

Table 188: Telegram structure: sRN TSCTCmaxoffset

Telegram structure: sRN TSCTCmaxoffset						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read maximum offset time	String	14		TSCTCmaxoffset	54 53 43 54 43 6D 61 78 6F 66 66 73 65 74

Table 189: Example: sRN TSCTCmaxoffset

CoLa A	<STX>sRN{SPC}TSCTCmaxoffset<ETX>		
	<STX>sRN TSCTCmaxoffset<ETX>		
	sRN TSCTCmaxoffset		
	02 73 52 4E 20 54 53 43 54 43 6D 61 78 6F 66 66 73 65 74 03		
CoLa B	02 02 02 02 00 00 00 12 73 52 4E 20 54 53 43 54 43 6D 61 78 6F 66 66 73 65 74 65		
	73 52 4E 20 54 53 43 54 43 6D 61 78 6F 66 66 73 65 74		

Table 190: Telegram structure: sRA TSCTCmaxoffset

Telegram structure: sRA TSCTCmaxoffset						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read maximum offset time	String	14		TSCTCmaxoffset	54 53 43 54 43 6D 61 78 6F 66 66 73 65 74
Max. offset time	[Seconds as float according to IEEE754]	Real	4	Min Value: $\sim -3.403 \cdot 10^{38}$ s Max Value: $\sim +3.403 \cdot 10^{38}$ s	0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF

Table 191: Example: sRA TSCTCmaxoffset 18000 s

CoLa A	<STX>sRA{SPC}TSCTCmaxoffset{SPC}468CA000<ETX>		
	02 73 52 41 20 54 53 43 54 43 6D 61 78 6F 66 66 73 65 74 20 34 36 38 43 41 30 30 30 03		
CoLa B	02 02 02 02 00 00 00 17 73 52 41 20 54 53 43 54 43 6D 61 78 6F 66 66 73 65 74 20 46 8C A0 00 20		

12.2.1.4.4.6 Read for delay time [sRN TSCTCdelay]

Read the network delay for the time synchronization.

Table 192: Telegram structure: sRN TSCTCdelay

Telegram structure: sRN TSCTCdelay						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read delay time	String	10		TSCTCdelay	54 53 43 54 43 64 65 6C 61 79

Table 193: Example: sRN TSCTCdelay

CoLa A	<STX>sRN{SPC}TSCTCdelay<ETX>		
	<STX>sRN TSCTCdelay<ETX>		
	sRN TSCTCdelay		
	02 73 52 4E 20 54 53 43 54 43 64 65 6C 61 79 03		
CoLa B	02 02 02 02 00 00 00 0E 73 52 4E 20 54 53 43 54 43 64 65 6C 61 79 69		
	73 52 4E 20 54 53 43 54 43 64 65 6C 61 79		

Table 194: Telegram structure: sRA TSCTCdelay

Telegram structure: sRA TSCTCdelay						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read delay time	String	10		TSCTCdelay	54 53 43 54 43 64 65 6C 61 79
Max. off-set time	[Seconds as float according to IEEE754]	Real	4		0h ... FFFFFFFh	00 00 00 00 ... FF FF FF FF

Table 195: Example: sRA TSCTCdelay 0.003 s

CoLa A	<STX>sRA[SPC]TSCTCdelay[SPC]3B435B02<ETX>					
	02 73 52 41 20 54 53 43 54 43 64 65 6C 61 79 20 33 42 34 33 35 42 30 32 03					
CoLa B	02 02 02 02 00 00 00 13 73 52 41 20 54 53 43 54 43 64 65 6C 61 79 20 3B 43 5B 02 67					

12.2.1.4.4.7 Reset maximum offset time [sMN mResetMaxOff]

This command resets the maximum offset time, i.e. sets it to zero (0).

Table 196: Telegram structure: sMN mResetMaxOff

Telegram structure: sMN mResetMaxOff (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Reset maximum offset time	String	12		mResetMaxOff	6D 52 65 73 65 74 4D 61 78 4F 66 66

Table 197: Example: sMN mResetMaxOff

CoLa A	<STX>sMN[SPC]mResetMaxOff<ETX>					
	<STX>sMN mResetMaxOff<ETX>					
	sMN mResetMaxOff					
	02 73 4D 4E 20 6D 52 65 73 65 74 4D 61 78 4F 66 66 03					
CoLa B	02 02 02 02 00 00 00 10 73 4D 4E 20 6D 52 65 73 65 74 4D 61 78 4F 66 66 73					
	73 4D 4E 20 6D 52 65 73 65 74 4D 61 78 4F 66 66					

Table 198: Telegram structure: sAN mResetMaxOff

Telegram structure: sAN mResetMaxOff						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Reset maximum offset time	String	12		mResetMaxOff	6D 52 65 73 65 74 4D 61 78 4F 66 66

Table 199: Example: sAN mResetMaxOff

CoLa A	<STX>sAN{SPC}mResetMaxOff<ETX>
	02 73 41 4E 20 6D 52 65 73 65 74 4D 61 78 4F 66 66 03
CoLa B	02 02 02 02 00 00 00 11 73 41 4E 20 6D 52 65 73 65 74 4D 61 78 4F 66 66 20 5F

12.2.1.4.5 Filters

12.2.1.4.5.1 Set particle filter [sWN LFPparticle]

Filter out disturbances in the measurement data caused by particles such as dust, snow flakes or similar [see "Particle filter", page 40](#).

Table 200: Telegram structure: sWN LFPparticle

Telegram structure: sWN LFPparticle (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set particle filter	String	11		LFPparticle	4C 46 50 70 61 72 74 69 63 6C 65
Status code	Code number	Bool_1	1	Inactive: Active:	0 1	00 01
Threshold ¹⁾	Particle threshold in mm	Uint_16	2	(must be taken)	+500d (1F4h)	01 F4

1) Never change the threshold here, it is taken by the device to handle the particles.

Table 201: Example: sWN LFPparticle

CoLa A	<STX>sWN{SPC}LFPparticle{SPC}1{SPC}+500<ETX>					
	<STX>sWN LFPparticle 1 +500<ETX>					
	sWN LFPparticle 1 +500					
	02 73 57 4E 20 4C 46 50 70 61 72 74 69 63 6C 65 20 31 20 2B 35 30 30 03					
CoLa B	02 02 02 02 00 00 00 13 73 57 4E 20 4C 46 50 70 61 72 74 69 63 6C 65 20 01 01 F4 D0					
	73 57 4E 20 4C 46 50 70 61 72 74 69 63 6C 65 20 01 01 F4					

Table 202: Telegram structure: sWA LFPparticle

Telegram structure: sWA LFPparticle						
Telegram part	Description	Variable	Length	Sensor	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set particle filter	String	11		LFPparticle	4C 46 50 70 61 72 74 69 63 6C 65

1) 1)

Table 203: Example: sWA LFPparticle

CoLa A	<STX>sWA{SPC}LFPparticle<ETX> 02 73 57 41 20 4C 46 50 70 61 72 74 69 63 6C 65 03
CoLa B	02 02 02 02 00 00 00 10 73 57 41 20 4C 46 50 70 61 72 74 69 63 6C 65 20 2B

12.2.1.4.5.2 Set average filter [sWN LFPmeanfilter]

This filter smooths the distance value by calculating the arithmetic average from the configured number of scans see "Average filter", page 41.

Table 204: Telegram structure: sWN LFPmeanfilter

Telegram structure: sWN LFPmeanfilter (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set average filter	String	13		LFPmeanfilter	4C 46 50 6D 65 61 6E 66 69 6C 74 65 72
Status code	Code number	Bool_1	1	Inactive: Active:	0 1	00 01
Number of scans	Number	Uint_16	2		+2d ... +100d (00 02h ... 00 64h)	00 02 ... 00 64
Reserved	-	Enum_8	1	Always:	0	00

Table 205: Example: sWN LFPmeanfilter

CoLa A	<STX>sWN{SPC}LFPmeanfilter{SPC}1{SPC}+10{SPC}0<ETX>					
	<STX>sWN LFPmeanfilter 1 +10 0<ETX>					
	sWN LFPmeanfilter 1 +10 0					
	02 73 57 4E 20 4C 46 50 6D 65 61 6E 66 69 6C 74 65 72 20 31 20 2B 31 30 20 30 03					
CoLa B	02 02 02 02 00 00 00 16 73 57 4E 20 4C 46 50 6D 65 61 6E 66 69 6C 74 65 72 20 01 00 64 00 52					
	73 57 4E 20 4C 46 50 6D 65 61 6E 66 69 6C 74 65 72 20 01 00 64 00					

Table 206: Telegram structure: sWA LFPmeanfilter

Telegram structure: sWA LFPmeanfilter						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set average filter	String	13		LFPmeanfilter	4C 46 50 6D 65 61 6E 66 69 6C 74 65 72

Table 207: Example: sWA LFPmeanfilter

CoLa A	<STX>sWA{SPC}LFPmeanfilter<ETX> 02 73 57 41 20 4C 46 50 6D 65 61 6E 66 69 6C 74 65 72 03
CoLa B	02 02 02 02 00 00 00 12 73 57 41 20 4C 46 50 6D 65 61 6E 66 69 6C 74 65 72 20 38

12.2.1.4.5.3 Set echo filter [sWN FREchoFilter]



NOTE

Only available with firmware versions > V1.10.

Select which measurement value(s) shall be send via LMDscanata, if the measurement of one angular position returns several distance values (see "Multi-echo analysis", page 38)

Table 208: Telegram structure: sWN FREchoFilter

Telegram structure: sWN FREchoFilter (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set echo filter	String	12		FREchoFilter	46 52 45 63 68 6F 46 69 6C 74 65 72
Status code	Code number	Enum_8	1	First echo: All echos: Last echo:	0 1 2	00 01 02

Table 209: Example: sWN FREchoFilter

CoLa A	<STX>sWN{SPC}FREchoFilter{SPC}1<ETX>		
	<STX>sWN FREchoFilter 1<ETX>		
	sWN FREchoFilter 1		
	02 73 57 4E 20 46 52 45 63 68 6F 46 69 6C 74 65 72 20 31 03		
CoLa B	02 02 02 02 00 00 00 12 73 57 4E 20 46 52 45 63 68 6F 46 69 6C 74 65 72 20 01 7E		
	73 57 4E 20 46 52 45 63 68 6F 46 69 6C 74 65 72 20 01		

Table 210: Telegram structure: sWA FREchoFilter

Telegram structure: sWA FREchoFilter						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set echo filter	String	12		FREchoFilter	46 52 45 63 68 6F 46 69 6C 74 65 72

Table 211: Example: sWa FREchoFilter

CoLa A	<STX>sWA{SPC}FREchoFilter<ETX>	
	02 73 57 41 20 46 52 45 63 68 6F 46 69 6C 74 65 72 03	
CoLa B	02 02 02 02 00 00 00 11 73 57 41 20 46 52 45 63 68 6F 46 69 6C 74 65 72 20 70	

12.2.1.4.5.4 Set fog filter [sWN CLFogFilterEn]

Activating this filter allows the device to eliminate unwanted echos at close range see "Fog filter", page 39.

Table 212: Telegram structure: sWN CLFogFilterEn

Telegram structure: sWN CLFogFilterEn (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Enable fog filter	String	13		CLFogFilterEn	43 4C 46 6F 67 46 69 6C 74 65 72 45 6E
Status code	Enable or disable fog filter	Bool_1	1	Disable: Enable:	0 1	00 01

Table 213: Example: sWN CLFogFilterEn

CoLa A	<STX>sWN[SPC]CLFogFilterEn[SPC]1<ETX>					
	<STX>sWN CLFogFilterEn 1<ETX>					
	sWN CLFogFilterEn 1					
	02 73 57 4E 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 20 31 03					
CoLa B	02 02 02 02 00 00 00 13 73 57 4E 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 20 01 21					
	73 57 4E 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 20 01					

Table 214: Telegram structure: sWA CLFogFilterEn

Telegram structure: sWA CLFogFilterEn						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Enable fog filter	String	13		CLFogFilterEn	43 4C 46 6F 67 46 69 6C 74 65 72 45 6E

Table 215: Example: sWA CLFogFilterEn

CoLa A	<STX>sWA[SPC]CLFogFilterEn<ETX>					
	02 73 57 41 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 03					
CoLa B	02 02 02 02 00 00 00 12 73 57 41 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 20 2F					

12.2.1.4.5.5 Read for enabled fog filter [sRN CLFogFilterEn]

Check whether the fog filter is enabled or disabled.

Table 216: Telegram structure: sRN CLFogFilterEn

Telegram structure: sRN CLFogFilterEn						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Enabled fog filter	String	13		CLFogFilterEn	43 4C 46 6F 67 46 69 6C 74 65 72 45 6E

Table 217: Example: sRN CLFogFilterEn

CoLa A	<STX>sRN{SPC}CLFogFilterEn<ETX>		
	<STX>sRN CLFogFilterEn<ETX>		
	sRN CLFogFilterEn		
	02 73 52 4E 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 03		
CoLa B	02 02 02 02 00 00 00 11 73 52 4E 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 05		
	73 52 4E 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E		

Table 218: Telegram structure: sRA CLFogFilterEn

Telegram structure: sRA CLFogFilterEn						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Enabled fog filter	String	13		CLFogFilterEn	43 4C 46 6F 67 46 69 6C 74 65 72 45 6E
Status code	Fog filter enabled or disabled	Bool_1	1	Disabled: Enabled:	0 1	00 01

Table 219: Example: sRA CLFogFilterEn

CoLa A	<STX>sRA{SPC}CLFogFilterEn{SPC}1<ETX>		
	02 73 52 41 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 20 01 03		
CoLa B	02 02 02 02 00 00 00 13 73 52 41 20 43 4C 46 6F 67 46 69 6C 74 65 72 45 6E 20 01 2B		

12.2.1.4.5.6 Set sensitivity fog filter [sWN MCSenseLevel]

Filter out disturbances in the measurement data caused by fog or steam.

Table 220: Telegram structure: sWN MCSenseLevel

Telegram structure: sWN MCSenseLevel (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Sense level	String	12		MCSenseLevel	4D 43 53 65 6E 73 65 4C 65 76 65 6C
Sensitivity level	Enable or disable fog filter and Sense Level	Uint_8	1		1 ... 6	01 ... 06

Table 221: Example: sWN MCSenseLevel

CoLa A	<STX>sWN{SPC}MCSenseLevel{SPC}1<ETX>		
	<STX>sWN MCSenseLevel 1<ETX>		
	sWN MCSenseLevel 1		
	02 73 57 4E 20 4D 43 53 65 6E 73 65 4C 65 76 65 6C 20 31 03		
CoLa B	02 02 02 02 00 00 00 10 73 57 4E 20 4D 43 53 65 6E 73 65 4C 65 76 65 6C 20 01 70		
	73 57 4E 20 4D 43 53 65 6E 73 65 4C 65 76 65 6C 20 01		

Table 222: Telegram structure: sWA MCSenseLevel

Telegram structure: sWA MCSenseLevel						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Sense level	String	12		MCSenseLevel	4D 43 53 65 6E 73 65 4C 65 76 65 6C

Table 223: Example: sWA MCSenseLevel

CoLa A	<STX>sWA[SPC]MCSenseLevel<ETX>
	02 73 57 41 20 4D 43 53 65 6E 73 65 4C 65 76 65 6C 20 03
CoLa B	02 02 02 02 00 00 00 0F 73 57 41 20 4D 43 53 65 6E 73 65 4C 65 76 65 6C 20 73

12.2.1.4.5.7 Activate/deactivate “fog filter operating radius active” [sWN FogFilterMaxRangeEnable]

Enable/ disable the fog filter only for specific distance ranges.

Table 224: Telegram structure: sWN FogFilterMaxRangeEnable

Telegram structure: sWN FogFilterMaxRangeEnable (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Enable max. range restriction for fog filter	String	23		FogFilterMax-RangeEnable	46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65
Enable/Disable		Bool_1	1	Activate: Deactivate:	1 0	01 00

Table 225: Example: sWN FogFilterMaxRangeEnable 1

CoLa A	<STX>sWN[SPC]FogFilterMaxRangeEnable[SPC]1<ETX>					
	<STX>sWN FogFilterMaxRangeEnable 1<ETX>					
	sWN FogFilterMaxRangeEnable 1					
	02 73 57 4E 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65 20 31 03					
CoLa B	02 02 02 02 00 00 00 1D 73 57 4E 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65 20 01 2F					
	73 57 4E 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65 20 01					

Table 226: Telegram structure: sWA FogFilterMaxRangeEnable

Telegram structure: sWA FogFilterMaxRangeEnable						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41

Telegram structure: sWA FogFilterMaxRangeEnable						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Enable max. range restriction for fog filter	String	23		FogFilterMaxRangeEnable	46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65

Table 227: Example: sWA FogFilterMaxRangeEnable

CoLa A	<STX>sWN{SPC}FogFilterMaxRangeEnable<ETX>	
	02 73 57 41 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65 03	
CoLa B	02 02 02 02 00 00 00 1C 73 57 41 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 45 6E 61 62 6C 65 20 21	

12.2.1.4.5.8 Execute the “Teach from 90° angle” button [sMN TeachFogFilterMaxRange]

Teach maximum fog filter distance, based on the current distance measurement in front of the sensor (90° position).

Table 228: Telegram structure: sMN TeachFogFilterMaxRange

Telegram structure: sMN TeachFogFilterMaxRange (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Teach max. range restriction for fog filter	String	22		TeachFogFilterMaxRange	54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65

Table 229: Example: sMN TeachFogFilterMaxRange

CoLa A	<STX>sMN{SPC}TeachFogFilterMaxRange<ETX>	
	<STX>sMN TeachFogFilterMaxRange<ETX>	
	sMN TeachFogFilterMaxRange	
	02 73 4D 4E 20 54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 03	
CoLa B	02 02 02 02 00 00 00 1A 73 4D 4E 20 54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 6E	
	73 4D 4E 20 54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65	

Table 230: Telegram structure: sAN TeachFogFilterMaxRange

Telegram structure: sAN TeachFogFilterMaxRange (required user level: Authorized Client)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E

Telegram structure: sAN TeachFogFilterMaxRange (required user level: Authorized Client)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Teach max. range restriction for fog filter	String	22		TeachFogFilterMaxRange	54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65

Table 231: Example: sAN TeachFogFilterMaxRange

CoLa A	<STX>sAN{SPC}TeachFogFilterMaxRange<ETX>					
	02 73 41 4E 20 54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 03					
CoLa B	02 02 02 02 00 00 00 1B 73 41 4E 20 54 65 61 63 68 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 20 42					

12.2.1.4.5.9 Setting of the value “Fog filter operating radius active up to” [sWN FogFilterMaxRange]

Define the maximum fog filter distance by a specific distance value.

Table 232: Telegram structure: sWN FogFilterMaxRange

Telegram structure: sWN FogFilterMaxRange (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Max. range restriction for fog filter	String	17		FogFilterMaxRange	46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65
Distance of the radius	[1/1000m]	Real as float according to IEEE754	4	0.5 m: up to	43FA0000	43 FA 00 00
				16.0 m:	467A0000	46 7A 00 00

Table 233: Example: sWN FogFilterMaxRange 43FA0000

CoLa A	<STX>sWN{SPC}FogFilterMaxRange{SPC}43FA0000<ETX>					
	<STX>sWN FogFilterMaxRange 43FA0000<ETX>					
	sWN FogFilterMaxRange 43FA0000					
	02 73 57 4E 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 20 43 FA 00 00 03					
CoLa B	02 02 02 02 00 00 00 1A 73 57 4E 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 20 43 FA 00 00 B6					
	73 57 4E 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 20 43 FA 00 00					

Table 234: Telegram structure: sWA FogFilterMaxRange

Telegram structure: sWA FogFilterMaxRange						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41

Telegram structure: sWA FogFilterMaxRange						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Max. range restriction for fog filter	String	17		FogFilterMax-Range	46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65

Table 235: Example: sWA FogFilterMaxRange

CoLa A	<STX>sWA{SPC}FogFilterMaxRange<ETX>					
	02 73 57 41 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 03					
CoLa B	02 02 02 02 00 00 00 16 73 57 41 20 46 6F 67 46 69 6C 74 65 72 4D 61 78 52 61 6E 67 65 20 00					

12.2.1.4.6 Encoder

12.2.1.4.6.1 Set increment source [sWN LICsrc]

Define if the device gets movement information via the encoder input or if a fixed speed is to be assumed.

Table 236: Telegram structure: sWN LICsrc

Telegram structure: sWN LICsrc (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set increment source	String	6		LICsrc	4C 49 43 73 72 63
Increment source		Enum_8	1	Fixed speed: Encoder:	0 1	00 01

Table 237: Example: sWN LICsrc

CoLa A	<STX>sWN{SPC}LICsrc{SPC}0<ETX>					
	<STX>sWN LICsrc 0<ETX>					
	sWN LICsrc 0					
	02 73 57 4E 20 4C 49 43 73 72 63 20 30 03					
CoLa B	02 02 02 02 00 00 00 0C 73 57 4E 20 4C 49 43 73 72 63 20 00 4E					
	73 57 4E 20 4C 49 43 73 72 63 20 00					

Table 238: Telegram structure: sWA LICsrc

Telegram structure: sWA LICsrc						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set increment source	String	6		LICsrc	4C 49 43 73 72 63

Table 239: Example: sWA LICsrc

CoLa A	<STX>sWA[SPC]LICsrc<ETX>					
	02 73 57 41 20 4C 49 43 73 72 63 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 41 20 4C 49 43 73 72 63 20 41					

12.2.1.4.6.2 Set encoder settings [sWN LICencset]

Define if and which type of encoder is connected to the device so that input signals are processed correctly.

Table 240: Telegram structure: sWN LICencset

Telegram structure: sWN LICencset (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Encoder settings	String	9		LICencset	4C 49 43 65 6E 63 73 65 74
Encoder setting		Enum_8	1	Off: Single increment/INC1: Direction recognition (phase): Direction recognition (level):	0 1 2 3	00 01 02 03

Table 241: Example: sWN LICencset

CoLa A	<STX>sWN[SPC]LICencset[SPC]0<ETX>					
	<STX>sWN LICencset 0<ETX>					
	sWN LICencset 0					
	02 73 57 4E 20 4C 49 43 65 6E 63 73 65 74 20 30 03					
CoLa B	02 02 02 02 00 00 00 0F 73 57 4E 20 4C 49 43 65 6E 63 73 65 74 20 00 26					
	73 57 4E 20 4C 49 43 65 6E 63 73 65 74 20 00					

Table 242: Telegram structure: sWA LICencset

Telegram structure: sWA LICencset						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Encoder settings	String	9		LICencset	4C 49 43 65 6E 63 73 65 74

Table 243: Example: sWA LICencset

CoLa A	<STX>sWA[SPC]LICencset<ETX>					
	02 73 57 41 20 4C 49 43 65 6E 63 73 65 74 03					
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 4C 49 43 65 6E 63 73 65 74 20 29					

12.2.1.4.6.3 Set encoder resolution [sWN LICencres]

Determine the encoder resolution in mm/increment.

Table 244: Telegram structure: sWN LICencres

Telegram structure: sWN LICencres (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set encoder resolution	String	9		LICencres	4C 49 43 65 6E 63 72 65 73
Encoder resolution	Resolution value in mm/Inc as float according to IEEE754	Real	4		+0.001d ... +2000d	3A 83 12 6F ... 44 FA 00 00 (see IEEE 754)

Table 245: Example: sWN LICencres

CoLa A	<STX>sWN[SPC]LICencres[SPC]+1000<ETX>					
	<STX>sWN LICencres +1000<ETX>					
	sWN LICencres +1000					
	02 73 57 4E 20 4C 49 43 65 6E 63 72 65 73 20 2B 31 30 30 03					
CoLa B	02 02 02 02 00 00 00 10 73 57 4E 20 4C 49 43 65 6E 63 72 65 73 20 44 7A 00 00 1E					
	73 57 4E 20 4C 49 43 65 6E 63 72 65 73 20 44 7A 00 00					

Table 246: Telegram structure: sWA LICencres

Telegram structure: sWA LICencres						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set encoder resolution	String	9		LICencres	4C 49 43 65 6E 63 72 65 73

Table 247: Example: sWA LICencres

CoLa A	<STX>sWA[SPC]LICencres<ETX>					
	02 73 57 41 20 4C 49 43 65 6E 63 72 65 73 03					
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 4C 49 43 65 6E 63 72 65 73 20 2F					

12.2.1.4.6.4 Set fixed speed [sWN LICFixVel]

Simulate fixed encoder speed in m/s.

Table 248: Telegram structure: sWN LICFixVel

Telegram structure: sWN LICFixVel (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set fixed speed	String	9		LICFixVel	4C 49 43 46 69 78 56 65 6C

Telegram structure: sWN LICFixVel (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Fixed speed	Speed in m/s as float according to IEEE754	Real	4		+0.001d ... +10.0d	3A 83 12 6F ... 41 20 00 00

Table 249: Example: sWN LICFixVel

CoLa A	<STX>sWN[SPC]LICFixVel[SPC]+5<ETX>					
	<STX>sWN LICFixVel +5<ETX>					
	sWN LICFixVel +5					
	02 73 57 4E 20 4C 49 43 46 69 78 56 65 6C 20 2B 35 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 4E 20 4C 49 43 46 69 78 56 65 6C 20 40 A0 00 00 C4					
	73 57 4E 20 4C 49 43 46 69 78 56 65 6C 20 40 A0 00 00					

Table 250: Telegram structure: sWA LICFixVel

Telegram structure: sWA LICFixVel						
Telegram part	Description	Variable	Length	Sensor	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set fixed speed	String	9		LICFixVel	4C 49 43 46 69 78 56 65 6C

Table 251: Example: sWA LICFixVel

CoLa A	<STX>sWA[SPC]LICFixVel<ETX>					
	02 73 57 41 20 4C 49 43 46 69 78 56 65 6C 03					
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 4C 49 43 46 69 78 56 65 6C 20 2B					

12.2.1.4.6.5 Read speed threshold [sRN LICSpTh]

Table 252: Telegram structure: sRN LICSpTh

Telegram structure: sRN LICSpTh						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read speed threshold	String	7		LICSpTh	4C 49 43 53 70 54 68

Table 253: Example: sRN LICSpTh

CoLa A	<STX>sRN[SPC]LICSpTh<ETX>					
	<STX>sRN LICSpTh<ETX>					
	sRN LICSpTh					
	02 73 52 4E 20 4C 49 43 53 70 54 68 03					

CoLa B	02 02 02 02 00 00 00 0D 73 52 4E 20 4C 49 43 53 70 54 68 16	
	73 52 4E 20 4C 49 43 53 70 54 68	

Table 254: Telegram structure: sRA LICSpTh

Telegram structure: sRA LICSpTh					 	
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read speed threshold	String	7		LICSpTh	4C 49 43 53 70 54 68
Speed threshold	Speed threshold in %	Uint_8	2		+1d ... +20d (01h ... 14h)	01 ... 14

Table 255: Example: sRA LICSpTh

CoLa A	<STX>sRA{SPC}LICSpTh{SPC}5<ETX>
	02 73 52 41 20 4C 49 43 53 70 54 68 20 35 03
CoLa B	02 02 02 02 00 00 00 0D 73 52 41 20 4C 49 43 53 70 54 68 20 05 3C

12.2.1.4.6.6 Read encoder speed [sRN LICencsp]

Read encoder speed in m/s.

Table 256: Telegram structure: sRN LICencsp

Telegram structure: sRN LICencsp					 	
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read encoder speed	String	8		LICencsp	4C 49 43 65 6E 63 73 70

Table 257: Example: sRN LICencsp

CoLa A	<STX>sRN{SPC}LICencsp<ETX>	
	<STX>sRN LICencsp<ETX>	
	sRN LICencsp	
CoLa B	02 02 02 02 00 00 00 11 73 52 4E 20 4C 49 43 65 6E 63 73 70 62	
	73 52 4E 20 4C 49 43 65 6E 63 73 70	

Table 258: Telegram structure: sRA LICencsp

Telegram structure: sRA LICencsp					 	
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Encoder speed	[Speed in m/s as float according to IEEE754]	Real	4		0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF

Table 259: Example: sRA LICencsp

CoLa A	<STX>sRA{SPC}LICencsp{SPC}0<ETX>
CoLa B	02 02 02 02 00 00 00 11 73 52 41 20 4C 49 43 65 6E 63 73 70 20 00 00 00 00 4D

12.2.1.4.7 Inputs and Outputs

12.2.1.4.7.1 Read state of the ports [sRN LIDportstate]

LIDportstate has to be available additionally or as successor of the LIDoutputstate telegram.

Valid for all sensors with Ethernet and ports (inputs / outputs).

Table 260: Telegram structure: sRN LIDportstate

Telegram structure: sRN LIDportstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Ask for port configuration	String	12		LIDportstate	4C 49 44 70 6F 72 74 73 74 61 74 65

Table 261: Example: sRN LIDportstate

CoLa A	<STX>sRN{SPC}LIDportstate<ETX>																
	<STX>sRN LIDportstate<ETX>																
	sRN LIDportstate																
	02 73 52 4E 20 4C 49 44 70 6F 72 74 73 74 61 74 65 03																
CoLa B	02 02 02 02 00 00 00 10 73 52 4E 20 4C 49 44 70 6F 72 74 73 74 61 74 65 60																
	73 52 4E 20 4C 49 44 70 6F 72 74 73 74 61 74 65																

Table 262: Telegram structure: sRA LIDportstate

Telegram structure: sRA LIDportstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Port state	String	12		LIDportstate	4C 49 44 70 6F 72 74 73 74 61 74 65
Status code	Version number	Uint_16	2	Current version:	0 ... FFFFh 1	00 01 ... FF FF
	System counter (time in µs since power up max. 71min then starting from 0 again)	Uint_32	4		0 ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF

Telegram structure: sRA LIDportstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
ARRAY which defines the number of internal ports*	0...n	Uint_16	2	Hex: Not available: Number of ports:	0000 - FFFF 00 01 ... n	00 00 - FF FF
State of the ports and count value in hex	Internal port state	Enum_8	1	Output voltage low: (Relays open) Output voltage high: (Relays closed) Tri-state: Input voltage high (level): Input voltage from low to high (edge) Input voltage low (level): Input voltage high to low (edge)	00 01 02 03 04	00 01 02 03 04
	Internal port counter	Uint_32	4		0 ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
						
ARRAY which defines the number of external ports*	0...n	Uint_16	1	Hex: Not available: Nuner of ports:	00 00 - FF FF 00 01 ... n	00 00 - FF FF
State of the ports and count value in hex	External port state	Enum_8	1	Output voltage low: (Relays open) Output voltage high: (Relays closed) Tri-state: Input voltage high (level): Input voltage from low to high (edge) Input voltage low (level): Input voltage high to low (edge)	00 01 02 03 04	00 01 02 03 04
	External port counter	Uint_32	4		0 ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
Time	States code	Enum_16	1	No time data: Time data:	00 00 00 01	00 00 00 01
Time Block (sensor time from the last change of min. one of the outputs)	Year	Array	2	E.g.	1970	07 B2
	Month		1		1 ... 12	01 ... 0C
	Day		1		1 ... 31	01 ... 1F
	Hour		1		0 ... 23	00 ... 17
	Minute		1		0 ... 59	00 ... 3B
	Second		1		0 ... 59	00 ... 3B
	Microsecond		4		0 ... 999999	00 00 00 00 ... 00 0F 42 3F

Inputs/outputs: If the device has separate inputs and outputs (instead of general purpose ports) the ARRAY shall start with inputs followed by the outputs.

Example with 3 internal and 4 external ports:

Table 263: Example: sRA LIDportstate

CoLa A	<STX>sRA{SPC}LIDportstate{SPC}1{SPC}41F84EC5{SPC}3{SPC}1{SPC}20{SPC}1{SPC}20{SPC}3{SPC}20{SPC}4{SPC}1{SPC}20{SPC}1{SPC}20{SPC}0{SPC}20{SPC}03{SPC}20{SPC}1{SPC}7D9{SPC}2{SPC}12{SPC}C{SPC}29{SPC}E{SPC}975E0<ETX>
CoLa B	02 73 52 41 20 4C 49 44 70 6F 72 74 73 74 61 74 65 20 31 20 34 31 46 38 34 45 43 35 20 33 20 31 20 32 30 20 31 20 32 30 20 33 20 32 30 20 34 20 31 20 32 30 20 31 20 32 30 20 30 20 32 30 20 30 33 20 32 30 20 31 20 37 44 39 20 32 20 31 32 20 43 20 32 39 20 45 20 39 37 35 45 30 03
CoLa B	02 02 02 02 00 00 00 5B 73 52 41 20 4C 49 44 70 6F 72 74 73 74 61 74 65 20 01 00 41 F8 4E C5 00 03 00 01 00 20 00 04 00 01 00 20 00 01 00 20 00 00 00 20 00 03 00 20 00 01 00 07 D9 00 02 00 12 00 0C 00 29 00 0E 00 09 75 E0 21

12.2.1.4.7.2 Read state of the inputs [sRN LIDinputstate]

Use sEN LIDinputstate 1 to receive a telegram each time an input signal (e.g. by trigger) changes. Compare with chapter "Receive outputstate by event [sEN LIDoutputstate]", page 190.

Table 264: Telegram structure: sRN LIDinputstate

Telegram structure: sRN LIDinputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Input state	String	14		LIDinputstate	4C 49 44 69 6E 70 75 74 73 74 61 74 65

Table 265: Example: sRN LIDinputstate

CoLa A	<STX>sRN{SPC}LIDinputstate<ETX>																
	<STX>sRN LIDinputstate<ETX>																
	sRN LIDinputstate																
	02 73 52 4E 20 4C 49 44 69 6E 70 75 74 73 74 61 74 65 03																
CoLa B	02 02 02 02 00 00 00 11 73 52 4E 20 4C 49 44 69 6E 70 75 74 73 74 61 74 65 0F																
	73 52 4E 20 4C 49 44 69 6E 70 75 74 73 74 61 74 65																

Table 266: Telegram structure: sRA LIDinputstate

Telegram structure: sRA LIDinputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Output state	String	14		LIDinputstate	4C 49 44 69 6E 70 75 74 73 74 61 74 65

Telegram structure: sRA LIDinputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Status code	Version number	Uint_16	2		0h ... FFFFh	00 00 ... FF FF
	System counter (time in µs since power up max. 71min then starting from 0 again)	Uint_32	4		0 h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
State of the inputs 1 ... n	Amount of inputs (n) depending of device family	Enum_8	1	Not active: Active: Input not used:	0 1 2	00 01 02
Time	States code	Uint_16	2	No time data: Time data:	0 1	00 00 00 01
Time Block (sensor-time from the last change of min. one of the outputs)	Year	Array	2	E. g.	1970	07 B2
	Month		1		1 ... 12	01 ... 0C
	Day		1		1 ... 31	01 ... 1F
	Hour		1		0 ... 23	00 ... 17
	Minute		1		0 ... 59	00 ... 3B
	Second		1		0 ... 59	00 ... 3B
	Microsecond		4		0 ... 999999	00 00 00 00 ... 00 0F 42 3F

Table 267: Example: sRA LIDinputstate In1 inactive, In2 inactive, In3 inactive, In4 inactive, time: 1970-01-01 00:00 2 sec 265000 microseconds

CoLa A	<STX>sRA{SPC}LIDinput-state{SPC}0{SPC}238437{SPC}0{SPC}0{SPC}0{SPC}0{SPC}1{SPC}7B2{SPC}1{SPC}1{SPC}0{SPC}0{SPC}2{SPC}40B28<ETX>
	02 73 52 41 20 4C 49 44 69 6E 70 75 74 73 74 61 74 65 20 30 20 32 33 38 34 33 37 20 30 20 30 20 30 20 30 20 31 20 37 42 32 20 31 20 31 20 30 20 30 20 32 20 34 30 42 32 38 03
CoLa B	02 02 02 02 00 00 00 29 73 52 41 20 4C 49 44 69 6E 70 75 74 73 74 61 74 65 20 00 00 00 23 84 37 00 00 00 00 01 07 B2 01 01 00 00 02 00 04 0B 28 21

12.2.1.4.7.3 Read state of the outputs [sRN LIDoutputstate]

Status of all outputs

Table 268: Telegram structure: sRN LIDoutputstate

Telegram structure: sRN LIDoutputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Output state	String	14		LIDoutputstate	4C 49 44 6F 75 74 70 75 74 73 74 61 74 65

Table 269: Example: sRN LIDoutputstate

CoLa A	<STX>sRN{SPC}LIDoutputstate<ETX>					
	<STX>sRN LIDoutputstate<ETX>					
	sRN LIDoutputstate					
	02 73 52 4E 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 03					
CoLa B	02 02 02 02 00 00 00 12 73 52 4E 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 66					
	73 52 4E 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65					

Table 270: Telegram structure: sRA LIDoutputstate

Telegram structure: sRA LIDoutputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Complete telegram structure of the answer see "Receive outputstate by event [sEN LIDoutputstate]", page 190.						

12.2.1.4.7.4 Receive outputstate by event [sEN LIDoutputstate]

Output telegram is sent every time an output state changes.

Table 271: Telegram structure: sEN LIDoutputstate

Telegram structure: sEN LIDoutputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Event	String	3		sEN	73 45 4E
Command	Output state	String	14		LIDoutputstate	4C 49 44 6F 75 74 70 75 74 73 74 61 74 65
	Start/stop	Enum_8	1	Start: Stop:	1 0	01 00

Table 272: Example: sEN LIDoutputstate

CoLa A	<STX>sEN{SPC}LIDoutputstate{SPC}1<ETX>					
	<STX>sEN LIDoutputstate 1<ETX>					
	sEN LIDoutputstate 1					
	02 73 45 4E 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 20 31 03					
CoLa B	02 02 02 02 00 00 00 14 73 45 4E 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 20 01 50					
	73 45 4E 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 20 01					

Table 273: Telegram structure: sRA/sSN LIDoutputstate

Telegram structure: sRA/sSN LIDoutputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA / sSN	73 52 41 / 73 53 4E

Telegram structure: sRA/sSN LIDoutputstate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Output state	String	14		LIDoutputstate	4C 49 44 6F 75 74 70 75 74 73 74 61 74 65
Status code	Version number	Uint_16	2		0h ... FFFFh	00 00 ... FF FF
	System counter (time in µs since power up max. 71min then starting from 0 again)	Uint_32	4		0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
State of the outputs 1 ... n and count value in hex. (values of an example) Amount of outputs (n) depending of device family	Output 1 ... n state	Enum_8	1	Not active: Active: Output not used:	0 1 2	00 01 02
	Output 1 ... n count	Uint_32	4		0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
State of the external outputs 1 ... n and count value in hex. (values of an example) Amount of outputs (n) depending of device family	External Output 1 ... n state	Enum_8	1	Not active: Active: Output not used:	0 1 2	00 01 02
	External Output 1 ... n count	Uint_32	4		0 ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
Time	States code	Uint_16	2	No time data: Time data:	0 1	00 00 00 01
Time Block (sensor-time from the last change of min. one of the outputs)	Year	Array	2	E. g.	1970	07 B2
	Month		1		1 ... 12	01 ... 0C
	Day		1		1 ... 31	01 ... 1F
	Hour		1		0 ... 23	00 ... 17
	Minute		1		0 ... 59	00 ... 3B
	Second		1		0 ... 59	00 ... 3B
	Microsecond		4		0 ... 999999	00 00 00 00 ... 00 0F 42 3F

Table 274: Example: sRA LIDoutputstate Out1 active Count 5, Out2 active Count 5, Out3 active Count 5, all other Outputs not used, time: 2009-02-18 12:41 14.62 sec

CoLa A	<STX>sRA{SPC}LIDoutput-state{SPC}1{SPC}41F84EC5{SPC}1{SPC}5{SPC}1{SPC}5{SPC}1{SPC}5{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}2{SPC}0{SPC}1{SPC}7D9{SPC}2{SPC}12{SPC}C{SPC}29{SPC}E{SPC}975E0<ETX>
	02 73 52 41 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 20 31 20 41 F8 4E C5 20 31 20 35 20 31 20 35 20 31 20 35 20 32 20 30 20 32 20 30 20 32 20 30 20 32 20 30 20 32 20 30 20 32 20 30 20 32 20 30 20 31 20 37 44 39 20 32 20 31 32 20 43 20 32 39 20 45 20 39 37 35 45 30 03
CoLa B	02 02 02 02 00 00 00 5D 73 52 41 20 4C 49 44 6F 75 74 70 75 74 73 74 61 74 65 20 00 01 41 F8 4E C5 01 00 00 00 05 01 00 00 00 05 01 00 00 00 05 02 00 00 00 02 00 00 00 02 00 00 00 02 00 00 00 00 02 00 00 00 02 00 00 00 01 07 D9 02 12 0C 29 0E 00 09 75 E0 06

12.2.1.4.7.5 Set output state [sMN mDOSetOutput]

Set a specific output to high or low via software command.



NOTE

Output source needs to be set to "SOPAS command".

Table 275: Telegram structure: sMN mDOSetOutput

Telegram structure: sMN mDOSetOutput						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Set output state	String	12		mDOSetOutput	6D 44 4F 53 65 74 4F 75 74 70 75 74
Output number		Uint_8	1		1 ... 6	01 ... 06
Output state		Enum_8	1	Not active: Active:	0 1	00 01

Table 276: Example: sMN mDOSetOutput

CoLa A	<STX>sMN{SPC}mDOSetOutput{SPC}1{SPC}1<ETX>	
	<STX>sMN mDOSetOutput 1 1<ETX>	
	sMN mDOSetOutput 1 1	
	02 73 4D 4E 20 6D 44 4F 53 65 74 4F 75 74 70 75 74 20 31 20 31 03	
CoLa B	02 02 02 02 00 00 00 13 73 4D 4E 20 6D 44 4F 53 65 74 4F 75 74 70 75 74 20 01 01 6B	
	73 4D 4E 20 6D 44 4F 53 65 74 4F 75 74 70 75 74 20 01 01	

Table 277: Telegram structure: sAN mDOSetOutput

Telegram structure: sAN mDOSetOutput						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E

Telegram structure: sAN mDOSetOutput						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Set output state	String	12		mDOSetOutput	6D 44 4F 53 65 74 4F 75 74 70 75 74
Status Code	Status code	Bool_1	1	Error: Success:	0 1	00 01

Table 278: Example: sAN mDOSetOutput

CoLa A	<STX>sAN{SPC}mDOSetOutput{SPC}1<ETX>					
	02 73 41 4E 20 6D 44 4F 53 65 74 4F 75 74 70 75 74 20 31 03					
CoLa B	02 02 02 02 00 00 00 12 73 41 4E 20 6D 44 4F 53 65 74 4F 75 74 70 75 74 20 01 66					

12.2.1.4.7.6 Change output 6/3 function [sWN D06Fnc / D03Fnc]

Specify the activation condition or behavior for a specific digital output.

Table 279: Telegram structure PRO: sWN D06Fnc/Lite: sWN D03Fnc

Telegram structure: sWN D06Fnc/sWN D03Fnc (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Output function	String	6	LMS5xx PRO	D06Fnc	44 4F 36 46 6E 63
				LMS5xx Lite	D03Fnc	44 4F 33 46 6E 63
Output state		Enum_8	1	No Function: SOPAS command: Device Ready: Application: Application / Device Ready: Device ready / Contamination: Contamination: Master Synchronisation:	0 1 2 3 4 5 6 7	00 01 02 03 04 05 06 07

Table 280: Example: sWN D06Fnc → Out6 to Master synchronisation

CoLa A	<STX>sWN{SPC}D06Fnc{SPC}7<ETX>					
	<STX>sWN D06Fnc 7<ETX>					
	sWN D06Fnc 7					
	02 73 57 4E 20 44 4F 36 46 6E 63 20 37 03					
CoLa B	02 02 02 02 00 00 00 0C 73 57 4E 20 44 4F 36 46 6E 63 20 07 1B					
	73 57 4E 20 44 4F 36 46 6E 63 20 07					

Table 281: Telegram structure: PRO: sWN D06Fnc/Lite: sWN D03Fnc

Telegram structure: sWA D06Fnc						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Output function	String	6	LMS5xx PRO	D06Fnc	44 4F 36 46 6E 63
				LMS5xx Lite	D03Fnc	44 4F 33 46 6E 63

Table 282: Example: sWA D06Fnc

CoLa A	<STX>sWA[SPC]D06Fnc<ETX>					
	02 73 57 41 20 44 4F 36 46 6E 63 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 41 20 44 4F 36 46 6E 63 20 13					

12.2.1.4.7.7 Set synchronization mode [sWN SYMode]

Define if and by which type of connection a device synchronization is established to avoid mutual optical interference.

Table 283: Telegram structure: sWN SYMode

Telegram structure: sWN SYMode (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set sync mode	String	6		SYMode	53 59 4D 6F 64 65
Sync mode data	Synchronization mode data	Bool_1	1	No sync: Sync by wire: Sync by CAN:	0 1 2	00 01 02

Table 284: Example: sWN SYMode

CoLa A	<STX>sWN[SPC]SYMode[SPC]1<ETX>					
	<STX>sWN SYMode 1<ETX>					
	sWN SYMode 1					
	02 73 57 4E 20 53 59 4D 6F 64 65 20 31 03					
CoLa B	02 02 02 02 00 00 00 0C 73 57 4E 20 53 59 4D 6F 64 65 20 01 42					
	73 57 4E 20 53 59 4D 6F 64 65 20 01					

Table 285: Telegram structure: sWA SYMode

Telegram structure: sWA SYMode						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41

Telegram structure: sWA SYMode						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Set sync mode	String	6		SYMode	53 59 4D 6F 64 65

Table 286: Example: sWA SYMode

CoLa A	<STX>sWA{SPC}SYMode<ETX>					
	02 73 57 41 20 53 59 4D 6F 64 65 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 41 20 53 59 4D 6F 64 65 20 4C					

12.2.1.4.7.8 Set synchronization phase [sWN SYPhase]

Define the phase difference for device synchronization to avoid mutual optical interference.

Table 287: Telegram structure: sWN SYPhase

Telegram structure: sWN SYPhase (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set sync phase	String	7		SYPhase	53 59 50 68 61 73 65
Sync phase data	Synchronization phase data	Int_16	2		-180d ... +180d (FF4Ch ... B4h)	FF 4C ... 00 B4

Table 288: Example: sWN SYPhase +90

CoLa A	<STX>sWN{SPC}SYPhase{SPC}+90<ETX>					
	<STX>sWN SYPhase +90<ETX>					
	sWN SYPhase +90					
	02 73 57 4E 20 53 59 50 68 61 73 65 20 2B 39 30 03					
CoLa B	02 02 02 02 00 00 00 0E 73 57 4E 20 53 59 50 68 61 73 65 20 00 5A 75					
	73 57 4E 20 53 59 50 68 61 73 65 20 00 5A					

Table 289: Telegram structure: sWA SYPhase

Telegram structure: sWA SYPhase						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set sync phase	String	7		SYPhase	53 59 50 68 61 73 65

Table 290: Example: sWA SYPhase

CoLa A	<STX>sWA{SPC}SYPhase<ETX>					
	02 73 57 41 20 53 59 50 68 61 73 65 03					
CoLa B	02 02 02 02 00 00 00 0C 73 57 41 20 53 59 50 68 61 73 65 20 20					

12.2.1.4.7.9 Change input 4 function [sWN DO3And4Fnc]

Define or change function of digital input 4.

Table 291: Telegram structure: sWN DO3And4Fnc

Telegram structure: sWN DO3And4Fnc (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Sensor	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Input function	String	10		DO3And4Fnc	44 4F 33 41 6E 64 34 46 6E 63
Input state	Code number	Enum_8	1	No function: Encoder: Slave sync: Digital input:	0 1 2 3	00 01 02 03

Table 292: Example: sWN In4 → In3+4 to slave sync

CoLa A	<STX>sWN{SPC}DO3And4Fnc{SPC}2<ETX>					
	<STX>sWN DO3And4Fnc 2<ETX>					
	sWN DO3And4Fnc 2					
	02 73 57 4E 20 44 4F 33 41 6E 64 34 46 6E 63 20 02 03					
CoLa B	Available with firmware versions > V1.10					
	02 02 02 02 00 00 00 11 73 57 4E 20 44 4F 33 41 6E 64 34 46 6E 63 20 00 32 54					

Table 293: Telegram structure: sWA DO3And4Fnc

Telegram structure: sWA DO3And4Fnc						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Input function	String	10		DO3And4Fnc	44 4F 33 41 6E 64 34 46 6E 63

Table 294: Example: sWA DO3And4Fnc

CoLa A	<STX>sWA{SPC}DO3And4Fnc<ETX>					
	02 73 57 41 20 44 4F 33 41 6E 64 34 46 6E 63 03					
CoLa B	Available with firmware versions > V1.10					
	02 02 02 02 00 00 00 0F 73 57 41 20 44 4F 33 41 6E 64 34 46 6E 63 20 69					

12.2.1.4.7.10 Set debouncing time for input x [sWN DI3DebTim]

The telegram applies for the inputs 1 to 4 (DIxDebTim, x = 1 ... 4). The following tables show the data for input 3.

Table 295: Telegram structure: sWN DI3DebTim

Telegram structure: sWN DI3DebTim (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set debouncing time for input 3	String	9		DI3DebTim	44 49 33 44 65 62 54 69 6D
Debouncing time data	[ms]	Uint_16	2		0d ... +10000d (00h ... 2710h)	00 00 ... 27 10

Table 296: Example: sWN DI3DebTim

CoLa A	<STX>sWN{SPC}DI3DebTim{SPC}+10<ETX>					
	<STX>sWN DI3DebTim +10<ETX>					
	sWN DI3DebTim +10					
	02 73 57 4E 20 44 49 33 44 65 62 54 69 6D 20 2B 31 30 03					
CoLa B	02 02 02 02 00 00 00 10 73 57 4E 20 44 49 33 44 65 62 54 69 6D 20 00 0A 77					
	73 57 4E 20 44 49 33 44 65 62 54 69 6D 20 00 0A					

Table 297: Telegram structure: sWA DI3DebTim

Telegram structure: sWA DI3DebTim						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set debouncing time for input 3	String	9		DI3DebTim	44 49 33 44 65 62 54 69 6D

Table 298: Example: sWA DI3DebTim

CoLa A	<STX>sWA{SPC}DI3DebTim<ETX>					
	02 73 57 4E 20 44 49 33 44 65 62 54 69 6D 03					
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 44 49 33 44 65 62 54 69 6D 20 48					

12.2.1.4.7.11 Read status of external sync signal [sRN SYextmon]

Verify if an external synchronization signal is available and read its status and frequency.

Table 299: Telegram structure: sRN SYextmon

Telegram structure: sRN SYextmon						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Status of external sync signal	String	8		SYextmon	53 59 65 78 74 6D 6F 6E

Table 300: Example: sRN SYextmon

CoLa A	<STX>sRN{SPC}SYextmon<ETX>					
	<STX>sRN SYextmon<ETX>					
	sRN SYextmon					
	02 73 52 4E 20 53 59 65 78 74 6D 6F 6E 03					
CoLa B	02 02 02 02 00 00 00 0C 73 52 4E 20 53 59 65 78 74 6D 6F 6E 40					
	73 52 4E 20 53 59 65 78 74 6D 6F 6E					

Table 301: Telegram structure: sRA SYextmon

Telegram structure: sRA SYextmon						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Status of external sync signal	String	8		SYextmon	53 59 65 78 74 6D 6F 6E
Sync status data	Synchronization status data	Uint_8	1	None: Too slow: Good: Too fast:	1 2 4 8	01 02 04 08
Signal frequency	[Frequency in Hz as float according to IEEE754]	Real	4		0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF

Table 302: Example: sRA SYextmon (49.9 Hz)

CoLa A	<STX>sRA{SPC}SYextmon{SPC}4{SPC}4247BD87<ETX>					
	02 73 52 41 20 53 59 65 78 74 6D 6F 6E 20 34 20 34 32 34 37 42 44 38 37 03					
CoLa B	02 02 02 02 00 00 00 12 73 52 41 20 53 59 65 78 74 6D 6F 6E 20 04 42 47 BD 87 54					

12.2.1.4.7.12 Reset output counter [sMN LIDrstoutpcnt]

Reset the counter which keeps track of how often an digital output has been active (and not active). Information from the counter is included in LIDOutputstate (see "Receive outputstate by event [sEN LIDOutputstate]", page 190).

Table 303: Telegram structure: sMN LIDrstoutpcnt

Telegram structure: sMN LIDrstoutpcnt (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Method	String	3		sMN	73 4D 4E
Command	Reset output counter	String	13		LIDrstoutpcnt	4C 49 44 72 73 74 6F 75 74 70 63 6E 74

Table 304: Example: sMN LIDrstoutpcnt

CoLa A	<STX>sMN{SPC}LIDrstoutpcnt<ETX>		
	<STX>sMN LIDrstoutpcnt<ETX>		
	sMN LIDrstoutpcnt		
	02 73 4D 4E 20 4C 49 44 72 73 74 6F 75 74 70 63 6E 74 03		
CoLa B	02 02 02 02 00 00 00 11 73 4D 4E 20 4C 49 44 72 73 74 6F 75 74 70 63 6E 74 03		
	73 4D 4E 20 4C 49 44 72 73 74 6F 75 74 70 63 6E 74		

Table 305: Telegram structure: sAN LIDrstoutpcnt

Telegram structure: sAN LIDrstoutpcnt						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sAN	73 41 4E
Command	Reset output counter	String	13		LIDrstoutpcnt	4C 49 44 72 73 74 6F 75 74 70 63 6E 74
Status code	Code number	Bool_1	1	Success: Error:	0 1	00 01

Table 306: Example: sAN LIDrstoutpcnt

CoLa A	<STX>sAN{SPC}LIDrstoutpcnt{SPC}0<ETX>		
	02 73 41 4E 20 4C 49 44 72 73 74 6F 75 74 70 63 6E 74 20 30 03		
CoLa B	02 02 02 02 00 00 00 13 73 41 4E 20 4C 49 44 72 73 74 6F 75 74 70 63 6E 74 20 00 2F		

12.2.1.4.8 Status

12.2.1.4.8.1 Read firmware version [sRN DevicelDent]

Table 307: Telegram structure: sRN DevicelDent

Telegram structure: sRN DevicelDent						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read firmware version	String	11		DevicelDent	44 65 76 69 63 65 49 64 65 6E 74

Table 308: Example: sRN DevicelDent

CoLa A	<STX>sRN{SPC}DevicelDent<ETX>		
	<STX>sRN DevicelDent<ETX>		
	sRN DevicelDent		
	02 73 52 4E 20 44 65 76 69 63 65 49 64 65 6E 74 03		
CoLa B	02 02 02 02 00 00 00 0F 73 52 4E 20 44 65 76 69 63 65 49 64 65 6E 74 25		
	73 52 4E 20 44 65 76 69 63 65 49 64 65 6E 74		

Table 309: Telegram structure: sRA Devicelident

Telegram structure: sRA Devicelident						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command		String	11		Devicelident	44 65 76 69 63 65 49 64 65 6E 74
Value	Length of firmware designation	Enum_16	2		0 ... 22h	0 ... 22h
Value	Firmware designation for device family	String			(See example)	(See example)
Value	Length of firmware version	Enum_16	2		0 ... 22h	0 ... 22h
Value	Firmware version	String			(See example)	(See example)

Table 310: Example: sRA Devicelident

CoLa A	<STX>sRA{SPC}Devicelident{SPC}14{SPC}LMS5xx_FieldEval_PRO{SPC}10{SPC}V2.30-29.11.2023<ETX>					
	02 73 52 41 20 44 65 76 69 63 65 49 64 65 6E 74 20 31 34 20 4C 4D 53 35 78 78 5F 46 69 65 6C 64 45 76 61 6C 5F 50 52 4F 20 31 30 20 56 32 2E 33 30 2D 32 39 2E 31 31 2E 32 30 32 33 03					
CoLa B	02 02 02 02 00 00 00 38 73 52 41 20 44 65 76 69 63 65 49 64 65 6E 74 20 00 14 4C 4D 53 35 78 78 5F 46 69 65 6C 64 45 76 61 6C 5F 50 52 4F 00 10 56 32 2E 33 30 2D 32 39 2E 31 31 2E 32 30 32 33 34					

12.2.1.4.8.2 Read the device state [sRN SCdevicestate]

This telegram reads the general device state.



NOTE

The status of the measurement function can be read separately with the telegram STlms.

Table 311: Telegram structure: sRN SCdevicestate

Telegram structure: sRN SCdevicestate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read the device state	String	13		SCdevicestate	53 43 64 65 76 69 63 65 73 74 61 74 65

Table 312: Example: sRN SCdevicestate

CoLa A	<STX>sRN{SPC}SCdevicestate<ETX>					
	<STX>sRN SCdevicestate<ETX>					
	sRN SCdevicestate					
	02 73 52 4E 20 53 43 64 65 76 69 63 65 73 74 61 74 65 03					
CoLa B	02 02 02 02 00 00 00 11 73 52 4E 20 53 43 64 65 76 69 63 65 73 74 61 74 65 30					
	73 52 4E 20 53 43 64 65 76 69 63 65 73 74 61 74 65					

Table 313: Telegram structure: sRA SCdevicestate

Telegram structure: sRA SCdevicestate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read the device state	String	13		SCdevicestate	53 43 64 65 76 69 63 65 73 74 61 74 65
Status code	Code number	Enum_8	1	Busy / logged-in: Ready: Error: Standby:	0 1 2 3	00 01 02 03

Table 314: Example: sRA SCdevicestate

CoLa A	<STX>sRA{SPC}SCdevicestate{SPC}1<ETX>
	02 73 52 41 20 53 43 64 65 76 69 63 65 73 74 61 74 65 20 31 03
CoLa B	02 02 02 02 00 00 00 13 73 52 41 20 53 43 64 65 76 69 63 65 73 74 61 74 65 20 01 1E

12.2.1.4.8.3 Read device order number [sRN Dlornr]

This telegram reads the device order number.

Table 315: Telegram structure: sRN Dlornr

Telegram structure: sRN Dlornr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read device order number	String	6		Dlornr	44 49 6F 72 6E 72

Table 316: Example: sRN Dlornr

CoLa A	<STX>sRN{SPC}Dlornr<ETX>	
	<STX>sRN Dlornr<ETX>	
	sRN Dlornr	
	02 73 52 4E 20 44 49 6F 72 6E 72 03	
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 44 49 6F 72 6E 72 43	
	73 52 4E 20 44 49 6F 72 6E 72	

Table 317: Telegram structure: sRA Dlornr

Telegram structure: sRA Dlornr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41

Telegram structure: sRA Dlornr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Read device order number	String	6		Dlornr	44 49 6F 72 6E 72
Order number	Order number in 7 digits	String	7		0000000 ... 9999999	00 00 00 00 00 00 00 ... FF FF FF FF FF FF FF

Example: sRA Dlornr 1047782 (Order Number for LMS511-20100)

Table 318: Example: sRA Dlornr

CoLa A	<STX>sRA{SPC}Dlornr{SPC}1047782<ETX>
CoLa B	02 02 02 02 00 00 00 12 73 52 41 20 44 49 6F 72 6E 72 20 31 30 34 37 37 38 32 53

12.2.1.4.8.4 Read device type [sRN Dtype]

This telegram asks for the device type of the product family.

Table 319: Telegram structure: sRN Dtype

Telegram structure: sRN Dtype						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Ask state	String	6		Dtype	44 49 74 79 70 65

Table 320: Example: sRN Dtype

CoLa A	<STX>sRN{SPC}Dtype<ETX>					
	<STX>sRN Dtype<ETX>					
	sRN Dtype					
	02 73 52 4E 20 44 49 74 79 70 65 03					
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 44 49 74 79 70 65 5A					
	73 52 4E 20 44 49 74 79 70 65					

Table 321: Telegram structure: sRA Ddtype

Telegram structure: sRA Ddtype						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Ask state	String	6		Ddtype	44 49 74 79 70 65
Length of type key	Number of digits of the following type code length	Uint_8	1		0d ... 255d (0h ... FFh)	00 ... FF

Telegram structure: sRA Ditype						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Device type	Type code of the device	String	(var.)		(Device type)	(Device type)

Table 322: sRA Ditype Example for LMS511-20100:

CoLa A	<STX>sRA{SPC}Ditype{SPC}C{SPC}LMS511-20100<ETX>					
	02 73 52 41 20 44 49 74 79 70 65 20 43 20 4C 4D 53 35 31 31 2D 32 30 31 30 30 03					
CoLa B	02 02 02 02 00 00 00 18 73 52 41 20 44 49 74 79 70 65 20 0C 4C 4D 53 35 31 31 2D 32 30 31 30 30 00					

12.2.1.4.8.5 Read operating hours [sRN ODoprh]

Table 323: Telegram structure: sRN ODoprh

Telegram structure: sRN ODoprh						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read operating hours	String	6		ODoprh	4F 44 6F 70 72 68

Table 324: Example: sRN ODoprh

CoLa A	<STX>sRN{SPC}ODoprh<ETX>					
	<STX>sRN ODoprh<ETX>					
	sRN ODoprh					
	02 73 52 4E 20 4F 44 6F 70 72 68 03					
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 4F 44 6F 70 72 68 41					
	73 52 4E 20 4F 44 6F 70 72 68					

Table 325: Telegram structure: sRA ODoprh

Telegram structure: sRA ODoprh						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read operating hours	String	6		ODoprh	4F 44 6F 70 72 68
Value	Operating hours in 1/10 h	Uint_32	4		0h ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF

Table 326: Example: sRA ODoprh

CoLa A	<STX>sRA{SPC}ODoprh{SPC}2DC8B<ETX>					
	02 73 52 41 20 4F 44 6F 70 72 68 20 32 44 43 38 42 03					
CoLa B	02 02 02 02 00 00 00 0F 73 52 41 20 4F 44 6F 70 72 68 20 00 02 DC 8B 36					

Calculation of the value: 2DC8B (hex) → 187531 (dez) × 1/10 h = 18753.1 h

12.2.1.4.8.6 Read power on counter [sRN ODpwrC]

Shows the number of power on cycles.

Table 327: Telegram structure: sRN ODpwrC

Telegram structure: sRN ODpwrC						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read power on counter	String	6		ODpwrC	4F 44 70 77 72 63

Table 328: Example: sRN ODpwrC

CoLa A	<STX>sRN{SPC}ODpwrC<ETX>					
	<STX>sRN ODpwrC<ETX>					
	sRN ODpwrC					
	02 73 52 4E 20 4F 44 70 77 72 63 03					
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 4F 44 70 77 72 63 52					
	73 52 4E 20 4F 44 70 77 72 63					

Table 329: Telegram structure: sRA ODpwrC

Telegram structure: sRA ODpwrC						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read power on counter	String	6		ODpwrC	4F 44 70 77 72 63
Value	Power on counter	Uint_32	4		0h ... FFFFFFFh	00 00 00 00 ... FF FF FF FF

Table 330: Example: sRA ODpwrC

CoLa A	<STX>sRA{SPC}ODpwrC{SPC}752D<ETX>					
	02 73 52 41 20 4F 44 70 77 72 63 20 752D 03					
CoLa B	02 02 02 02 00 00 00 0F 73 52 41 20 4F 44 70 77 72 63 20 00 00 75 2D 36					

12.2.1.4.8.7 Read temperature [sRN OPcurtmpdev]

With this command the internal temperature of the device can be identified. Please note that it does not give an indication of the current ambient temperature.

Table 331: Telegram structure: sRN OPcurtmpdev

Telegram structure: sRN OPcurtmpdev						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E

Telegram structure: sRN OPcurtmpdev						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Read temperature of the device	String	11		OPcurtmpdev	4F 50 63 75 72 74 6D 70 64 65 76

Table 332: Example: sRN OPcurtmpdev

CoLa A	<STX>sRN{SPC}OPcurtmpdev<ETX>																
	<STX>sRN OPcurtmpdev<ETX>																
	sRN OPcurtmpdev																
	02 73 52 4E 20 4F 50 63 75 72 74 6D 70 64 65 76 03																
CoLa B	02 02 02 02 00 00 00 0F 73 52 4E 20 4F 50 63 75 72 74 6D 70 64 65 76 2A																
	73 52 4E 20 4F 50 63 75 72 74 6D 70 64 65 76																

Table 333: Telegram structure: sRA OPcurtmpdev

Telegram structure: sRA OPcurtmpdev						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read temperature of the device	String	11		OPcurtmpdev	4F 50 63 75 72 74 6D 70 64 65 76
Temperature data	[°C]	Real as float according to IEEE754	4	(-50 °C ... +100 °C)	C2480000h ... 42C80000h	C2 48 00 00 ... 42 C8 00 00

Example: sRA OPcurtmpdev (35 °C)

Table 334: Example: sRA OPcurtmpdev

CoLa A	<STX>sRA[SPC]OPcurtmpdev[SPC]420C0000<ETX>					
	02 73 52 41 20 4F 50 63 75 72 74 6D 70 64 65 76 20 34 32 30 43 30 30 03					
CoLa B	02 02 02 02 00 00 00 14 73 52 41 20 4F 50 63 75 72 74 6D 70 64 65 76 20 42 0C 00 00 4B					

12.2.1.4.8.8 Set device name [sWN LocationName]

Give the device a specific description name such as its location.

Table 335: Telegram structure: sWN LocationName

Telegram structure: sWN LocationName (User level 'Maintenance' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set device name	String	12		LocationName	4C 6F 63 61 74 69 6F 6E 4E 61 6D 65

Telegram structure: sWN LocationName (User level 'Maintenance' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Value	Number of characters of the following device name	Uint_16	2		0d ... +16d (0h ... 10h)	00 00 ... 00 10
Value	Device name	String	16		[Device name]	[Device name]

Table 336: Example: sWN LocationName +13 OutdoorDevice

CoLa A	<STX>sWN{SPC}LocationName{SPC}+13{SPC}OutdoorDevice<ETX>					
	<STX>sWN LocationName +13 OutdoorDevice<ETX>					
	sWN LocationName +13 OutdoorDevice					
CoLa B	02 73 57 4E 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 20 2B 31 33 20 4F 75 74 64 6F 6F 72 44 65 76 69 63 65 03					
	02 02 02 02 00 00 00 20 73 57 4E 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 20 00 0D 4F 75 74 64 6F 6F 72 44 65 76 69 63 65 1D					
CoLa B	73 57 4E 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 20 00 0D 4F 75 74 64 6F 6F 72 44 65 76 69 63 65					
						

Table 337: Telegram structure: sWA LocationName

Telegram structure: sWA LocationName						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set device name	String	12		LocationName	4C 6F 63 61 74 69 6F 6E 4E 61 6D 65

Table 338: Example: sWA LocationName

CoLa A	<STX>sWA{SPC}LocationName<ETX>					
	02 73 57 41 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 03					
CoLa B	02 02 02 02 00 00 00 11 73 57 41 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 20 7F					

12.2.1.4.8.9 Read device name [sRN LocationName]

Read the given name of the device (Default is the serial number of the device).

Table 339: Telegram structure: sRN LocationName

Telegram structure: sRN LocationName						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read device name	String	12		LocationName	4C 6F 63 61 74 69 6F 6E 4E 61 6D 65

Table 340: Example: sRN LocationName

CoLa A	<STX>sRN{SPC}LocationName<ETX>		
	<STX>sRN LocationName<ETX>		
	sRN LocationName		
	02 73 52 4E 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 03		
CoLa B	02 02 02 02 00 00 00 10 73 52 4E 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65 55		
	73 52 4E 20 4C 6F 63 61 74 69 6F 6E 4E 61 6D 65		

Table 341: Telegram structure: sRA LocationName

Telegram structure: sRA LocationName						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Find complete telegram structure of the answer in see table 335, page 205						

12.2.1.4.8.10 Read heating state [sRN OPheatstateext]

Read if the heating is connected and its status.



NOTE

It is not allowed to request this telegram in a faster cycle than 10 ms!

Table 342: Telegram structure: sRN OPheatstateext

Telegram structure: sRN OPheatstateext						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command		String	14		OPheatstateext	4F 50 68 65 61 74 73 74 61 74 65 65 78 74 74

Table 343: Example: sRN OPheatstateext

CoLa A	<STX>sRN{SPC}OPheatstateext<ETX>		
	<STX>sRN OPheatstateext<ETX>		
	sRN OPheatstateext		
	02 73 52 4E 20 4F 50 68 65 61 74 73 74 61 74 65 65 78 74 03		
CoLa B	02 02 02 02 00 00 00 12 73 52 4E 20 4F 50 68 65 61 74 73 74 61 74 65 65 78 74 56		
	73 52 4E 20 4F 50 68 65 61 74 73 74 61 74 65 65 78 74		

Table 344: Telegram structure: sRA OPheatstateext

Telegram structure: sRA OPheatstateext						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41

Telegram structure: sRA OPheatstateext						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command		String	14		OPheatstateext	4F 50 68 65 61 74 73 74 61 74 65 65 78 74
Heating state	Heating state	Enum_8	1	Heating active: Electrical current for heating too low: Heating inactive: Power supply for heating not connected:	0d 1d 2d 3d	00 01 02 03

Table 345: Example: sRA OPheatstateext 2

CoLa A	<STX>sRA{SPC}OPheatstateext{SPC}2<ETX>	
	02 73 52 41 20 4F 50 68 65 61 74 73 74 61 74 65 65 78 74 20 32 03	
CoLa B	02 02 02 02 00 00 00 14 73 52 41 20 4F 50 68 65 61 74 73 74 61 74 65 65 78 74 20 02 7B	

12.2.1.4.9 Interfaces

12.2.1.4.9.1 Set IP address [sWN EllpAddr]



NOTE

- Save permanently to set values. Changes will be active after rebooting the device.
- Settings must correspond with network in which scanner is used. Else device cannot be found any more.

Table 346: Telegram structure: sWN EllpAddr

Telegram structure: sWN EllpAddr (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set IP address	String	8		EllpAddr	45 49 49 50 41 64 64 72
IP address	Set values	Uint_8	1	First part of IP adress	0 ...+255d (00 ... FF)	00 ... FF
				Second part of IP adress	0 ...+255d (00 ... FF)	00 ... FF
				Third part of IP adress	0 ...+255d (00 ... FF)	00 ... FF
				Fourth part of IP adress	0 ...+255d (00 ... FF)	00 ... FF

Table 347: Example: sWN EllpAddr 192.168.0.2

CoLa A	<STX>sWN{SPC}EllpAddr{SPC}C0{SPC}A8{SPC}0{SPC}2<ETX>	
	<STX>sWN EllpAddr C0 A8 0 2<ETX>	
	sWN EllpAddr C0 A8 0 2	
	02 73 57 4E 20 45 49 49 70 41 64 64 72 20 43 30 20 41 38 20 30 20 32 03	

CoLa B	02 02 02 02 00 00 00 11 73 57 4E 20 45 49 49 70 41 64 64 72 20 C0 A8 00 02 06
	73 57 4E 20 45 49 49 70 41 64 64 72 20 C0 A8 00 02

Table 348: Telegram structure: sWA EllpAddr

Telegram structure: sWA EllpAddr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set IP address	String	8		EllpAddr	45 49 49 50 41 64 64 72

Table 349: Example: sWA EllpAddr

CoLa A	<STX>sWA[SPC]EllpAddr<ETX>
	02 73 57 41 20 45 49 49 70 41 64 64 72 03
CoLa B	02 02 02 02 00 00 00 0D 73 57 41 20 45 49 49 70 41 64 64 72 20 63

12.2.1.4.9.2 Read IP address [sRN EllpAddr]

Read the IP address of the device.

Table 350: Telegram structure: sRN EllpAddr

Telegram structure: sRN EllpAddr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read IP address	String	8		EllpAddr	45 49 49 50 41 64 64 72

Table 351: Example: sRN EllpAddr

CoLa A	<STX>sRN[SPC]EllpAddr<ETX>
	<STX>sRN EllpAddr<ETX>
	sRN EllpAddr
	02 73 52 4E 20 45 49 49 70 41 64 64 72 03
CoLa B	02 02 02 02 00 00 00 0C 73 52 4E 20 45 49 49 70 41 64 64 72 49
	73 52 4E 20 45 49 49 70 41 64 64 72

Table 352: Telegram structure: sRA EllpAddr

Telegram structure: sRA EllpAddr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read IP address	String	8		EllpAddr	45 49 49 50 41 64 64 72

Telegram structure: sRA ElIpAddr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
IP address	Default: 192.168.0.1	Uint_8	1	First part of IP address	0 ...+255d (00 ... FF)	00 ... FF
				Second part of IP address	0 ...+255d (00 ... FF)	00 ... FF
				Third part of IP address	0 ...+255d (00 ... FF)	00 ... FF
				Fourth part of IP address	0 ...+255d (00 ... FF)	00 ... FF

Table 353: Example: sRA ElIpAddr 192.168.0.2

CoLa A	<STX>sRA{SPC}ElIpAddr{SPC}C0{SPC}A8{SPC}00{SPC}02<ETX>					
	02 73 57 41 20 45 49 49 70 41 64 64 72 20 C0 20 A8 20 00 20 02 03					
CoLa B	02 02 02 02 00 00 00 11 73 52 41 20 45 49 49 70 41 64 64 72 20 C0 A8 00 02 0C					

12.2.1.4.9.3 Set Ethernet gateway [sWN Elgate]



NOTE

- Save permanently to set values. Changes will be active after rebooting the device.
- Settings must correspond with network in which scanner is used. Else device cannot be found any more.

Table 354: Telegram structure: sWN Elgate

Telegram structure: sWN Elgate (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set gateway adress	String	6		Elgate	45 49 67 61 74 65
Gateway address	Set values	Uint_8	1	First part of gateway address	0 ...+255d (00...FF)	00 ...FF
				Second part of gateway address	0 ...+255d (00...FF)	00 ...FF
				Third part of gateway address	0 ...+255d (00...FF)	00 ...FF
				Fourth part of gateway address	0 ...+255d (00...FF)	00 ...FF

Table 355: Example: sWN Elgate 192.168.0.1

CoLa A	<STX>sWN{SPC}Elgate{SPC}C0{SPC}A8{SPC}00{SPC}01<ETX>					
	<STX>sWN Elgate C0 A8 00 01<ETX>					
	sWN Elgate C0 A8 00 01					
	02 73 57 4E 20 45 49 67 61 74 65 20 43 30 20 41 38 20 30 30 20 30 31 03					
CoLa B	02 02 02 02 00 00 00 0F 73 57 4E 20 45 49 67 61 74 65 20 C0 A8 00 01 18					
	73 57 4E 20 45 49 67 61 74 65 20 C0 A8 00 01					

Table 356: Telegram structure: sWA Elgate

Telegram structure: sWA Elgate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set gateway adress	String	6		Elgate	45 49 67 61 74 65

Table 357: Example: sWA Elgate

CoLa A	<STX>sWA{SPC}Elgate<ETX>					
	02 73 57 41 20 45 49 67 61 74 65 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 41 20 45 49 67 61 74 65 20 7E					

12.2.1.4.9.4 Read Ethernet gateway [sRN Elgate]

Read for the Ethernet gateway (TCP/IP)

Table 358: Telegram structure: sRN Elgate

Telegram structure: sRN Elgate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read gateway address	String	6		Elgate	45 49 67 61 74 65

Table 359: Example: sRN Elgate

CoLa A	<STX>sRN{SPC}Elgate<ETX>										
	<STX>sRN Elgate<ETX>										
	sRN Elgate										
	02 73 52 4E 20 45 49 67 61 74 65 03										
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 45 49 67 61 74 65 54										
	73 52 4E 20 45 49 67 61 74 65										

Table 360: Telegram structure: sRA Elgate

Telegram structure: sRA Elgate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read gateway address	String	6		Elgate	45 49 67 61 74 65

Telegram structure: sRA Elgate						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Gateway address	Default: 0.0.0.0	Uint_8	1	First part of gateway address	0 ...+255d (00...FF)	00 ... FF
				Second part of gateway address	0 ...+255d (00...FF)	00 ... FF
				Third part of gateway address	0 ...+255d (00...FF)	00 ... FF
				Fourth part of gateway address	0 ...+255d (00...FF)	00 ... FF

Table 361: Example: sRA Elgate 192.168.0.1

CoLa A	<STX>sRA{SPC}Elgate{SPC}C0{SPC}A8{SPC}00{SPC}01<ETX>				
	02 73 52 41 20 45 49 67 61 74 65 20 C0 A8 00 01 03				
CoLa B	02 02 02 02 00 00 00 0F 73 52 41 20 45 49 67 61 74 65 20 C0 A8 00 01 12				

12.2.1.4.9.5 Set IP mask [sWN Elmask]

Define the subnet mask of the device.



NOTE

- Save permanently to set values. Changes will be active after rebooting the device.
- Settings must correspond with network in which scanner is used. Else device cannot be found any more.

Table 362: Telegram structure: sWN Elmask

Telegram structure: sWN Elmask (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set IP mask	String	6		Elmask	45 49 6D 61 73 6B
IP mask	Set values	Uint_8	1	First part of IP mask	0 ...+255d (00...FF)	00 ...FF
				Second part of IP mask	0 ...+255d (00...FF)	00 ...FF
				Third part of IP mask	0 ...+255d (00...FF)	00 ...FF
				Fourth part of IP mask	0 ...+255d (00...FF)	00 ...FF

Table 363: Example: sWN Elmask 255.255.254.0

CoLa A	<STX>sWN{SPC}Elmask{SPC}FF{SPC}FF{SPC}FE{SPC}00<ETX>				
	<STX>sWN Elmask FF FF FE 00<ETX>				
	sWN Elmask FF FF FE 00				
	02 73 57 4E 20 45 49 6D 61 73 6B 20 46 46 20 46 46 20 46 45 20 30 30 03				
CoLa B	02 02 02 02 00 00 00 0F 73 57 4E 20 45 49 6D 61 73 6B 20 FF FF FE 00 8C				
	73 57 4E 20 45 49 6D 61 73 6B 20 FF FF FE 00				

Table 364: Telegram structure: sWA Elmask

Telegram structure: sWA Elmask						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set IP mask	String	6		Elmask	45 49 6D 61 73 6B

Table 365: Example: sWA Elmask

CoLa A	<STX>sWA{SPC}Elmask<ETX>					
	02 73 57 41 20 45 49 6D 61 73 6B 03					
CoLa B	02 02 02 02 00 00 00 0B 73 57 41 20 45 49 6D 61 73 6B 20 7D					

12.2.1.4.9.6 Read IP mask [sRN Elmask]

Read the subnet mask of the device.

Table 366: Telegram structure: sRN Elmask

Telegram structure: sRN Elmask						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read IP mask	String	6		Elmask	45 49 6D 61 73 6B

Table 367: Example: sRN Elmask

CoLa A	<STX>sRN{SPC}Elmask<ETX>										
	<STX>sRN Elmask<ETX>										
	sRN Elmask										
	02 73 52 4E 20 45 49 6D 61 73 6B 03										
CoLa B	02 02 02 02 00 00 00 0A 73 52 4E 20 45 49 6D 61 73 6B 57										
	73 52 4E 20 45 49 6D 61 73 6B										

Table 368: Telegram structure: sRA Elmask

Telegram structure: sRA Elmask						
Telegram part	Description	Variable	Length	Sensor	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read IP mask	String	6		Elmask	45 49 6D 61 73 6B

Telegram structure: sRA Elmask						
Telegram part	Description	Variable	Length	Sensor	Values CoLa A (ASCII)	Values CoLa B (Binary)
IP mask	Default: 255.255.255.0	Uint_8	1	First part of IP mask	0 ...+255d (00...FF)	00 ... FF
				Second part of IP mask	0 ...+255d (00...FF)	00 ... FF
				Third part of IP mask	0 ...+255d (00...FF)	00 ... FF
				Fourth part of IP mask	0 ...+255d (00...FF)	00 ... FF

Table 369: Example: sRA Elmask 255.255.254.0

CoLa A	<STX>sRA{SPC}Elmask{SPC}FF{SPC}FF{SPC}FE{SPC}00<ETX>
	02 73 52 41 20 45 49 6D 61 73 6B 20 45 49 6D 61 73 6B 03
CoLa B	02 02 02 02 00 00 00 0F 73 52 41 20 45 49 6D 61 73 6B 20 FF FF FE 00 86

12.2.1.4.9.7 Read MAC address [sRN EIMacAdr]

Read the MAC address of the device.

Table 370: Telegram structure: sRN EIMacAdr

Telegram structure: sRN EIMacAdr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read MAC address of the device	String	8		EIMacAdr	45 49 4D 61 63 41 64 72

Table 371: Example: sRN EIMacAdr

CoLa A	<STX>sRN{SPC}EIMacAdr<ETX>					
	<STX>sRN EIMacAdr<ETX>					
	sRN EIMacAdr					
	02 73 57 4E 20 45 49 4D 61 63 41 64 72 03					
CoLa B	02 02 02 02 00 00 00 0C 73 52 4E 20 45 49 4D 61 63 41 64 72 5B					
	73 52 4E 20 45 49 4D 61 63 41 64 72					

Table 372: Telegram structure: sRA EIMacAdr

Telegram structure: sRA EIMacAdr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read MAC address of the device	String	8		EIMacAdr	45 49 4D 61 63 41 64 72

Telegram structure: sRA EIMacAdr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
MAC address	Values	Uint_8	1	First part of MAC address	0 ...+255d (00...FF)	00 ... FF
		Uint_8	1	Second part of MAC address	0 ...+255d (00...FF)	00 ... FF
		Uint_8	1	Third part of MAC address	0 ...+255d (00...FF)	00 ... FF
		Uint_8	1	Fourth part of MAC address	0 ...+255d (00...FF)	00 ... FF
		Uint_8	1	Fifth part of MAC address	0 ...+255d (00...FF)	00 ... FF
		Uint_8	1	Sixth part of MAC address	0 ...+255d (00...FF)	00 ... FF

Table 373: Example: sRA EIMacAdr 00:06:77:22:40:EA

CoLa A	<STX>sRA{SPC}EIMacAdr{SPC}0{SPC}6{SPC}77{SPC}22{SPC}40{SPC}EA<ETX>					
	02 73 52 41 20 45 49 4D 61 63 41 64 72 20 30 20 36 20 37 37 20 32 32 20 34 30 20 45 41 03					
CoLa B	02 02 02 02 00 00 00 13 73 52 41 20 45 49 4D 61 63 41 64 72 20 00 06 77 22 40 EA 8D					

12.2.1.4.9.8 Set baud rate for host interface [sWN SIHstBaud]

Define the rate in bits/s for the serial host interface.

Table 374: Telegram structure: sWN SIHstBaud

Telegram structure: sWN SIHstBaud (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set baud rate for host interface	String	9		SIHstBaud	53 49 48 73 74 42 61 75 64
Baud rate data	Baud rate data for host interface	Enum_8	1	9600: 19200: 38400: 57600: 115200: 250000: 500000:	+5d (05h) +6d (06h) +7d (07h) +8d (08h) +9d (09h) +10d (0Ah) +11d (0Bh)	05 06 07 08 09 0A 0B

Table 375: Example: sWN SIHstBaud

CoLa A	<STX>sWN{SPC}SIHstBaud{SPC}+8<ETX>					
	<STX>sWN SIHstBaud +8<ETX>					
	sWN SIHstBaud +8					
	02 73 57 4E 20 53 49 48 73 74 42 61 75 64 20 08 03					
CoLa B	02 02 02 02 00 00 00 0F 73 57 4E 20 53 49 48 73 74 42 61 75 64 20 08 05					
	73 57 4E 20 53 49 48 73 74 42 61 75 64 20 08					

Table 376: Telegram structure: sWA SIHstBaud

Telegram structure: sWA SIHstBaud						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set baud rate for host interface	String	9		SIHstBaud	53 49 48 73 74 42 61 75 64

Table 377: Example: sWA SIHstBaud

CoLa A	<STX>sWA[SPC]SIHstBaud<ETX>					
	02 73 57 41 20 53 49 48 73 74 42 61 75 64 03					
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 53 49 48 73 74 42 61 75 64 20 02					

12.2.1.4.9.9 Read baud rate of host interface [sRN SIHstBaud]

Read the configured rate in bits/s of the serial host interface.

Table 378: Telegram structure: sRN SIHstBaud

Telegram structure: sRN SIHstBaud						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read baud rate of host interface	String	9		SIHstBaud	53 49 48 73 74 42 61 75 64

Table 379: Example: sRN SIHstBaud

CoLa A	<STX>sRN[SPC]SIHstBaud<ETX>					
	<STX>sRN SIHstBaud<ETX>					
	sRN SIHstBaud					
	02 73 52 4E 20 53 49 48 73 74 42 61 75 64 03					
CoLa B	02 02 02 02 00 00 00 0D 73 52 4E 20 53 49 48 73 74 42 61 75 64 28					
	73 52 4E 20 53 49 48 73 74 42 61 75 64					

Table 380: Telegram structure: sRA SIHstBaud

Telegram structure: sRA SIHstBaud						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read baud rate of host interface	String	9		SIHstBaud	53 49 48 73 74 42 61 75 64

Telegram structure: sRA SIHstBaud						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Baud rate data	Baud rate data of host interface	Enum_8	1	9600: 19200: 38400: 57600: 115200: 250000: 500000:	5d (05h) 6d (06h) 7d (07h) 8d (08h) 9d (09h) 10d (0Ah) 11d (0Bh)	05 06 07 08 09 0A 0B

Table 381: Example: sRA SIHstBaud

CoLa A	<STX>sRA{SPC}SIHstBaud{SPC}8<ETX>					
	02 73 52 41 20 53 49 48 73 74 42 61 75 64 20 08 03					
CoLa B	02 02 02 02 00 00 00 0F 73 52 41 20 53 49 48 73 74 42 61 75 64 20 08 0F					

12.2.1.4.9.10 Set interface type [sWN SIHstHw]

Define connection type of the serial interface.

Table 382: Telegram structure: sWN SIHstHw

Telegram structure: sWN SIHstHw (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set hardware settings for host interface	String	7		SIHstHw	53 49 48 73 74 48 77
Interface type data	Hardware settings data for host interface	Enum_8	1	TX_RS232: TX_RS485_2WIRE: TX_RS422_485_4WIRE:	0 1 2	00 01 02

Table 383: Example: sWN SIHstHw

CoLa A	<STX>sWN{SPC}SIHstHw{SPC}0<ETX>					
	<STX>sWN SIHstHw 0<ETX>					
	sWN SIHstHw 0					
	02 73 57 4E 20 53 49 48 73 74 48 77 20 30 03					
CoLa B	02 02 02 02 00 00 00 0D 73 57 4E 20 53 49 48 73 74 48 77 20 00 00					
	73 57 4E 20 53 49 48 73 74 48 77 20 00					

Table 384: Telegram structure: sWA SIHstHw

Telegram structure: sWA SIHstHw						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set hardware settings for host interface	String	7		SIHstHw	53 49 48 73 74 48 77

Table 385: Example: sWA SIHstHw

CoLa A	<STX>sWA{SPC}SIHstHw<ETX>					
	02 73 57 41 20 53 49 48 73 74 48 77 03					
CoLa B	02 02 02 02 00 00 00 0C 73 57 41 20 53 49 48 73 74 48 77 20 0F					

12.2.1.4.9.11 Read interface type [sRN SIHstHw]

Read the connection type of the serial interface.

Table 386: Telegram structure: sRN SIHstHw

Telegram structure: sRN SIHstHw						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Read hardware settings of host interface	String	7		SIHstHw	53 49 48 73 74 48 77

Table 387: Example: sRN SIHstHw

CoLa A	<STX>sRN{SPC}SIHstHw<ETX>					
	<STX>sRN SIHstHw<ETX>					
	sRN SIHstHw					
	02 73 52 4E 20 53 49 48 73 74 48 77 03					
CoLa B	02 02 02 02 00 00 00 0B 73 52 4E 20 53 49 48 73 74 48 77 25					
	73 52 4E 20 53 49 48 73 74 48 77					

Table 388: Telegram structure: sRA SIHstHw

Telegram structure: sRA SIHstHw						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sRA	73 52 41
Command	Read hardware settings of host interface	String	7		SIHstHw	53 49 48 73 74 48 77
Interface type data	Hardware settings data of host interface	Enum_8	1	TX_RS232: TX_RS485_2WIRE: TX_RS422_485_4WIRE:	0 1 2	00 01 02

Table 389: Example: sRA SIHstHw

CoLa A	<STX>sRA{SPC}SIHstHw{SPC}0<ETX>					
	02 73 57 41 20 53 49 48 73 74 48 77 20 00 03					
CoLa B	02 02 02 02 00 00 00 0D 73 52 41 20 53 49 48 73 74 48 77 20 00 0A					

12.2.1.4.9.12 Set Host/ UDP port number [sWN EIHstPort, sWN EIUDPPort]

Define the TCP/IP host or UDP port number.

Table 390: Telegram structure: sWN EIHstPort

Telegram structure: sWN EIHstPort (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Read hardware settings of host interface	String	7	Ethernet host TCP/ IP Ethernet host UDP/ IP	EIHstPort EIUDPPort	45 49 48 73 74 50 6F 72 74 45 49 55 44 50 50 6F 72 74
Port number	Host port number (Default = 2112)	Uint_16	2		+0d ... +65535d (0h ... FF FFh)	00 00 ... FF FF

Example: sWN EIHstPort +2110 (Host Port 2110)

Table 391: Example: sWN EIHstPort +2110

CoLa A	<STX>sWN{SPC}EIHstPort{SPC}+2110<ETX>					
	<STX>sWN EIHstPort +2110<ETX>					
	sWN EIHstPort +2110					
	02 73 57 4E 20 45 49 48 73 74 50 6F 72 74 20 2B 32 31 31 30 03					
CoLa B	02 02 02 02 00 00 00 10 73 57 4E 20 45 49 48 73 74 50 6F 72 74 20 08 3E 26					
	73 57 4E 20 45 49 48 73 74 50 6F 72 74 20 08 3E					

Example: sWN EIUDPPort +2214 (UDP Port 2214)

Table 392: Example: sWN EIUDPPort +2214

CoLa A	<STX>sWN{SPC}EIUDPPort{SPC}+2214<ETX>					
	<STX>sWN EIUDPPort +2214<ETX>					
	sWN EIUDPPort +2214					
	02 73 57 4E 20 45 49 55 44 50 50 6F 72 74 20 2B 32 32 31 34 03					
CoLa B	02 02 02 02 00 00 00 10 73 57 4E 20 45 49 55 44 50 50 6F 72 74 20 08 A6 B0					
	73 57 4E 20 45 49 55 44 50 50 6F 72 74 20 08 A6					

Table 393: Telegram structure: sWA EIHstPort

Telegram structure: sWA EIHstPort						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Read hardware settings of host interface	String	7	Ethernet host TCP/ IP Ethernet host UDP/ IP	EIHstPort EIUDPPort	45 49 48 73 74 50 6F 72 74 45 49 55 44 50 50 6F 72 74

Example: sWA EIHstPort (Host Port)

Table 394: Example: sWA EIHstPort

CoLa A	<STX>sWA{SPC}EIHstPort<ETX>					
	02 73 57 41 20 45 49 48 73 74 50 6F 72 74 03					

CoLa B 02 02 02 02 00 00 00 0E 73 57 41 20 45 49 48 73 74 50 6F 72 74 20 1F

Example: sWA EIUDPPort (UDP Port)

Table 395: Example: sWA EIUDPPort

CoLa A	<STX>sWA[SPC]EIUDPPort<ETX>
	02 73 57 41 20 45 49 55 44 50 50 6F 72 74 03
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 45 49 55 44 50 50 6F 72 74 20 11

12.2.1.4.9.13 Set Host port Command Language (CoLa dialect) [sWN EIHstCola]

Define the communication language (SICK specific) of the TCP/IP host port.

NOTE
It is not allowed to use this telegram in a faster cycle than 10 ms!
After switching the CoLa dialect by this telegram, you have to store the changes permanently and reboot the sensor to activate the chosen CoLa dialect.
Binary CRC32 is available since the firmware version V1.80.0

Table 396: Telegram structure: sWN EIHstCola

Telegram structure: sWN EIHstCola (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set hardware settings of host interface	String	7		EIHstCola	45 49 48 73 74 43 6F 6C 61
Command language	Host port Command language	Enum_8	1	CoLa ASCII: CoLa binary: Binary CRC32:	0 1 2	00 01 02

Example: sWN EIHstCola 1 (Host Port CoLa binary)

Table 397: Example: sWN EIHstCola 1

CoLa A	<STX>sWN[SPC]EIHstCola[SPC]1<ETX>					
	<STX>sWN EIHstCola 1<ETX>					
	sWN EIHstCola 1					
	02 73 57 4E 20 45 49 48 73 74 43 6F 6C 61 20 31 03					
CoLa B	02 02 02 02 00 00 00 0F 73 57 4E 20 45 49 48 73 74 43 6F 6C 61 20 01 09					
	73 57 4E 20 45 49 48 73 74 43 6F 6C 61 20 01					

Table 398: Telegram structure: sWA EIHstCola

Telegram structure: sWA EIHstCola						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set hardware settings of host interface	String	7		EIHstCola	45 49 48 73 74 43 6F 6C 61

Example: sWA EIHstCola (Host Port)

Table 399: Example: sWA EIHstCola

CoLa A	<STX>sWA[SPC]EIHstCola<ETX> 02 73 57 41 20 45 49 48 73 74 43 6F 6C 61 03
CoLa B	02 02 02 02 00 00 00 0E 73 57 41 20 45 49 48 73 74 43 6F 6C 61 20 07

12.2.1.4.9.14 Enable/Disable Front Panel [sWN LMLfpen]

The following telegram LMLfpen corresponds to the SOPAS GUI check box “Display active”.

Display

Display active ☒

Function LED Q1 Q2 Application

7-segment display Application

Table 400: Telegram structure: sWN LMLfpen

Telegram structure: sWN LMLfpen (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set front panel display and serial aux interface	String	7		LMLfpen	4C 4D 4C 66 70 65 6E
Status	Enable/Disable (Active/inactive)	Bool_1	1	Enable (Active): Disable (Inactive):	1 0	01 00

Table 401: Example: sWN LMLfpen 1 (Enable Front Panel)

CoLa A	<STX>sWN[SPC]LMLfpen[SPC]1<ETX>					
	<STX>sWN LMLfpen 1<ETX>					
	sWN LMLfpen 1					
	02 73 57 4E 20 4C 4D 4C 66 70 65 6E 20 31 03					
CoLa B	02 02 02 02 00 00 00 0D 73 57 4E 20 4C 4D 4C 66 70 65 6E 20 01 3B					
	73 57 4E 20 4C 4D 4C 66 70 65 6E 20 01					

Table 402: Telegram structure: sWA LMLfpen

Telegram structure: sWA LMLfpen						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set front panel display and serial aux interface	String	7		LMLfpen	4C 4D 4C 66 70 65 6E

Table 403: Example: sWA LMLfpn

CoLa A	<STX>sWA{SPC}LMLfpn<ETX>
	02 73 57 41 20 4C 4D 4C 66 70 65 6E 03
CoLa B	02 02 02 02 00 00 00 0C 73 57 41 20 4C 4D 4C 66 70 65 6E 20 35

Activating state dependent in LMS531 Security:

- For LMS5xx Security sensors telegram LLMfpmode corresponds to the selection of Mode between State dependent (the mode is dependent on the state of the selection of Arm / Disarmed / Walk Test) or Permanent (the always active mode).
- Only available with firmware versions > V2.01.

Display

Display and USB enable/disable ☒

Mode State dependent

Function LED Q1 Q2 Application

7-segment display Application

Display

Display and USB enable/disable ☒

Mode Permanent

Function LED Q1 Q2 Application

7-segment display Application

Table 404: Telegram structure: sWN LLMfpmode

Telegram structure: sWN LLMfpmode (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3	LMS531 Security	sWN	73 57 4E
Command	Set front panel display and serial aux interface	String	7	LMS531 Security	LLMfpmode	4C 4C 4D 66 70 6D 6F 64 65
Status	Enable/Disable (Active/inactive)	Bool_1	1	LMS531 Security Permanent (active): State dependent (Inactive):	0 1	00 01

Example: sWN LLMfpmode

Table 405: Example: sWN LLMfpmode 0 (set to "Permanent")

CoLa A	<STX>sWN{SPC}LLMfpmode {SPC}1<ETX>	
	<STX>sWN LLMfpmode 1<ETX>	
	sWN LLMfpmode 1	
	02 73 57 4E 20 4C 4C 4D 66 70 6D 6F 64 65 20 31 03	
CoLa B	02 02 02 02 00 00 00 0D 73 57 4E 20 4C 4C 4D 66 70 6D 6F 64 65 20 00 12	
	73 57 4E 20 4C 4C 4D 66 70 6D 6F 64 65 20 00	

Table 406: Telegram structure: sWA LLMfpmode

Telegram structure: sWA LLMfpmode						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3	LMS531 Security	sWA	73 57 41
Command	Set front panel display and serial aux interface	String	7	LMS531 Security	LLMfpmode	4C 4C 4D 66 70 6D 6F 64 65

Table 407: Example: sWA LLMfpmode

CoLa A	<STX>sWA{SPC}LLMfpmode <ETX>
	02 73 57 41 20 4C 4C 4D 66 70 6D 6F 64 65 03
CoLa B	02 02 02 02 00 00 00 0C 73 57 41 20 4C 4D 4C 66 70 65 6E 20 3D

12.2.1.4.9.15 Set function front panel [sWN LMLfpFcn]

Configure the function of the status LEDs and the 7-segment display on the device housing.

Table 408: Telegram structure: sWN LMLfpFcn

Telegram structure: sWN LMLfpFcn (User level 'Authorized client' required)						
Telegram part	Description	Variable	Length	Sensor	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Write	String	3		sWN	73 57 4E
Command	Set function of the front panel	String	8		LMLfpFcn	4C 4D 4C 66 70 46 63 6E
Reserved	Reserved	Bool_1	1		1	01
LED function Q1/Q2	Code number	Enum_8	1	No function:	0	00
				Application:	1	01
				Command:	2	02
LED function OK/Stop	Code number	Enum_8	1	Application:	0	00
				Command:	1	01
Display function	Code number	Enum_8	1	No function:	0	00
				Application:	1	01
				Command:	2	02

Table 409: Example: sWN LMLfpFcn

CoLa A	<STX>sWN{SPC}LMLfpFcn{SPC}1{SPC}1{SPC}0{SPC}1<ETX>
	<STX>sWN LMLfpFcn 1 1 0 1<ETX>
	sWN LMLfpFcn 1 1 0 1
	02 73 57 4E 20 4C 4D 4C 66 70 46 63 6E 20 31 20 31 20 30 20 31 03
CoLa B	02 02 02 02 00 00 00 11 73 57 4E 20 4C 4D 4C 66 70 46 63 6E 20 01 01 00 01 7B
	73 57 4E 20 4C 4D 4C 66 70 46 63 6E 20 01 01 00 01

Table 410: Telegram structure: sWA LMLfpFcn

Telegram structure: sWA LMLfpFcn						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer	String	3		sWA	73 57 41
Command	Set function of the front panel	String	8		LMLfpFcn	4C 4D 4C 66 70 46 63 6E

Table 411: Example: sWA LMLfpFcn

CoLa A	<STX>sWA{SPC}LMLfpFcn<ETX> 02 73 57 41 20 4C 4D 4C 66 70 46 63 6E 03
CoLa B	02 02 02 02 00 00 00 0D 73 57 41 20 4C 4D 4C 66 70 46 63 6E 75

12.2.1.4.9.16 Set 7-segment display to specific symbol or number [sMN mLMLSetDisp]



NOTE

Preconditions:

It is mandatory to define that the 7-segment display should react to SOPAS commands. This option needs to be activated via sWN LMLfpFcn or using the configuration software SOPAS ET. Choose “SOPAS command” in the drop-down list for the 7-segment display (as shown in the figure below). Afterwards the segments of the display can be set via telegram.


Display

Display active ☒

Function LED Q1 Q2 Application

7-segment display SOPAS command

The display is consisting of the segments a-p:



The segments a-g are operated using the bits 0 to 6, the segment p using bit 7:

Segment	p	g	f	e	d	c	b	a
Related bit	7	6	5	4	3	2	1	0

Example: Showing the number “7” on the display:

Segment	p	g	f	e	d	c	b	a
On/Off for showing the required symbol	off	off	off	off	off	on	on	on
Binary	0	0	0	0	0	1	1	1

Transfer binary into ASCII:

00000111 bin $\triangleq$ 07 ASCII

Table 412: Telegram structure: sMN mLMLSetDisp

Telegram structure: sMN mLMLSetDisp						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Request (SOPAS method by name)	String	3		sMN	73 4D 4E
Command	Set 7-segment display	String	11		mLMLSetDisp	6D 4C 4D 4C 53 65 74 44 69 73 70
Display	7-segment display in the display of the LMS. The segments A-G are operated using the bits 0 to 6, the point P using bit 7.	Uint_8	1	Display off: ... Display shows 2: Display shows 7: ... Display completely on (8.):	0 ... 5Bh 7 ... FFh	00 ... 5B 07 ... FF

Table 413: Example: sMN mLMLSetDisp 07 (Showing the number “7” on the display)

CoLa A	<STX>sMN{SPC}mLMLSetDisp{SPC}07<ETX>	
	<STX>sMN mLMLSetDisp 07<ETX>	
	sMN mLMLSetDisp 07	
	02 73 4D 4E 20 6D 4C 4D 4C 53 65 74 44 69 73 70 20 30 37 03	

CoLa B	02 02 02 02 00 00 00 11 73 4D 4E 20 6D 4C 4D 4C 53 65 74 44 69 73 70 20 07 3B
	73 4D 4E 20 6D 4C 4D 4C 53 65 74 44 69 73 70 20 07

Table 414: Telegram structure: sAN mLMSetDisp

Telegram structure: sAN mLMSetDisp						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Answer (SOPAS answer)	String	3		sAN	73 41 4E
Command	Set 7-segment display	String	11		mLMSetDisp	6D 4C 4D 4C 53 65 74 44 69 73 70
ErrorCode	The command has been accepted if the error code 1 is returned.	Enum8	1	Error: No error:	0 1	00 01

Table 415: Example: sAN mLMSetDisp 1

CoLa A	<STX>sAN{SPC}mLMSetDisp{SPC}1<ETX>
CoLa B	02 73 41 4E 20 6D 4C 4D 4C 53 65 74 44 69 73 70 20 31 03
CoLa B	02 02 02 02 00 00 00 11 73 41 4E 20 6D 4C 4D 4C 53 65 74 44 69 73 70 20 01 31

12.2.1.4.10 Application

12.2.1.4.10.1 Request status change of monitoring fields on event [sEN ECRChangeArr]



NOTE

Preconditions:

Necessary sensor setup:

- Setup detection fields.
- Setup evaluation cases and assign outputs to the evaluation cases. Evaluation of EVC without connected output possible with firmware versions > V2.10.

Advantage of this telegram:

- Status of the evaluation case (1=field free, 2=detecting or 3=infringement) is transmitted if there is a status change of the monitoring field within the application.
- For example if the object size in the field exceeds the set object size parameter but the duration of the object inside the field is below the set time parameter. Then the status change from “field free” to “detecting” will be given out via telegram.

Necessary procedure after each power up of the device:

- Establish Ethernet connection to the device
- If the user wants to register an event, it is necessary to send a telegram to register it each time after establishing connection

Table 416: Telegram structure: sEN ECRChangeArr

Telegram structure: sEN ECRChangeArr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEN	73 45 4E

Telegram structure: sEN ECRChangeArr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Data telegram	String	12		ECRChangeArr	45 43 52 43 68 61 6E 67 65 41 72 72
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 417: Example: sEN ECRChangeArr 1

CoLa A	<STX>sEN{SPC}ECRChangeArr{SPC}1<ETX>	
	<STX>sEN ECRChangeArr 1<ETX>	
	sEN ECRChangeArr 1	
	02 73 45 4E 20 45 43 52 43 68 61 6E 67 65 41 72 72 20 31 03	
CoLa B	02 02 02 02 00 00 00 12 73 45 4E 20 45 43 52 43 68 61 6E 67 65 41 72 72 20 01 4A	
	73 45 4E 20 45 43 52 43 68 61 6E 67 65 41 72 72 20 01	

Table 418: Telegram structure: sEA ECRChangeArr

Telegram structure: sEA ECRChangeArr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEA	73 45 41
Command	Data telegram	String	12		ECRChangeArr	45 43 52 43 68 61 6E 67 65 41 72 72
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 419: Example: sEA ECRChangeArr 1

CoLa A	<STX>sEA{SPC}ECRChangeArr{SPC}1<ETX>	
	02 73 45 41 20 45 43 52 43 68 61 6E 67 65 41 72 72 20 31 03	
CoLa B	02 02 02 02 00 00 00 12 73 45 41 20 45 43 52 43 68 61 6E 67 65 41 72 72 20 01 45	

NOTE
The answer to the telegram will be followed by data that is sent on event.
The sensor only sends the following answer if there is a status change of the evaluation case within the application.

Table 420: Telegram structure: sSN ECRChangeArr

Telegram structure: sSN ECRChangeArr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sSN	73 53 4E
Command	Data telegram	String	12		ECRChangeArr	45 43 52 43 68 61 6E 67 65 41 72 72

Telegram structure: sSN ECRChangeArr						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
System counter	Time in μ s since power up max. 71 min then starting from 0 again	UInt_32	4		0 ... FFFFFFFFh	00 00 00 00 ... FF FF FF FF
Array	1-10	UInt_16	2		0h ... Ah (0d ... 10d)	00 01 ... 00 0A
EVC number	1-10	UInt_8	1		0h ... Ah (0d ... 10d)	00 01 ... 00 0A
Object detection		Enum_8	1	field free detecting infringement	1 2 3	01 02 03
Year		UInt_16	2		0000h ... 270Fh (0d... 9999d)	00 00 ... 27 0F
Month	1 to 12	UInt_8	1		00h ... 0Ch (0d ... 12d)	00 ... 0C
Day	Day of month 1 to 31	UInt_8	1		00h ... 1Fh (0d ... 31d)	00 ... 1F
Hour	0 to 23	UInt_8	1		00h ... 17h (0d ... 23d)	00 ... 17
Minute	0 to 59	UInt_8	1		00h ... 3Bh (0d ... 59d)	00 ... 3B
Second	0 to 59	UInt_8	1		00h ... 3Bh (0d ... 59d)	00 ... 3B
μ Second	0 to 9999999	UInt_32	4		00000000h ... 000F423Fh (0d ... 9999999d)	00 00 00 00 ... 00 0F 42 3F

Table 421: Example: sSN ECRChangeArr 1

CoLa A	<STX>sSN{SPC}ECRChangeArr{SPC}498986CC{SPC}1{SPC}1{SPC}1{SPC}7E7{SPC}B{SPC}17{SPC}B{SPC}10{SPC}14{SPC}DC758<ETX>
CoLa B	02 02 02 02 00 00 00 24 73 53 4E 20 45 43 52 43 68 61 6E 67 65 41 72 72 20 49 89 86 CC 00 01 01 01 07 E7 0B 17 0B 10 14 00 0D C7 58 B7

12.2.1.4.10.2 Individual request of monitoring fields to their status changes – ECR xy [sRN ECRxy]



NOTE

The telegram “ECRxy” available with firmware versions > V2.10.

Preconditions:

Necessary sensor setup:

- Setup detection fields.
- Setup evaluation cases.
- Setup output assignments to the evaluation cases. Evaluation of EVC without connected output possible from firmware version V2.10

Necessary proceeding after each Laser Scanner power up:

- Establish Ethernet connection to the device.
- If the user wants to register an event, it is necessary to send a telegram to register it each time after establishing connection.

Read/Poll the status of an evaluation case

It is possible to send (poll repeatedly) this telegram to Ethernet port 2111 or Ethernet port 2112 to check the evaluation status.

Table 422: Telegram structure: sRN ECRxy

Telegram structure: sRN ECRxy						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Data telegram	String	12	Concrete number should be used for xy as shown below: Evaluation1: Evaluation2: ... Evaluation10:	ECRxy ECR01 ECR02 ... ECR10	45 43 52 30 31 45 43 52 30 32 ... 45 43 52 31 30

Table 423: Example: sRN ECR01

CoLa A	<STX>sRN{SPC}ECR01<ETX>	
	<STX>sRN ECR01<ETX>	
	sRN ECR01	
	02 73 52 4E 20 45 43 52 30 31 03	
CoLa B	02 02 02 02 00 00 00 09 73 52 4E 20 45 43 52 30 31 1A	
	73 52 4E 20 45 43 52 30 31	

The response telegram is shown in Telegram structure: sRA/ sSN ECRxy

Register an event to get the status update of an evaluation

It is also possible to register an event by “sEN ECRxy” for receiving the change of the an evaluation. So, when there a change happens in the field of this evaluation, an update telegram will be sent out automatically.

The registration telegram format is: sEN ECRxy 0/1 (shown below)

Table 424: Telegram structure: sEN ECRxy

Telegram structure: sEN ECRxy						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEN	73 45 4E
Command	Data telegram	String	12	Concrete number should be used for xy as shown below: Evaluation1: Evaluation2: ... Evaluation10:	ECRxy ECR01 ECR02 ... ECR10	45 43 52 30 31 45 43 52 30 32 ... 45 43 52 31 30
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 425: Example: sEN ECR01 1

CoLa A	<STX>sEN{SPC}ECR01{SPC}1<ETX>			
	<STX>sEN ECR01 1<ETX>			
	sEN ECR01 1			
	02 73 45 4E 20 45 43 52 30 31 20 31 03			
CoLa B	02 02 02 02 00 00 00 0B 73 45 4E 20 45 43 52 30 31 20 01 2C			
	73 45 4E 20 45 43 52 30 31 20 01			

Table 426: Telegram structure: sEA ECRxy

Telegram structure: sEA ECRxy						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEA	73 45 41
Command	Data telegram	String	12	Concrete number should be used for xy as shown below: Evaluation1: Evaluation2: ... Evaluation10:	ECRxy ECR01 ECR02 ... ECR10	45 43 52 30 31 45 43 52 30 32 ... 45 43 52 31 30
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 427: Example: sEA ECR01 1

CoLa A	<STX>sEA{SPC}ECR01{SPC}1<ETX>			
	02 73 45 41 20 45 43 52 30 31 20 01 03			
CoLa B	02 02 02 02 00 00 00 0B 73 45 41 20 45 43 52 30 31 20 01 23			

**NOTE**

- The event registration is not a parameter and cannot be saved permanently. Therefore it is necessary to send the telegram to register an event each time after establishing a connection to the device (especially, when the Ethernet port is in server mode).
- Ethernet port 2112 has a special function and can be set as client mode (as shown in Figure 1). Then, the corresponding telegram can be selected for the expected evaluation (for example evaluation 1, as shown below). There is no further need to manually register an event by sending a separate telegram. When there is a change in the registered field evaluation, LMS531 will automatically connect to the specified server (such as 192.168.0.11, as shown below) to send an update telegram. If the settings are saved permanently, this is the same situation even after the sensor power cycle.

Ethernet host port

CoLa dialect

CoLa ASCII

To apply a new COLA dialect a device reset is necessary.
Parameters have to be saved permanently, before.

Server / client

Client

Server port

2112

Server IP address

192 . 168 . 0 . 11

Available events

Name	Subscribed
ECRChangeArr	☐
LMDscandata	☐
LIDoutputstate	☐
ECR01	☒
ECR02	☐
ECR03	☐
ECR04	☐
ECR05	☐
ECR06	☐
ECR07	☐
ECR08	☐
ECR09	☐
ECR10	☐

Figure 75: Ethernet host port setting (LMS531)

The response telegram to “sRN ECRxy” and the event status update telegram for “sEA ECRxy 1” follows the format in table 7 as shown below.

Table 428: Telegram structure: sRA/sSN ECRxy

Telegram structure: sRA/sSN ECRxy						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3	for sRN ECRxy: for sEN ECRxy:	sRA sSN	73 52 41 73 53 4E

Telegram structure: sRA/sSN ECRxy						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Data telegram	String	12	Concrete number should be used for xy as shown below: Evaluation1: Evaluation2: ... Evaluation10:	ECRxy ECR01 ECR02 ... ECR10	45 43 52 30 31 45 43 52 30 32 ... 45 43 52 31 30
Reporting	Object detection	Enum_8	1	DON'T CARE: FIELD FREE: DETECTING: INFRINGEMENT:	0 1 2 3	00 01 02 03
Time-stamp	Transmisssion time stamp of the current telegram (unit:µs)	Uint_32	4		00000000h.... FFFFFFFh	00 00 00 00 ... FF FF FF FF
Year		Uint_16	2		0000h ... 270Fh (0d... 9999d)	00 00 ... 27 0F
Month	1 to 12	Uint_8	1		00h ... 0Ch (0d ... 12d)	00 ... 0C
Day	Day of month 1 to 31	Uint_8	1		00h ... 1Fh (0d ... 31d)	00 ... 1F
Hour	0 to 23	Uint_8	1		00h ... 17h (0d ... 23d)	00 ... 17
Minute	0 to 59	Uint_8	1		00h ... 3Bh (0d ... 59d)	00 ... 3B
Second	0 to 59	Uint_8	1		00h ... 3Bh (0d ... 59d)	00 ... 3B
µSecond	0 to 99999999	Uint_32	4		00000000h ... 000F423Fh (0d ... 999999d)	00 00 00 00 ... 00 0F 42 3F


Table 429: Example: sRA ECR01

CoLa A	<STX>sRA{SPC}ECR01{SPC}1{SPC}684E451D 7B2 1 1 0 1D 9 D7938<ETX>
CoLa B	02 02 02 02 00 00 00 1A 73 53 4E 20 45 43 52 30 31 20 01 68 4E 45 1D 07 B2 01 01 00 1D 09 00 0D 79 38 A9

12.2.1.4.10.3 Request SOPAS field data structure [sMN mLFEgetField]

The SOPAS telegram `mLFEgetField` requests a field number as parameter and returns the corresponding SOPAS field data structure. If the field number is number is not configured, the answer telegram will be filled with 0.

Example – Request the field data structure of an evaluation field (field number: 1) that has been parameterized in the engineering tool SOPAS.



The answer telegram will include information regarding the field data structure of the requested evaluation field (type: segmented, number of field points etc.)

Please note: The sensor will switch to the state “Stop measurement” during read out. After the read out you have to switch the sensor back to “Run measurement”.

Table 430: Telegram structure: sMN mLFEgetField

Telegram structure: sMN mLFEgetField (User level 'Authorized Client' required)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Request	String	3		sMN	73 4D 4E
Command	Only one telegram	String	14		mLFEgetField	6D 4C 46 45 67 65 74 46 69 65 6C 64
Command		UInt_32	4		1 ... 10	00 00 00 01 ... 00 00 01 01

Table 431: Example: sMN mLFEgetField 1

CoLa A	<STX>sMN{SPC}mLFEgetField{SPC}1<ETX>		 
	<STX>sMN mLFEgetField 1<ETX>		
	sMN mLFEgetField 1		
	02 73 4D 4E 20 6D 4C 46 45 67 65 74 46 69 65 6C 64 20 31 03		
CoLa B	02 02 02 02 00 00 00 15 73 4D 4E 20 6D 4C 46 45 67 65 74 46 69 65 6C 64 20 00 00 00 01 67		
	73 4D 4E 20 6D 4C 46 45 67 65 74 46 69 65 6C 64 20 00 00 00 01		 

Table 432: Example: sAN mLFEgetField

Telegram structure: sAN mLFEgetField						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (binary)
Read		String	3		sAN	73 41 4E
Command	Only one telegram	String	14		mLFEgetField	6D 4C 46 45 67 65 74 46 69 65 6C 64
Field header						
Distance Scale Factor	Scale factor or factor of the measurement values (this depends on the angular resolution)	Real as float according to IEEE754	4	Factor x 1: Factor x 2:	3F800000h 40000000h	3F 80 00 00 40 00 00 00
Distance Scale Offset	Sets starting point of measurement	Real as float according to IEEE754	4	No offset:	00000000	00 00 00 00
Angle Scale Factor	Angle resolution	UInt_32	4	0.042°: 0.083°: 0.1667°: 0.25°: 0.333°: 0.5°: 0.667°: 1°:	+0417d (01A1h) +0833d (0341h) +1667d (683h) +2500d (9C4h) +3333d (D05h) +5000d (1388h) +6667d (1A0Bh) +10000d (2710h)	00 00 01 A1 00 00 03 41 00 00 06 83 00 00 09 C4 00 00 0D 05 00 00 13 88 00 00 1A 0B 00 00 27 10
Angle Scale Offset	Starting angle	Int_32	4		-50000d ... +1850000d (FFFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
Field type		Enum_8	1	Radial: Rectangle: Segmented: Dynamic:	0 1 2 3	00 01 02 03
Field number		UInt_8	1		0 ... Ah	00 ... 0A
Segmented field						
Segmented field configured		UInt_16	2	No data for segmented field available, i.e. field type is not segmented field: Data for segmented field available:	0 1	00 00 00 01

Telegram structure: sAN mLFEGeetField						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (binary)
Only shown if field type is configured	Number of field points	Uint_16	2	0 ... 571:	0h ... 23Bh	00 00 ... 02 3B
	Angle index n	Uint_16	2	0 ... 1140:	0h ... 0474h	00 00 ... 04 74
	Start distance	Uint_16	2	0 ... 65535:	0h ... FFFFh	00 00 ... FF FF
	End distance	Uint_16	2	0 ... 65535:	0h ... FFFFh	00 00 ... FF FF
	Angle index n+1	...	...	...	...	...
	Start distance	...	...	...	...	...
	End distance	...	...	...	...	...
	...	...	...	...	...	...
Rectangular field						
Rectangular field configured		Uint_16	2	No data for rectangular field available, i.e. field type is not rectangular field: Data for rectangular field available:	0 1	00 00 00 01
Only shown if field type is configured	Angle of reference point	Int_32	4		-50000d ... +1850000d (FFFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
	Distance of reference point	Uint_16	2	0 ... 65535:	0h ... FFFFh	00 00 ... FF FF
	Rotation angle	Int_32	4		-1800000d ... 1800000d (FFE488C0h ... 001B7740h)	FF E4 88 C0 ... 00 1B 77 40
	Width	Uint_32	4		0 ... 4294967295d (0 ... FFFFFFFFh)	00 00 00 00 ... FF FF FF FF
	Length	Uint_32	4		0 ... 4294967295d (0 ... FFFFFFFFh)	00 00 00 00 ... FF FF FF FF
Radial field						
Radial field configured		Uint_16	2	Radial fields are not available	0	00 00
Dynamic field						
Dynamic field configured		Uint_16	2	No data for dynamic field available, i.e. field type is not dynamic field Data for dynamic field available	0 1	00 00 00 01

Telegram structure: sAN mLFEGetField						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (binary)
Only shown if field type is configured	Angle of reference point	Int_32			-50000d ... +1850000d (FFFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
	Distance of reference point	Uint_16	2	0 ... 65535:	0h ... FFFFh	00 00 ... FF FF
	Rotation angle	Int_32	4		-1800000d ... 1800000d (FFE48C0h ... 001B7740h)	FF E4 88 C0 ... 00 1B 77 40
	Width	Uint_32	4		0 ... 4294967295d (0 ... FFFFFFFFh)	00 00 00 00 ... FF FF FF FF
	Length	Uint_32	4		0 ... 4294967295d (0 ... FFFFFFFFh)	00 00 00 00 ... FF FF FF FF
	Maximum speed	Int_16	2		0 ... 30000d (0 ... 7530h)	00 00 ... 75 30
	Maximum length	Uint_32	4		0 ... 4294967295d	00 00 00 00 ... FF FF FF FF
General						
Version number		Uint_16	2		0 ... 65535	00 00 ... FF FF
Length of field name		Uint_16	2		0 ... 32	00 00 ... 00 20
Field name		String	0 ... 32		FIELD1 FIELD2 FIELD3	46 49 45 4C 44 31 46 49 45 4C 44 32 46 49 45 4C 44 33
Reserved	-	Uint_16	2	Always:	0	0
Reserved	-	String	0 ... 128	Always:	0	0

Table 433: Example: sAN mLFEGetField

CoLa A	<STX>sAN{SPC}mLFEGetField{SPC}40000000{SPC}00000000{SPC}1388{SPC}FFFF3CB0{SPC}2{SPC}1{SPC}1{SPC}4{SPC}12{SPC}FFFF{SPC}F7{SPC}72{SPC}FFFF{SPC}18B{SPC}12D{SPC}FFFF{SPC}233{SPC}16D{SPC}FFFF{SPC}1DC{SPC}0{SPC}0{SPC}0{SPC}0{SPC}1{SPC}6{SPC}FIELD1{SPC}0<ETX>					
	02 73 41 4E 20 6D 4C 46 45 67 65 74 46 69 65 6C 64 20 34 30 30 30 30 30 30 20 30 30 30 30 30 30 30 30 20 31 33 38 38 20 46 46 46 46 33 43 42 30 20 32 20 31 20 31 20 34 20 31 32 20 46 46 46 46 20 46 37 20 37 32 20 46 46 46 46 20 31 38 42 20 31 32 44 20 46 46 46 46 20 32 33 33 20 31 36 44 20 46 46 46 46 20 31 44 43 20 30 20 30 20 30 20 31 20 36 20 46 49 45 4C 44 31 20 30 03					
CoLa B	02 02 02 02 00 00 00 51 73 41 4E 20 6D 4C 46 45 67 65 74 46 69 65 6C 64 20 40 00 00 00 00 00 00 00 00 00 00 13 88 FF FF 3C B0 02 01 00 01 00 04 00 12 FF FF 00 F7 00 72 FF FF 01 8B 01 2D FF FF 02 33 01 6D FF FF 01 DC 00 00 00 00 00 00 00 01 00 06 46 49 45 4C 44 31 00 00 FE					

12.2.1.4.10.4 Request minimal and maximal perpendicular distance once [sRN LFEperpdistresult]

Set the EVC to evaluation strategy "Min. perpendicular distance" or "Max. perpendicular distance" and choose the field which you would like to read out. The field evaluation will only be activated by choosing an output.



NOTE

Precondition:

Either evaluation strategy "Minimal perpendicular distance" or "Maximal perpendicular distance" has to be activated in the engineering tool SOPAS. After the according perpendicular distance value is displayed in SOPAS (as shown below), you are able to read out the telegram.

Evaluation strategy

Strategy Min. perpendicular distance
d: available by telegram "LFEperpdistresult", please see telegram listing.

Response time 500 ms

Corresponds to: 25 scans

Blanking size 200 mm

☒ Reference line 0°
☐ Reference line 90°
☐ Enter angle β : 45

Evaluation strategy

Strategy Max. perpendicular distance
d: available by telegram "LFEperpdistresult", please see telegram listing.

Response time 500 ms

Corresponds to: 25 scans

Blanking size 200 mm

☒ Reference line 0°
☐ Reference line 90°
☐ Enter angle β : 45




Table 434: Telegram structure: sRN LFEperpdistresult

Telegram structure: sRN LFEperpdistresult (no required user level)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Only one telegram	String	14		LFEperpdistresult	4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74

Table 435: Example: sRN LFEperpdistresult

CoLa A	<STX>sRN{SPC}LFEperpdistresult<ETX>					
	<STX>sRN LFEperpdistresult<ETX>					
	sRN LFEperpdistresult					
CoLa B	02 73 52 4E 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 03					
	02 02 02 02 00 00 00 15 73 52 4E 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 14					
	73 52 4E 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74					

Table 436: Telegram structure: sRA LFEperpdistresult

Telegram structure: sRA LFEperpdistresult (no required user level)						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRA	73 52 41
Command	Only one telegram	String	14		LFEperpdistresult	4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74

[illegible]

Table 437: Example: sRA LFEperpdistresult

	<STX>sRA{SPC} LFEperpdistresult{SPC}1{SPC}2{SPC}21A{SPC}0{SPC}0{SPC}0{SPC}21A{SPC}0{SPC}21A{SPC}DBBA0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0{SPC}0<ETX>
CoLa A	02 73 41 4E 20 6D 4C 46 45 67 65 74 46 69 65 6C 64 20 34 30 30 30 30 30 30 20 30 30 30 30 30 30 30 20 31 33 38 38 20 46 46 46 46 33 43 42 30 20 32 20 31 20 31 20 34 20 31 32 20 46 46 46 46 20 46 37 20 37 32 20 46 46 46 46 20 31 38 42 20 31 32 44 20 46 46 46 46 20 32 33 33 20 31 36 44 20 46 46 46 46 20 31 44 43 20 30 20 30 20 30 20 31 20 36 20 46 49 45 4C 44 31 20 30 03

CoLa B	02 02 02 02 00 00 00 61 73 52 41 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 20 00 01 02 00
	00 00
	00 00
	00 00 00 38

12.2.1.4.10.5 Request minimal and maximal perpendicular distance continuously on event [sEN LFEperpdistresult]

Set the EVC to evaluation strategy “Min. perpendicular distance” or “Max. perpendicular distance” and choose the field which you would like to read out. The field evaluation will only be activated by choosing an output.



NOTE

Precondition:

Either evaluation strategy "Minimal perpendicular distance" or "Maximal perpendicular distance" has to be activated in the engineering tool SOPAS. After the according perpendicular distance value is displayed in SOPAS (as shown below), you are able to read out the telegram.

Evaluation strategy

Strategy Min. perpendicular distance d: available by telegram "LFEperpdistresult", please see telegram listing.

Response time 500 ms

Corresponds to: 25 scans

Blanking size 200 mm

☒ Reference line 0° ☐ Reference line 90° ☐ Enter angle β : 45

Evaluation strategy

Strategy Max. perpendicular distance d: available by telegram "LFEperpdistresult", please see telegram listing.

Response time 500 ms

Corresponds to: 25 scans

Blanking size 200 mm

☒ Reference line 0° ☐ Reference line 90° ☐ Enter angle β : 45




Table 438: Telegram structure: sEN LFEperpdistresult

Telegram structure: sEN LFEperpdistresult						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEN	73 45 4E
Command	Only one telegram	String	14		LFEperpdistresult	4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 439: Example: sEN LFEperpdistresult 1

CoLa A	<STX>sEN{SPC}LFEperpdistresult{SPC}1<ETX>																
	<STX>sEN LFEperpdistresult 1<ETX>																
	sEN LFEperpdistresult 1																
	02 73 45 4E 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 20 31 03																
CoLa B	02 02 02 02 00 00 00 17 73 45 4E 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 20 01 22																
	73 45 4E 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 20 01																

Table 440: Telegram structure: sEA LFEperpdistresult

Telegram structure: sEA LFEperpdistresult						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEA	73 45 41

Telegram structure: sEA LFEperpdistresult						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Only one telegram	String	14		LFEperpdistresult	4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 441: Example: sEA LFEperpdistresult 1

CoLa A	<STX>sEA{SPC}LFEperpdistresult{SPC}1<ETX>
	02 73 45 41 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 20 01 03
CoLa B	02 02 02 02 00 00 00 17 73 45 41 20 4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74 20 01 2D

NOTE

The answer to the telegram will be followed by data that is sent on event.

The sensor only sends the following answer if there are perpendicular distance values calculated within the application.

Table 442: Telegram structure: sSN LFEperpdistresult

Telegram structure: sSN LFEperpdistresult						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sSN	73 53 4E
Command	Only one telegram	String	14		LFEperpdistresult	4C 46 45 70 65 72 70 64 69 73 74 72 65 73 75 6C 74
Array		UInt_16	2		0 ... 10d (0 ... Ah)	00 00 ... 00 0A
EVC number	1-10	UInt_8	1		0 ... 10d (0 ... Ah)	00 ... 0A
Perpendicular distance	0 m ... 80 m	UInt_32	4		0 ... 80000d (0 ... 13880h)	00 00 00 00 ... 00 01 38 80
Reserved	default 0	UInt_32	4		0	00 00 00 00
Reserved	default 0	UInt_32	4		0	00 00 00 00
X-Pos [mm]	0 m ... 80 m	Int_32	4		-80000d ... 80000d (FFFE780h ... 13880h)	FF FE C7 80 ... 00 01 38 80
Y-Pos [mm]	0 m ... 80 m	Int_32	4		-80000d ... 80000d (FFFE780h ... 13880h)	FF FE C7 80 ... 00 01 38 80
Reserved	default 0	Int_32	4		0	00 00 00 00

[illegible]

Table 443: Example: sSN LFEperpdistresult


[illegible]

12.2.1.4.10.6 Request latest field infringement info [sRN LFEinfringementinfo]

This command is used to request entries from the “field infringement logging” via telegram. Using this command, only the latest field infringement is given out. The answer telegram includes information regarding date and time of the infringement as well as the associated EVC and infringement position.

NOTE
Only a

Only activated EVCs will be considered. An EVC is only valid, when an output is defined in the EVC. Using this telegram, an EVC without a defined output is not taken into consideration.



Selection of evaluation cases

☒ 1 ☒ 2 ☒ 3 ☒ 4 ☒ 5 ☒ 6

Logging table

No.	Date	Time	Eval-case	X-Pos. [mm]	Y-Pos. [mm]	Angle [°]	Distance [mm]
1	01.01.1970	00:57:20,489	3	-567	462	140.8333	731

Table 444: Telegram structure: sRN LFEinfringementinfo

Telegram structure: sRN LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRN	73 52 4E
Command	Only one telegram	String	19		LFEinfringementinfo	4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F

Table 445: Example: sEN LFEinfringementinfo

CoLa A	<STX>sRN{SPC}LFEinfringementinfo<ETX>																
	<STX>sRN LFEinfringementinfo<ETX>																
	sRN LFEinfringementinfo																
	02 73 52 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 03																
CoLa B	02 02 02 02 00 00 00 17 73 52 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 0A																
	73 52 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F																

**NOTE**

The answer telegram refers to the latest recorded field infringement. Therefore the device outputs the latest field infringement entry from the logging table.

Table 446: Telegram structure: sRA LFEinfringementinfo

Telegram structure: sRA LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sRA	73 52 4E
Command	Only one telegram	String	19		LFEinfringementinfo	4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F
Time info						
Counter	continous counter of infrigements	Uint_16	2		0 ... 9999d (0 ... 270Fh)	00 00 ... 27 0F

Telegram structure: sRA LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Year		Uint_16	2		0 ... 9999d (0 ... 270Fh)	00 00 ... 27 0F
Month	1 to 12	Uint_8	1		0 ... 12d (0 ... Ch)	00 ... 0C
Day	Day of month 1 to 31	Uint_8	1		0 ... 31d (0 ... 1Fh)	00 ... 1F
Hour	0 to 23	Uint_8	1		0 ... 23d (0 ... 17h)	00 ... 17
Minute	0 to 59	Uint_8	1		0 ... 59d (0 ... 3Bh)	00 ... 3B
Second	0 to 59	Uint_8	1		0 ... 59d (0 ... 3Bh)	00 ... 3B
µSecond	0 to 999999	Uint_32	4		0 ... 999999d (0 ... 000F423Fh)	00 00 00 00 ... 00 0F 42 3F
Infringement-info						
EVC number	1-10	Uint_8	1		0 ... 10d (0 ... Ah)	00 ... 0A
X-Pos [mm]	0 ... 80 m	Int_32	4		-80000d ... 80000d (FFFE780h ... 13880h)	FF FE C7 80 ... 00 01 38 80
Y-Pos [mm]	0 ... 80 m	Int_32	4		-80000d ... 80000d (FFFE780h ... 13880h)	FF FE C7 80 ... 00 01 38 80
Distance [mm]	0 ... 80 m	Uint_32	4		0 ... 80000d (0h ... 13880h)	00 00 00 00 ... 00 01 38 80
Angle [°]	-5° ... 185°	Int_32	4		-50000d ... +1850000d (FFFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
Angle of Layer [°]	-5° ... 185°	Int_32	4		-50000d ... +1850000d (FFFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
Object size [mm]	0 ... 80 m	Uint_32	4		0 ... 80000d (0h ... 13880h)	00 00 00 00 ... 00 01 38 80

Table 447: Example: sRA LFEinfringementinfo

CoLa A	<STX>sRA{SPC}LFEinfringementinfo{SPC}4{SPC}7B2{SPC}1{SPC}1{SPC}2{SPC}32{SPC}1F{SPC}3A1B0{SPC}1{SPC}FFFFDAE{SPC}D6{SPC}277{SPC}187083{SPC}4A<ETX>
	02 73 52 41 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 34 20 37 42 32 20 31 20 31 20 32 20 33 32 20 31 46 20 33 41 31 42 30 20 31 20 46 46 46 46 46 44 41 45 20 44 36 20 32 37 37 20 31 38 37 30 38 33 20 34 41 03
CoLa B	02 02 02 02 00 00 00 3A 73 52 41 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 00 04 07 B2 01 01 02 32 1F 00 03 A1 B0 01 FF FF FD AE 00 00 00 D6 00 00 02 77 00 18 70 83 00 00 00 4A F9

12.2.1.4.10.7 Request field infringement info continuously on event [sEN LFEinfringementinfo]

The command is used to request entries from the “field infringement logging” via telegram. Using this command, a telegram will be sent from the sensor on event (in case of a new field infringement). The answer telegram includes information regarding date and time of the infringement as well as the associated EVC and infringement position.

NOTE Only activated EVCs will be considered. An EVC is only valid, when an output is defined in the EVC. Using this telegram, an EVC without a defined output is not taken into consideration.




Table 448: Telegram structure: sEN LFEinfringementinfo

Telegram structure: sEN LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sEN	73 45 4E
Command	Data telegram	String	19		LFEinfringementinfo	4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 449: Example: sEN LFEinfringementinfo 1

CoLa A	<STX>sEN{SPC}LFEinfringementinfo{SPC}1<ETX>					
	<STX>sEN LFEinfringementinfo 1<ETX>					
	sEN LFEinfringementinfo 1					
	02 73 45 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 31 03					
CoLa B	02 02 02 02 00 00 00 19 73 45 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 01 3C					
	73 45 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 01					

Table 450: Telegram structure: sEA LFEinfringementinfo

Telegram structure: sEA LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Event	String	3		sEA	73 45 41

Telegram structure: sEA LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command	Data telegram	String	19		LFEinfringementinfo	4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F
Reporting	Start/stop	Enum_8	1	Stop: Start:	0 1	00 01

Table 451: Example: sEA LFEinfringementinfo 1

CoLa A	<STX>sEA{SPC}LFEinfringementinfo{SPC}1<ETX>
	02 73 45 41 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 31 03
CoLa B	02 02 02 02 00 00 00 19 73 45 41 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 01 33

**NOTE**

The answer to the telegram is followed by data that is sent on event.

The sensor only sends the following data if there is a new field infringement detected and noted in the field infringement logging.

Table 452: Telegram structure: sSN LFEinfringementinfo

Telegram structure: sSN LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
Command type	Read	String	3		sSN	73 53 4E
Command	Data telegram	String	19		LFEinfringementinfo	4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F
Time info						
Counter	continious counter of infrigements	Uint_16	2		0 ... 9999d (0 ... 270Fh)	00 00 ... 27 0F
Year		Uint_16	2		0 ... 9999d (0 ... 270Fh)	00 00 ... 27 0F
Month	1 to 12	Uint_8	1		0 ... 12d (0 ... Ch)	00 ... 0C
Day	Day of month 1 to 31	Uint_8	1		0 ... 31d (0 ... 1Fh)	00 ... 1F
Hour	0 to 23	Uint_8	1		0 ... 23d (0 ... 17h)	00 ... 17
Minute	0 to 59	Uint_8	1		0 ... 59d (0 ... 3Bh)	00 ... 3B
Second	0 to 59	Uint_8	1		0 ... 59d (0 ... 3Bh)	00 ... 3B
µSecond	0 to 999999	Uint_32	4		0 ... 999999d (0 ... 000F423Fh)	00 00 00 00 ... 00 0F 42 3F
Infringement-info						

Telegram structure: sSN LFEinfringementinfo						
Telegram part	Description	Variable	Length	Additional details	Values CoLa A (ASCII)	Values CoLa B (Binary)
EVC number	1-10	Uint_8	1		0 ... 10d (0 ... Ah)	00 ... 0A
X-Pos [mm]	0 ... 80 m	Int_32	4		-80000d ... 80000d (FFEC780h ... 13880h)	FF FE C7 80 ... 00 01 38 80
Y-Pos [mm]	0 ... 80 m	Int_32	4		-80000d ... 80000d (FFEC780h ... 13880h)	FF FE C7 80 ... 00 01 38 80
Distance [mm]	0 ... 80 m	Uint_32	4		0 ... 80000d (0h ... 13880h)	00 00 00 00 ... 00 01 38 80
Angle [°]	-5° ... 185°	Int_32	4		-50000d ... +1850000d (FFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
Angle of Layer [°]	-5° ... 185°	Int_32	4		-50000d ... +1850000d (FFF3CB0h ... 1C3A90h)	FF FF 3C B0 ... 00 1C 3A 90
Object size [mm]	0 ... 80 m	Uint_32	4		0 ... 80000d (0h ... 13880h)	00 00 00 00 ... 00 01 38 80

Table 453: Example: sSN LFEinfringementinfo

CoLa A	<STX>sSN{SPC}LFEinfringementinfo{SPC}6{SPC}7B2{SPC}1{SPC}1{SPC}0{SPC}19{SPC}21{SPC}9D788{SPC}1{SPC}41{SPC}C3{SPC}0{SPC}CE{SPC}AE8F8{SPC}0{SPC}A8<ETX>
	02 73 53 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 36 20 37 42 32 20 31 20 31 20 30 20 31 39 20 32 31 20 39 44 37 38 38 20 31 20 34 31 20 43 33 20 30 20 43 45 20 41 45 38 46 38 20 30 20 41 38 03
CoLa B	02 02 02 02 00 00 00 40 73 53 4E 20 4C 46 45 69 6E 66 72 69 6E 67 65 6D 65 6E 74 69 6E 66 6F 20 00 06 07 B2 01 01 00 19 21 00 09 D7 88 01 00 00 00 41 00 00 00 C3 00 00 00 00 00 00 CE 00 0A E8 F8 00 00 00 00 00 A8 09

12.2.1.5 Diagnostics

12.2.1.5.1 SOPAS error codes

sFA ErrorCode

Table 454: SOPAS error codes

Telegram structure: sFA ErrorCode			
Error code	Description	Dec.	Hex.
Sopas_Ok	No error	0	0
Sopas_Error_METHODIN_ACCESSDENIED	Wrong userlevel, access to method not allowed	1	1
Sopas_Error_METHODIN_UNKNOWNINDEX	Trying to access a method with an unknown Sopas index	2	2
Sopas_Error_VARIABLE_UNKNOWNINDEX	Trying to access a variable with an unknown Sopas index	3	3

Telegram structure: sFA ErrorCode			
Error code	Description	Dec.	Hex.
Sopas_Error_LOCALCONDITIONFAILED	Local condition violated, e.g. giving a value that exceeds the minimum or maximum allowed value for this variable	4	4
Sopas_Error_INVALID_DATA	Invalid data given for variable, this errorcode is deprecated (is not used anymore).	5	5
Sopas_Error_UNKNOWN_ERROR	An error with unknown reason occurred, this errorcode is deprecated.	6	6
Sopas_Error_BUFFER_OVERFLOW	The communication buffer was too small for the amount of data that should be serialised.	7	7
Sopas_Error_BUFFER_UNDERFLOW	More data was expected, the allocated buffer could not be filled.	8	8
Sopas_Error_ERROR_UNKNOWN_TYPE	The variable that shall be serialised has an unknown type. This can only happen when there are variables in the firmware of the device that do not exist in the released description of the device. This should never happen.	9	9
Sopas_Error_VARIABLE_WRITE_ACCESSDENIED	It is not allowed to write values to this variable. Probably the variable is defined as read-only.	10	A
Sopas_Error_UNKNOWN_CMD_FOR_NAMESERVER	When using names instead of indices, a command was issued that the nameserver does not understand.	11	B
Sopas_Error_UNKNOWN_COLA_COMMAND	The CoLa protocol specification does not define the given command, command is unknown.	12	C
Sopas_Error_METHODIN_SERVER_BUSY	It is not possible to issue more than one command at a time to an SRT device.	13	D
Sopas_Error_FLEX_OUT_OF_BOUNDS	An array was accessed over its maximum length.	14	E
Sopas_Error_EVENTREG_UNKNOWNINDEX	The event you wanted to register for does not exist, the index is unknown.	15	F
Sopas_Error_COLA_A_VALUE_OVERFLOW	The value does not fit into the value field, it is too large.	16	10
Sopas_Error_COLA_A_INVALID_CHARACTER	Character is unknown, probably not alphanumeric.	17	11
Sopas_Error_OSAI_NO_MESSAGE	Only when using SRTOS in the firmware and distributed variables this error can occur. It is an indication that no operating system message could be created. This happens when trying to GET a variable.	18	12
Sopas_Error_OSAI_NO_ANSWER_MESSAGE	This is the same as <code>Sopas_Error_OSAI_NO_MESSAGE</code> with the difference that it is thrown when trying to PUT a variable.	19	13
Sopas_Error_INTERNAL	Internal error in the firmware, probably a pointer to a parameter was null.	20	14
Sopas_Error_HubAddressCorrupted	The Sopas Hubaddress is either too short or too long.	21	15
Sopas_Error_HubAddressDecoding	The Sopas Hubaddress is invalid, it can not be decoded (Syntax).	22	16
Sopas_Error_HubAddressAddressExceeded	Too many hubs in the address	23	17
Sopas_Error_HubAddressBlankExpected	When parsing a HubAddress an expected blank was not found. The HubAddress is not valid.	24	18

Telegram structure: sFA ErrorCode			
Error code	Description	Dec.	Hex.
Sopas_Error_AsyncMethodsAreSuppressed	An asynchronous method call was made although the device was built with "AsyncMethodsSuppressed". This is an internal error that should never happen in a released device.	25	19
Sopas_Error_ComplexArraysNotSupported	Device was built with „ComplexArraysSuppressed“ because the compiler does not allow recursions. But now a complex array was found. This is an internal error that should never happen in a released device.	26	20

Table 455: Example: sFA ErrorCode Wrong userlevel

CoLa A	<STX>sFA{SPC}1<ETX>
	02 73 46 41 20 31 03
CoLa B	02 02 02 02 00 00 00 05 73 46 41 20 00 01 75

Australia

Phone +61 (3) 9457 0600
1800 33 48 02 – tollfree
E-Mail sales@sick.com.au

Austria

Phone +43 (0) 2236 62288-0
E-Mail office@sick.at

Belgium/Luxembourg

Phone +32 (0) 2 466 55 66
E-Mail info@sick.be

Brazil

Phone +55 11 3215-4900
E-Mail comercial@sick.com.br

Canada

Phone +1 905.771.1444
E-Mail cs.canada@sick.com

Czech Republic

Phone +420 234 719 500
E-Mail sick@sick.cz

Chile

Phone +56 (2) 2274 7430
E-Mail chile@sick.com

China

Phone +86 20 2882 3600
E-Mail info.china@sick.net.cn

Denmark

Phone +45 45 82 64 00
E-Mail sick@sick.dk

Finland

Phone +358-9-25 15 800
E-Mail sick@sick.fi

France

Phone +33 1 64 62 35 00
E-Mail info@sick.fr

Germany

Phone +49 (0) 2 11 53 010
E-Mail info@sick.de

Greece

Phone +30 210 6825100
E-Mail office@sick.com.gr

Hong Kong

Phone +852 2153 6300
E-Mail ghk@sick.com.hk

Hungary

Phone +36 1 371 2680
E-Mail ertekesites@sick.hu

India

Phone +91-22-6119 8900
E-Mail info@sick-india.com

Israel

Phone +972 97110 11
E-Mail info@sick-sensors.com

Italy

Phone +39 02 27 43 41
E-Mail info@sick.it

Japan

Phone +81 3 5309 2112
E-Mail support@sick.jp

Malaysia

Phone +603-8080 7425
E-Mail enquiry.my@sick.com

Mexico

Phone +52 (472) 748 9451
E-Mail mexico@sick.com

Netherlands

Phone +31 (0) 30 204 40 00
E-Mail info@sick.nl

New Zealand

Phone +64 9 415 0459
0800 222 278 – tollfree
E-Mail sales@sick.co.nz

Norway

Phone +47 67 81 50 00
E-Mail sick@sick.no

Poland

Phone +48 22 539 41 00
E-Mail info@sick.pl

Romania

Phone +40 356-17 11 20
E-Mail office@sick.ro

Singapore

Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Slovakia

Phone +421 482 901 201
E-Mail mail@sick-sk.sk

Slovenia

Phone +386 591 78849
E-Mail office@sick.si

South Africa

Phone +27 10 060 0550
E-Mail info@sickautomation.co.za

South Korea

Phone +82 2 786 6321/4
E-Mail infokorea@sick.com

Spain

Phone +34 93 480 31 00
E-Mail info@sick.es

Sweden

Phone +46 10 110 10 00
E-Mail info@sick.se

Switzerland

Phone +41 41 619 29 39
E-Mail contact@sick.ch

Taiwan

Phone +886-2-2375-6288
E-Mail sales@sick.com.tw

Thailand

Phone +66 2 645 0009
E-Mail marcom.th@sick.com

Turkey

Phone +90 (216) 528 50 00
E-Mail info@sick.com.tr

United Arab Emirates

Phone +971 (0) 4 88 65 878
E-Mail contact@sick.ae

United Kingdom

Phone +44 (0)17278 31121
E-Mail info@sick.co.uk

USA

Phone +1 800.325.7425
E-Mail info@sick.com

Vietnam

Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Detailed addresses and further locations at www.sick.com